Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bonnlo SF105-18G+HA232-27

Bonnlo Freestanding Electric Fireplace Stove Instruction Manual

Model: SF105-18G+HA232-27 | Brand: Bonnlo

1. Important Safety Information

Please read all instructions carefully before using this electric fireplace. Failure to follow these instructions may result in fire, electric shock, or injury.

- **Electrical Safety:** Ensure the fireplace is connected to a properly grounded outlet. Do not overload electrical circuits.
- **Placement:** Place the fireplace on a firm, level surface. Maintain adequate clearance from combustible materials (curtains, furniture, bedding). Do not block air vents.
- **Overheat Protection:** This unit is equipped with automatic overheat protection. If the heater overheats, it will automatically shut off. Unplug the unit, allow it to cool, and then plug it back in.
- **Tip-Over Protection:** The fireplace includes tip-over protection, which automatically shuts off the unit if it is accidentally knocked over.
- **Children and Pets:** Keep children and pets away from the hot surfaces of the fireplace.
- **Maintenance:** Always unplug the fireplace before cleaning or performing any maintenance.
- **CSA Certified:** This product is CSA certified, meeting applicable safety and performance standards in North America.

2. Package Contents

Verify that all components are present and undamaged before assembly.

- 1 x Electric Fireplace Insert
- 1 x Wooden Cabinet
- 1 x Remote Control
- 1 x User's Manual (this document)

- 1 x Mounting Screw Pack

3. Assembly Instructions

Assembly is required for the wooden cabinet. Follow the detailed instructions provided in the included User's Manual and refer to the assembly video for visual guidance.

Video: Electric Fireplace Surround Assembly Guide. This video demonstrates the step-by-step assembly process for the wooden cabinet components of the electric fireplace.

Ensure all screws are tightened securely, but do not overtighten. Place the electric fireplace insert into the assembled cabinet once the cabinet is fully constructed.

4. Product Overview

Familiarize yourself with the components and controls of your Bonnlo Electric Fireplace Stove.



Image: The Bonnlo Freestanding Electric Fireplace Stove, showcasing its overall design and the realistic flame effect within the insert.

Control Panel



Image: Close-up of the fireplace's control panel, showing buttons for power, heat, flame, and timer settings, along with a digital display.

Remote Control



Image: The remote control for the electric fireplace, detailing buttons for power, heat, flame control, timer, and temperature adjustment.

5. Setup

Proper setup ensures optimal performance and safety.

- **Location:** Choose a location with a stable, level surface. Ensure there is sufficient space around the fireplace for proper ventilation and to avoid fire hazards.
- **Power Connection:** Plug the fireplace into a standard 120V AC grounded electrical outlet. Do not use extension cords or power strips.

6. Operating Instructions

Operate your electric fireplace using either the control panel on the unit or the provided remote control.

Video: Operation demonstration of a similar electric fireplace, showing flame effects, heat settings, and remote control usage.

Basic Functions:

- **Power On/Off:** Press the power button on the control panel or remote to turn the unit on or off.
- **Flame Control:** Press the flame button to cycle through 6 flame colors and 5 brightness levels (L1-L5). You can enjoy the flame effect independently without heat.
- **Heat Function:** Press the heat button to activate the 1400W heater. The digital display will show the current temperature setting.
- **Temperature Adjustment:** Use the temperature UP/DOWN buttons on the remote or control panel to set the desired temperature between 62°F and 82°F.
- **Timer Setting:** Press the timer button to set an automatic shut-off timer from 0.5 to 6 hours.



Image: Visual representation of the 6 flame colors and 5 brightness levels available on the electric fireplace, illustrating the customizable ambiance.



Image: Diagram illustrating the heating capability of the electric fireplace, showing warm air distribution in a room.

7. Maintenance

Regular maintenance ensures the longevity and safe operation of your fireplace.

- **Cleaning:** Disconnect power before cleaning. Use a soft, damp cloth to wipe surfaces. Do not use abrasive cleaners or solvents.
- **Ventilation:** Keep the air intake and exhaust vents clear of dust and debris. Use a vacuum cleaner with a brush attachment to clean the vents periodically.
- **Storage:** If storing the fireplace for an extended period, unplug it and store it in a dry, dust-free location.

8. Troubleshooting

Refer to this section for common issues and their solutions.

- **No Power:** Check if the power cord is securely plugged into a working outlet. Ensure the wall switch (if any) is on.
- **Heater Not Working:** If the flame effect works but there is no heat, ensure the heat function is activated and the temperature setting is above the ambient room temperature. Check for overheat protection activation (unplug, cool down, replug).
- **Remote Control Not Responding:** Check the remote control batteries and replace if necessary. Ensure there are no obstructions between the remote and the fireplace sensor.
- **Error Code 'E3':** If the display shows 'E3', this typically indicates an issue with the heating element or internal temperature sensor. Disconnect power, wait a few minutes, and then reconnect. If the error persists, contact customer support.

Video: A user demonstrating the 'E3' error code on the fireplace display, indicating a potential heating issue.

9. Specifications

Brand	Bonnlo
Model Name	SF105-18G+HA232-27
Power Source	AC
Power Consumption	1400W
Temperature Range	62°F - 82°F
Timer Range	0.5 - 6 Hours
Flame Colors	6
Flame Brightness Levels	5
Heating Coverage	Up to 400 sq ft
Material	Wooden, Iron & Glass
Color	Black & White
Wooden Cabinet Dimensions	26.38"W x 7.87"D x 21.22"H
Fireplace Insert Dimensions	18.11"W x 4.53"D x 17.32"H
Weight	35 lb
Certifications	CSA

10. Warranty and Support

This Bonnlo Electric Fireplace Stove comes with a**1-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, troubleshooting assistance, or warranty inquiries, please contact Bonnlo customer service through the retailer where the product was purchased or visit the official Bonnlo website for contact information.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DHX11PF5

More documents and user manuals: **https://manuals.plus/**