

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [ANCOON](#) /

> [ANCOON ANCOON-S01-Y Portable Bluetooth Speaker User Manual](#)

ANCOON ANCOON-S01-Y

ANCOON ANCOON-S01-Y Portable Bluetooth Speaker User Manual

Model: ANCOON-S01-Y

1. INTRODUCTION

Thank you for choosing the ANCOON ANCOON-S01-Y Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker. Designed for versatility, this speaker delivers powerful audio with deep bass, dynamic LED lighting, and robust IPX6 waterproofing, making it suitable for various indoor and outdoor environments.



Figure 1: ANCOON ANCOON-S01-Y Portable Bluetooth Speaker (Blue)

2. KEY FEATURES

- **80W Peak Power & Deep Bass:** Equipped with two 40W full-range speakers and two diaphragms for a powerful, authentic auditory experience.
- **IPX6 Waterproof:** Built to withstand water splashes and rain, ideal for outdoor use.
- **20-Hour Playtime:** Integrated 10000mAh battery provides extended music playback.
- **Dynamic LED Lights:** Features six light switching modes to enhance your listening environment.
- **TWS Stereo Surround:** Pair two ANCOON speakers for an immersive spatial audio experience.
- **Bluetooth 5.3:** Ensures stable and fast wireless connection with compatible devices.
- **Built-in Power Bank:** USB port allows charging of external devices.



Figure 2: Internal Speaker Components and Bass Boost Technology

3. WHAT'S IN THE BOX

- ANCOON ANCOON-S01-Y Main Unit
- User Manual
- Aux Cable
- Type C Charging Cable

4. SETUP

4.1 Initial Charging

1. Connect the provided Type C charging cable to the speaker's Type C port (located under the rubber flap on the back).
2. Connect the other end of the cable to a compatible USB power adapter (not included).
3. Charge the speaker fully before first use. A full charge takes approximately 6 hours.

4.2 Bluetooth Pairing

1. Press and hold the Power button () on the top panel to turn on the speaker. The LED lights will illuminate, and you will hear an audible prompt indicating it's in pairing mode.
2. On your mobile device (smartphone, tablet, laptop), enable Bluetooth.
3. Search for available Bluetooth devices and select "ANCOON-S01-Y" from the list.
4. Once connected, you will hear a confirmation tone.

4.3 TWS (True Wireless Stereo) Pairing (Optional)

To achieve a stereo sound experience, you can pair two ANCOON ANCOON-S01-Y speakers together:

1. Ensure both speakers are powered on and not connected to any other Bluetooth device.
2. On one speaker (this will be the primary speaker), press the 'M' button twice. The speaker will enter TWS pairing mode.
3. The two speakers will automatically search for and connect to each other. A confirmation tone will sound once paired.
4. Connect your mobile device to the primary speaker via Bluetooth as described in section 4.2.

TRUE WIRELESS STEREO SURROUND

Enjoy your outdoor activities immersively



Figure 3: TWS Stereo Surround Pairing

5. OPERATING INSTRUCTIONS

5.1 Basic Controls

- **Power Button ():** Press and hold to turn on/off. Short press to play/pause music.
- **Bass Button:** Press to toggle Deep Bass mode on/off.
- **Volume Down (-):** Short press to decrease volume.
- **Previous Track ():** Long press to go to the previous track.
- **Volume Up (+):** Short press to increase volume.
- **Next Track ():** Long press to go to the next track.

- **Mode Button (M):** Short press to cycle through input modes (Bluetooth, AUX, USB). Double press for TWS pairing.
- **Light Mode Button (* /):** Press to cycle through 6 different LED light modes or turn lights off.

5.2 LED Light Modes

The speaker features six dynamic LED light modes that can be changed by pressing the Light Mode button:

- Flame
- Breathing
- Flash
- Wander
- Meteors
- Rainbow

6 LED MODES-10 COLORS

Colorful LED lights that dance to the beat of the music



Flame



Breathing



Flash



Wander



Meteors



Rainbow



Figure 4: Six LED Light Modes

5.3 Using as a Power Bank

To charge an external device using the speaker's built-in power bank function:

1. Open the rubber flap on the back of the speaker to access the ports.
2. Connect your device's charging cable to the USB-A output port on the speaker.
3. Your device will begin charging.

BUILT-IN POWER BANK



Figure 5: Charging an External Device

6. MAINTENANCE

6.1 Cleaning

Wipe the speaker with a soft, damp cloth. Do not use harsh chemicals or abrasive cleaners. Ensure all port covers are securely closed before exposing the speaker to water.

6.2 Water Resistance

The speaker is IPX6 waterproof, meaning it can resist high-pressure, multi-directional water jets. It is suitable for use in rainy conditions or near pools, but should not be submerged in water.

IPX6 WATERPROOF

Keep the beat playing in the rain
on the beach or by the pool!

IPX6



Figure 6: IPX6 Waterproof Feature

7. TROUBLESHOOTING

- **Speaker not turning on:** Ensure the battery is charged. Connect to a power source using the Type C cable.
- **Cannot pair via Bluetooth:** Make sure the speaker is in pairing mode (LEDs flashing). Ensure your device's Bluetooth is enabled and within range (up to 100 feet). Forget previous pairings on your device and try again.
- **No sound:** Check the volume levels on both the speaker and your connected device. Ensure the correct input mode is selected (Bluetooth, AUX, USB).
- **TWS pairing issues:** Ensure both speakers are fully charged and not connected to any other

Bluetooth device before initiating TWS pairing.

- **Sound distortion:** Reduce the volume on both the speaker and your device. Ensure the audio source is of good quality.

8. SPECIFICATIONS

Model Name	ANCOON-S01-Y
Brand	ANCOON
Speaker Type	Portable Bluetooth Speaker (Indoor/Outdoor)
Connectivity Technology	Bluetooth 5.3
Speaker Output Power	80W (Peak)
Audio Output Mode	Stereo
Water Resistance Level	IPX6 Waterproof
Battery Capacity	10000mAh
Playtime	Up to 20 hours (actual time varies with volume)
Charging Time	Approx. 6 hours
Bluetooth Range	Up to 100 feet
Product Dimensions	10.4"D x 6.3"W x 5.7"H
Item Weight	4.8 Pounds
Material	Acrylonitrile Butadiene Styrene (ABS) Metallic

9. WARRANTY & SUPPORT

This ANCOON product comes with a limited warranty. For detailed warranty information, please refer to the warranty card included in your product packaging or visit the official ANCOON website. For technical support, troubleshooting assistance, or any inquiries, please contact ANCOON customer service through the contact information provided on the official website or your purchase platform.