

[Manuals.plus](#) /

› [COMHOMA](#) /

› COMHOMA Ergonomic Executive Office Chair CH158 User Manual

COMHOMA CH158

COMHOMA Ergonomic Executive Office Chair CH158 User Manual

Model: CH158

1. INTRODUCTION

Thank you for choosing the COMHOMA Ergonomic Executive Office Chair CH158. This manual provides essential information for the safe assembly, operation, and maintenance of your new office chair. Please read these instructions carefully before assembly and retain them for future reference.



Image 1: The COMHOMA Ergonomic Executive Office Chair CH158. This image displays the full chair in a light black finish, featuring a high back, padded armrests, and a five-star base with rolling casters.

2. SAFETY INFORMATION

- **Maximum Weight Limit:** The chair is designed to support a maximum weight of 400 lbs (181 kg). Do not exceed this limit to prevent damage or injury.
- **Assembly:** Follow all assembly instructions carefully. Ensure all bolts and screws are securely tightened before use. Re-tighten all fasteners every 6 months to maintain stability.
- **Usage:** Use adjustable features with caution. Avoid standing on the chair or using it as a step stool.
- **Maintenance:** Regularly inspect the chair for loose parts, damage, or wear. Discontinue use if any issues are found and contact customer service.
- **Children:** Keep children away from the chair during assembly. This product is intended for adult use.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

- Backrest
- Seat Cushion
- Armrests (2)
- Chair Base (5-star)
- Casters (5)
- Gas Lift Cylinder
- Mechanism Plate
- Hardware Kit (screws, washers, Allen wrench)
- Instruction Manual



Image 2: Key components of the COMHOMA Executive Office Chair. This image highlights the gas lift cylinder, the chair's mechanism plate, the five-star chair base, and the rolling casters, illustrating the durable construction of these parts.

4. ASSEMBLY INSTRUCTIONS

Assembly typically takes one person approximately 30 minutes. An illustrated manual and all necessary tools are included in the package.

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of each leg of the chair base. Push firmly until they click into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled chair base.
3. **Attach Mechanism to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Secure it with the provided screws, ensuring the front of the mechanism faces the front of the seat.
4. **Attach Armrests to Seat:** Secure the armrests to the sides of the seat cushion using the designated screws. Do not fully tighten yet.
5. **Attach Backrest to Seat and Armrests:** Connect the backrest to the seat cushion and the armrests. Once all connections are aligned, fully tighten all screws for the armrests and backrest.
6. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the center hole of the mechanism plate aligns with the top of the gas lift. Press down firmly to secure.

Ensure all bolts are completely tightened for stability and safety. Periodically check and re-tighten bolts every six months.

5. OPERATING INSTRUCTIONS

Your COMHOMA Executive Office Chair features several adjustable functions to enhance comfort and support.

- **Height Adjustment:** To adjust the seat height, pull the lever located under the right side of the seat upwards. While seated, lift the lever to lower the seat. To raise the seat, lift the lever while standing or with minimal weight on the seat. Release the lever to lock the height.
- **Tilt/Rocking Function:** To enable the rocking function, pull the same lever (under the right side of the seat) outwards. Push it inwards to lock the chair in an upright position. The chair offers a rocking range of 90° to 120°.
- **Tilt Tension Adjustment:** The round knob located under the front-center of the seat controls the tilt tension. Turn clockwise to increase tension (making it harder to recline) or counter-clockwise to decrease tension (making it easier to recline).
- **360-Degree Swivel:** The chair seat can freely rotate 360 degrees for easy movement and access to your workspace.
- **Rolling Casters:** The smooth-rolling casters allow for easy mobility across hard floors.



Image 3: Operational features of the COMHOMA Executive Office Chair. This graphic illustrates the 360-degree swivel, 90-120 degree rocking function, 3.93-inch height adjustment range, and silent smooth casters for enhanced user experience.

6. MAINTENANCE

To ensure the longevity and appearance of your COMHOMA Executive Office Chair, follow these simple maintenance guidelines:

- **Cleaning:** The PU leather cover is waterproof and resistant to spills. Wipe clean with a damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the material.
- **Fasteners:** Periodically check all screws and bolts for tightness. Re-tighten as needed, approximately every six months, to maintain the chair's structural integrity.
- **Casters:** Keep casters free of hair and debris to ensure smooth rolling.
- **Gas Lift:** If the gas lift cylinder begins to lose its ability to hold height, contact customer service for assistance.

7. TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common troubleshooting tips:

- **Chair is unstable/wobbly:** Ensure all assembly screws are fully tightened. Check that the gas lift is properly seated in the base and mechanism.
- **Chair does not adjust height:** Verify that the gas lift lever is functioning correctly and not stuck. Ensure the gas lift cylinder is properly installed. If the gas lift is faulty, it may need replacement.
- **Casters do not roll smoothly:** Check casters for accumulated hair, dust, or debris. Clean them thoroughly. Ensure casters are fully inserted into the chair base.
- **Chair squeaks:** Apply a small amount of lubricant to moving parts, such as the mechanism plate, gas lift, and caster stems. Ensure all screws are tight.
- **Backrest does not recline/tilt:** Ensure the tilt lock lever is disengaged (pulled outwards). Adjust the tilt tension knob counter-clockwise to reduce resistance.

If problems persist after attempting these solutions, please contact COMHOMA customer service.

8. SPECIFICATIONS

Feature	Detail
Brand	COMHOMA
Model Name	CH158
Color	Light Black
Product Dimensions	20"D x 20"W x 40"H
Seat Depth	19.68 inches
Seat Height	Adjustable, up to 29.13 inches
Item Weight	30 pounds
Maximum Weight Recommendation	400 Pounds
Material	PU Leather, Sponge (Fill Material), FSC-Certified Wood (Seat cushion inner support)
Special Features	Adjustable Height, Adjustable Head Support, Padded Armrests, Ergonomic, Reclining (2 positions), Rolling, Swivel
Gas Lift	SGS Class-3, 120,000+ lift test passed
Mechanism	BIFMA tested, 100,000+ durability test passed
UPC	810170301483



Image 4: Detailed dimensions of the COMHOMA Executive Office Chair. This image provides measurements for the seat width (20.86 inches), seat height range (19.29 to 23.22 inches), backrest height (29.13 inches), and overall chair height range (41.73 to 45.66 inches), along with the 400 lbs weight capacity.

9. WARRANTY AND SUPPORT

COMHOMA stands behind the quality of its products.

- **Replacement Services:** We offer 30-day replacement services for any manufacturing defects or issues.
- **Parts Quality Warranty:** A 1-year warranty is provided for parts quality.
- **Customer Service:** Our 24/7 customer service team is available to assist you with any questions, concerns, or issues you may have. Please refer to the contact information provided with your purchase or visit the official COMHOMA website for support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DHX7786B>

More documents and user manuals: <https://manuals.plus/>