

[Manuals.plus](#) /

› [ANCOON](#) /

› ANCOON Bluetooth Speaker Instruction Manual

ANCOON ANCOON-S01-Y

ANCOON Bluetooth Speaker

INSTRUCTION MANUAL

Introduction

Thank you for choosing the ANCOON Bluetooth Speaker. This powerful and versatile speaker is designed to deliver an immersive audio experience with deep bass, vibrant LED lights, and robust waterproof durability. Ideal for various environments including job sites, outdoor gatherings, workshops, and garages, this manual will guide you through its features, setup, operation, and maintenance to ensure optimal performance.



Front view of the ANCOON Bluetooth speaker, showcasing its rugged design and IPX6 waterproof rating.

What's in the Box

Please check the package contents to ensure all items are present:

- Main Unit (ANCOON Bluetooth Speaker)
- AUX Cable
- Type-C Cable
- User Manual

Product Features

IPX6 Waterproof & Durable

The ANCOON speaker features IPX6-level waterproof capabilities, making it resistant to strong water jets. Its solid and shock-resistant build ensures durability in challenging environments like garages, construction sites, and outdoor settings.

IPX6 WATERPROOF

Keep the beat playing in the rain
on the beach or by the pool!

IPX6



The ANCOON speaker is designed to withstand water splashes and jets, perfect for poolside or outdoor use.

Tireless Companions: Extended Playtime & Bluetooth 5.3

Equipped with a large 10000mAh battery, the speaker offers over 20 hours of playtime on a full charge (actual time varies with volume). Bluetooth 5.3 technology ensures stable and fast connections with any Bluetooth audio source device.

UP TO 20H PLAYTIME

Enjoy your outdoor activities immersively



20H
PLAYTIME

Enjoy extended music playback with the speaker's long-lasting battery, ideal for all-day adventures.

Ultimate Listening Experience: 80W Peak Power & Deep Bass

Experience vivid and powerful sound with the 80W peak power speaker, featuring two reinforced speaker magnets, two diaphragms, and Deep Bass technology. It's capable of penetrating most ambient noise, providing a natural and authentic auditory experience.

80W BASS BOOSTED 2.0

Crash Protection Sleeve

80W



2x40W
Full-Range Speaker

Colorful Light Show

Tip: The speaker has a built-in 10000mAh battery, no need to buy extra batteries. Does not come with AM/FM function.

Internal components of the speaker, highlighting the 80W peak power and bass-boosting technology.

A Visual Journey of Fun: 6 LED Light Modes

Enhance your sensory experience with six dynamic LED light switching modes that create a party atmosphere and make music more enjoyable. Perfect for hard rock and punk styles.

6 LED MODES-10 COLORS

Colorful LED lights that dance to the beat of the music



Flame



Breathing



Flash



Wander



Meteors



Rainbow



The speaker features multiple LED light modes to complement your music and create a lively ambiance.

TWS Stereo Surround

The ANCOON speaker supports True Wireless Stereo (TWS) functionality, allowing you to pair two speakers for a powerful, immersive spatial audio experience.

TRUE WIRELESS STEREO SURROUND

Enjoy your outdoor activities immersively



Two ANCOON speakers wirelessly connected for an enhanced stereo surround sound experience.

Built-in Power Bank

Utilize the speaker's large battery capacity (10000mAh) to charge your other devices via its USB port, serving as a convenient emergency power bank.

BUILT-IN POWER BANK



The speaker can also function as a power bank to charge your mobile devices on the go.

Setup

Initial Charging

1. Before first use, fully charge the speaker using the provided Type-C cable. The charging time is approximately 6 hours.

2. Connect the Type-C cable to the speaker's Type-C port and the other end to a compatible USB power adapter (not included).
3. The charging indicator light will show charging status and turn off when fully charged.

Power On/Off

- To power on, press and hold the Power button () located on the top panel until you hear an audible prompt and the LED lights illuminate.
- To power off, press and hold the Power button () again until the speaker powers down.

Operating Instructions

Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth pairing mode (indicated by flashing blue LED lights).
2. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
3. Select "ANCOON-S01" from the list of devices.
4. Once connected, you will hear a confirmation sound, and the blue LED light will become solid.

TWS (True Wireless Stereo) Pairing

To achieve a stereo sound experience, you can pair two ANCOON-S01 speakers together:

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker, press and hold the 'M' (Mode) button for 3 seconds. You will hear a prompt indicating TWS pairing mode.
3. The two speakers will automatically connect to each other. Once paired, you will hear a confirmation sound.
4. Now, connect your device to one of the paired speakers via Bluetooth as described in the "Bluetooth Pairing" section. Both speakers will play audio in stereo.

Adjusting Volume and Playback

- **Volume Up:** Press the '+' button.
- **Volume Down:** Press the '-' button.
- **Next Track:** Press and hold the '+' button.
- **Previous Track:** Press and hold the '-' button.
- **Play/Pause:** Press the Play/Pause button (▶||).

Bass Boost Function

- Press the 'BASS' button to toggle the Deep Bass technology on or off.

LED Light Modes

- Press the Light Mode button (✱) to cycle through the 6 available LED light modes.
- The modes include: Flame, Breathing, Flash, Wander, Meteors, and Rainbow.

Using as a Power Bank

- Open the rubber cover on the back of the speaker to access the USB-A output port.
- Connect your device's charging cable to the USB-A port on the speaker.
- The speaker will begin charging your device.

Other Audio Input Modes (AUX, USB Disk, Microphone)

- **AUX Input:** Connect an external audio device using the provided AUX cable to the 3.5mm AUX port. The speaker will automatically switch to AUX mode.
- **USB Disk Playback:** Insert a USB flash drive into the USB-A port. The speaker will automatically detect and play audio files from the drive.
- **Microphone Input:** Connect a microphone (not included) to the MIC jack for karaoke or public speaking.

Maintenance

- **Cleaning:** Use a soft, damp cloth to clean the speaker's exterior. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Protection:** Always ensure the rubber cover for the ports is securely closed when using the speaker near water to maintain its IPX6 rating.
- **Battery Care:** To prolong battery life, avoid fully discharging the speaker frequently. Charge it regularly, even if not in use for extended periods.

Troubleshooting

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from device.	Ensure speaker is in pairing mode. Turn device Bluetooth on/off. Move speaker closer to device.
No sound.	Volume too low; incorrect input mode; device not playing.	Increase volume on speaker and device. Check input mode. Ensure device is playing audio.
TWS pairing failed.	Speakers already paired to another device; too far apart.	Disconnect speakers from other devices. Ensure speakers are within close proximity for TWS pairing.

Specifications

Feature	Detail
Brand	ANCOON
Model Name	ANCOON-S01-Y
Speaker Maximum Output Power	80 Watts (Peak)
Connectivity Technology	Bluetooth 5.3
Bluetooth Range	100 Feet
Water Resistance Level	IPX6 Waterproof
Battery Capacity	10000 Milliamp Hours
Battery Life	20 Hours
Charging Time	6 Hours
Product Dimensions	10.4"D x 6.3"W x 5.7"H

Feature	Detail
---------	--------

Item Weight	4.8 Pounds
Special Features	Bass Boost, Portable, Waterproof, LED Light, Stereo Pairing, Built-in Power Bank
Included Components	AUX Cable, User Manual, Main Unit, Type-C Cable

Warranty and Support

The ANCOON Bluetooth Speaker comes with a Limited Warranty. For detailed warranty information and support, please refer to the official User Manual PDF or contact ANCOON customer service.

Additional protection plans may be available for purchase:

- 2-Year Protection Plan
- 3-Year Protection Plan
- Complete Protect (monthly plan)

For more information about ANCOON products, visit the official brand store:[ANCOON Store](#)

You can also access the User Manual (PDF) directly via this link:[User Manual PDF](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

