

[Manuals.plus](#) /

> [ANCwear](#) /

> ANCwear FX-906V Wireless Bluetooth Earbuds User Manual

ANCwear FX-906V

ANCwear FX-906V Wireless Bluetooth Earbuds User Manual

Model: FX-906V

PRODUCT OVERVIEW

The ANCwear FX-906V Wireless Bluetooth Earbuds combine a nostalgic design with modern Bluetooth 5.2 connectivity. These earbuds are designed for daily use, offering comfort and reliable audio performance. The retro-styled charging case provides portability and protection.





Image: ANCwear FX-906V Wireless Bluetooth Earbuds shown with their retro-inspired charging case. The earbuds are purple and designed for an in-ear fit.

PACKAGE CONTENTS

Please check the package for the following items:

- ANCwear FX-906V Wireless Bluetooth Earbuds (Left and Right)
- Retro Charging Case
- USB-C Charging Cable
- User Manual

SETUP GUIDE

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. **Charge the Case:** Connect the provided USB-C cable to the charging port on the retro charging case and the other end to a USB power adapter (not included). The indicator light on the case will show charging status.
2. **Charge the Earbuds:** Place the earbuds into their respective slots in the charging case. Ensure they are correctly

seated. The earbuds will begin charging automatically.

A full charge provides up to 17 hours of playback time.

2. Pairing with a Device

1. **Power On:** Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. **Activate Bluetooth:** On your device (smartphone, tablet, etc.), go to the Bluetooth settings and enable Bluetooth.
3. **Select Device:** Look for "ANCwear FX-906V" (or similar) in the list of available Bluetooth devices and select it to connect.
4. **Confirmation:** Once connected, you will hear an audio prompt from the earbuds, and the device will show them as connected.

The earbuds will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

OPERATING INSTRUCTIONS

Touch Controls

The ANCwear FX-906V earbuds feature intuitive touch controls on each earbud. The functions are as follows:

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Right Earbud)	Next Track
Double Tap (Left Earbud)	Previous Track
Triple Tap (Right Earbud)	Volume Up
Triple Tap (Left Earbud)	Volume Down
Long Press (2 seconds)	Reject Call, Activate Voice Assistant

Wearing the Earbuds

For optimal sound quality and comfort, ensure the earbuds are properly seated in your ears. Each earbud is marked 'L' for left and 'R' for right.

- Gently insert the earbud into your ear canal.
- Rotate the earbud slightly until it feels secure and comfortable.

MAINTENANCE

Proper maintenance ensures the longevity and performance of your earbuds.

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage.
- **Avoid Water:** The earbuds are not waterproof. Avoid exposure to water, moisture, or extreme temperatures.
- **Charging Port:** Keep the USB-C charging port free of debris.

TROUBLESHOOTING

If you encounter issues with your ANCwear FX-906V earbuds, refer to the following common solutions:

1. Earbuds not pairing:

- Ensure both earbuds are charged.
- Turn off Bluetooth on your device, then turn it back on.
- Forget the device "ANCwear FX-906V" from your device's Bluetooth settings and attempt to pair again.
- Place earbuds back in the case, close the lid, wait 10 seconds, then open to re-initiate pairing mode.

2. No sound from one earbud:

- Ensure both earbuds are charged.
- Try resetting the earbuds (refer to the full manual for specific reset instructions if available, or try placing them back in the case and re-pairing).
- Clean the charging contacts on both the earbuds and the case.

3. Charging issues:

- Check the USB-C cable and power adapter for damage.
- Ensure the charging cable is securely connected to both the case and the power source.
- Verify that the earbuds are correctly seated in the charging case.

SPECIFICATIONS

Feature	Detail
Brand	ANCwear
Model Number	FX-906V
Color	Purple
Ear Placement	In Ear
Impedance	32 Ohms
Noise Control	Active Noise Cancellation
Frequency Range	20 Hz - 20,000 Hz
Connectivity Technology	Wireless
Wireless Technology	Bluetooth
Bluetooth Version	5.2
Control Method	Touch
Playtime	Up to 17 hours (with charging case)
Earbud Weight	3g (each)

WARRANTY AND SUPPORT

The ANCwear FX-906V Wireless Bluetooth Earbuds come with a **1-year manufacturer's warranty** from the date of

purchase.

For warranty claims, technical support, or further assistance, please contact ANCwear customer service through the retailer where the product was purchased or visit the official ANCwear website.

Manufacturer: ANCwear

ASIN: B0DHXCF6KP