LAUSAINT HOME 12'x12' Outdoor Patio Gazebo

LAUSAINT HOME 12'x12' Outdoor Patio Gazebo Instruction Manual

Model: 12'x12' Outdoor Patio Gazebo

1. Important Safety Information

WARNING: Do not use the gazebo in heavy rain, strong wind, heavy snow, or other similar extreme weather conditions. In case of such weather, please remove the canopy top, curtains, and netting immediately to avoid potential safety hazards and damage to the product. Always secure the gazebo with ground stakes or expansion bolts for maximum stability and long-term outdoor use.
Ensure all components are securely fastened before and during use. Regularly inspect the structure for any signs of wear or damage.

2. Product Overview

This LAUSAINT HOME 12'x12' Outdoor Patio Gazebo is designed for outdoor use, providing shade and shelter. It features a heavy-duty galvanized steel frame, a double-tier roof for ventilation, and includes mosquito netting and privacy curtains.



Image: Fully assembled 12'x12' gazebo with curtains and netting, situated next to a pool.

Key Features:

- **Heavy-Duty Galvanized Steel Frame:** Provides durability and stability, resistant to rust and corrosion.
- **1500MM Waterproof Polyester Canopy:** Offers water resistance for light rain and UPF 50+ UV protection.
- **Double-Tier Roof:** Enhances airflow and ventilation, with integrated mesh to deter insects.
- **Mosquito Netting and Privacy Curtains:** Zippered netting for insect protection and waterproof curtains for privacy and shade.
- **Center Ceiling Hook:** Suitable for hanging lights, fans, or decorations (weight capacity 44 lbs).
- **Expansion Bolts:** Included for secure fixing on various surfaces like concrete, grass, or wooden decks.

3. Components List

Before assembly, ensure all parts are present and undamaged. Refer to the packaging list for specific quantities. Common components include:

- Main Frame Poles (Legs, Beams, Roof Supports)
- Roof Canopy Fabric (Main and Upper Tier)
- Mosquito Netting Panels
- Privacy Curtain Panels
- Connectors and Fasteners (Screws, Bolts, Washers, Nuts)
- Ground Stakes and Ropes
- Expansion Bolts (12 pcs)




Image: Included expansion bolts, stakes, and ropes for securing the gazebo to various surfaces.

4. Setup and Assembly Instructions

Assembly typically requires two people and can take approximately 1.5 to 4 hours depending on experience. Follow the steps carefully and do not overtighten screws until instructed.

General Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components and verify against the parts list.
2. **Assemble Base Frame:** Connect the leg poles and horizontal beams to form the base structure.
3. **Install Roof Supports:** Attach the roof support beams to the top of the leg poles.
4. **Attach Canopy:** Carefully place the main canopy fabric over the roof structure. Ensure proper orientation.
5. **Install Upper Roof:** Secure the smaller upper canopy to the top tier of the roof frame.
6. **Hang Netting and Curtains:** Attach the mosquito netting and privacy curtains to the designated tracks or hooks.
7. **Secure Gazebo:** Use the provided ground stakes, ropes, or expansion bolts to firmly anchor the gazebo to the ground. For concrete or wooden decks, use expansion bolts for maximum stability.




Image: Product dimensions for planning placement and assembly.




Image: Premium track design allowing separate operation of curtains and netting.

5. Operating Instructions

Using Mosquito Netting and Privacy Curtains:

- The gazebo includes dual tracks for separate operation of the mosquito netting and privacy curtains.
- Use the zippers on the netting and curtains to open or close them as needed for insect protection or privacy.
- When not in use, the curtains and netting can be tied back using the integrated Velcro straps or elastic buckles.




Image: Velcro straps for organizing curtains and netting.

Hanging Decorations:

- A central hook is provided for hanging lights, fans, or other decorations. The maximum weight capacity for this hook is 44 lbs.
- Additional D-rings or corner rings are available for string lights or wind ropes.



Image: Central hanging hook and corner rings for attaching lights or other decorations.

6. Maintenance

- **Cleaning:** Clean the canopy fabric and frame with mild soap and water. Avoid harsh chemicals that may damage the material.
- **Seasonal Care:** During off-seasons or periods of non-use, it is recommended to store the canopy fabric, netting, and curtains indoors to prolong their lifespan.
- **Extreme Weather:** As noted in the safety information, remove the canopy, curtains, and netting during strong winds, heavy rain, snow, or storms to prevent damage.
- **Frame Inspection:** Periodically check all bolts and connections to ensure they remain tight. Re-tighten as necessary.
- **Drainage:** The canopy features side drainage holes to prevent water buildup. Ensure these remain clear of debris.




Image: Vented double roof design for improved airflow and heat dissipation.

7. Troubleshooting

- **Difficulty with Assembly:** If a part does not fit, double-check the instruction manual and ensure you are using the correct parts for that step. Do not force components. Some parts, like the roof canopy, may require firm but gentle pulling to fit correctly.
- **Gazebo Instability:** Ensure all frame connections are tightened. Verify that the gazebo is properly anchored to the ground using all provided stakes, ropes, or expansion bolts. Re-evaluate the ground surface for levelness.
- **Water Accumulation on Roof:** Check if the canopy is installed correctly and taut. Ensure the side drainage holes are not blocked.
- **Mosquitoes/Insects Entering:** Ensure all zippers on the netting are fully closed and there are no gaps. Check for any tears in the netting.

8. Specifications

Attribute	Detail
Brand	LAUSAINT HOME
Model	12'x12' Outdoor Patio Gazebo
Material	Metal (Frame), Polyester (Canopy)
Frame Material	Iron (Galvanized Steel)
Product Dimensions (L x W x H)	141.73"L x 141.73"W x 112.99"H
Floor Area	144 square feet
Water Resistance Level	Waterproof (1500MM)
UV Protection	UPF 50+
Color	Khaki
Number of Items	1

9. Warranty and Support

This product is typically covered by a 30-day return policy. For specific warranty details or customer support, please refer to your purchase documentation or contact the seller directly. Ensure you retain your proof of purchase for any warranty claims.

For assistance with assembly, missing parts, or product issues, please contact LAUSAINT HOME customer service or the retailer from whom you purchased the gazebo.

© 2026 LAUSAINT HOME. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question