

KUZOR AZ3003H-B

KUZOR AZ3003H-B Tall Matte Black Vessel Sink Faucet

Model: AZ3003H-B | Brand: KUZOR

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your KUZOR AZ3003H-B Tall Matte Black Vessel Sink Faucet. Please read these instructions carefully before installation and retain for future reference.

Included Components:

- Vessel Sink Faucet (Matte Black)
- Hot & Cold Water Supply Hoses (pre-attached)
- Fixing Part
- Pop-up Drain with Overflow (Matte Black)
- Installation Hardware
- Instruction Manual




Figure 1: Included Components

Your browser does not support the video tag.

Video 1: KUZOR Vessel Sink Faucet Unboxing and Overview. This video demonstrates the unboxing process and

provides a general overview of the faucet's features and components.

2. PRODUCT FEATURES

- **Sturdy & Dependable:** Crafted with premium metal components, including a SUS304 body, metal pop-up drain, and a drip-free ceramic cartridge.
- **Splash-Proof Design:** Features a vertical detachable water spout designed to prevent splashing and direct water flow into the sink.
- **Modern Aesthetic:** The square geometric shape and minimalist matte black finish add a contemporary touch to any bathroom.
- **Easy Operation:** Flexible single handle design provides accurate control over water flow and temperature.
- **Water Efficiency:** Eco-friendly aerator provides a steady and splash-free stream with a 1.2 GPM flow rate.

Modern & Sleek



MINIMALISM Square Shape

-  90° Vertical Spout
-  Premium 304 SS Body



Figure 2: Modern & Sleek Design

OUR ADVANTAGE

**Detachable
Easy to clean**



**Free Operation
Handle**



Eco-Friendly Aerator

Provides a steady and splash-free stream (1.2 GPM Flow Rate)



METAL POP UP DRAIN



**Build-in Strainer
Prevent dirt, hair, ring from
clogging up**

Figure 3: Eco-Friendly Aerator and Metal Pop-Up Drain

3. SETUP & INSTALLATION

Installation is designed to be straightforward for single-hole setups. The faucet comes with pre-attached hot and cold water supply hoses for convenience. A deck plate is NOT included, as this faucet is primarily designed for single-hole vessel sinks.

Pre-Installation Requirements:

- Ensure your sink has a pre-drilled hole size between 1.26 inches (min) and 1.85 inches (max).
- Maximum countertop thickness should not exceed 1.41 inches.
- Turn off the main water supply before beginning installation.



Figure 4: Faucet Dimensions and Sink Hole Requirements

Installation Steps:

1. Remove your old faucet and clean the sink area thoroughly.
2. Insert the new KUZOR faucet into the pre-drilled hole on your sink. Ensure the pre-attached hot and cold water supply hoses pass through the hole.
3. From underneath the sink, secure the faucet using the provided fixing part and installation hardware. Tighten firmly but do not overtighten.
4. Connect the hot and cold water supply hoses to your water supply lines. Ensure a watertight seal.
5. Install the metal pop-up drain into the sink drain opening. Follow the specific instructions provided with the drain for proper sealing and connection to your P-trap.
6. Once all connections are secure, slowly turn on the main water supply and check for any leaks.

Your browser does not support the video tag.

Video 2: KUZOR Faucet Installation Guide. This video provides a visual guide to installing the KUZOR vessel sink faucet and pop-up drain.

Your browser does not support the video tag.

Video 3: KUZOR Faucet Installation Overview. This video offers an additional perspective on the installation process for the KUZOR faucet.

4. OPERATING INSTRUCTIONS

The KUZOR AZ3003H-B faucet features a single lever handle for controlling water flow and temperature, and a push-button pop-up drain for convenience.

Faucet Operation:

- To turn on the water, lift the lever handle upwards.
- To increase water flow, lift the handle further.
- To decrease water flow, lower the handle.
- To adjust water temperature, move the lever handle left for hot water and right for cold water.
- To turn off the water, push the lever handle downwards to its original closed position.

Pop-Up Drain Operation:

- To close the drain and fill the sink, press down firmly on the top of the drain stopper.
- To open the drain and allow water to flow out, press down firmly on the drain stopper again.

Your browser does not support the video tag.

Video 4: KUZOR Faucet Operation Demonstration. This video illustrates the use of the single lever handle for water control and the pop-up drain mechanism.

5. MAINTENANCE

Proper maintenance will ensure the longevity and optimal performance of your KUZOR faucet.

Cleaning:

- Clean the faucet regularly with a soft, damp cloth and mild soap.
- Avoid using abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the matte black finish.
- Dry the faucet immediately after cleaning to prevent water spots.

Aerator Maintenance:

- If water flow becomes restricted, the aerator may be clogged with mineral deposits.
- The aerator is detachable. Gently unscrew it from the spout.
- Rinse the aerator under running water to remove debris. For stubborn deposits, soak it in a solution of equal parts white vinegar and water.
- Reattach the aerator securely.

Drain Maintenance:

- Periodically check the pop-up drain for hair and debris buildup to prevent clogging.
- The drain stopper can be easily removed for cleaning.

6. TROUBLESHOOTING

If you encounter issues with your KUZOR faucet, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator; partially closed water supply valves.	Clean the aerator (see Maintenance section). Ensure hot and cold water supply valves under the sink are fully open.
Leaks from Faucet Base	Loose mounting nut; improper sealing.	Tighten the mounting nut underneath the sink. Ensure rubber gaskets are correctly seated.
Leaks from Handle	Worn ceramic cartridge.	Contact KUZOR customer service for assistance or professional plumbing advice.
Pop-Up Drain Not Sealing	Debris in drain; improper installation of drain stopper.	Remove and clean the drain stopper. Reinstall the drain ensuring proper alignment and sealing.
No Hot/Cold Water	Water supply valve closed; reversed hot/cold connections.	Check that both hot and cold water supply valves are fully open. Verify hot and cold hoses are connected to the correct supply lines.

If these steps do not resolve the issue, please contact KUZOR customer support.

7. SPECIFICATIONS

Feature	Detail
Brand	KUZOR
Model Name	AZ3003H-B
Recommended Uses	Bathroom
Mounting Type	Deck Mount
Finish Type	Matte Black
Material	Stainless Steel (SUS304 body)
Number of Handles	1
Hole Count	1
Special Feature	Pop Up Drain with Overflow
Style	Handle Pull
Installation Type	Single Hole
Handle Material	Stainless Steel
Item Weight	3.72 pounds (1.69 Kilograms)

Feature	Detail
Product Dimensions	9.86 x 6.3 x 2.32 inches
Spout Design	Waterfall Vertical
Hose Length	60 cm (23.6 inches) with 3/8 inch compression threads
Flow Rate	1.2 GPM

8. WARRANTY & SUPPORT

Your KUZOR AZ3003H-B Tall Matte Black Vessel Sink Faucet is covered by a **180-day limited warranty** from the date of purchase. This warranty covers manufacturing defects and ensures peace of mind regarding the quality and performance of your product.

Should you encounter any issues or require assistance with your faucet, please contact KUZOR customer service. Our dedicated support team is available to provide prompt and effective assistance.

Please retain your proof of purchase for warranty claims.