

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [MGSTN](#) /

› Fingertip Wireless Bluetooth Remote Control User Manual

MGSTN WFWFSSXSX

Fingertip Wireless Bluetooth Remote Control User Manual

Brand: MGSTN | Model: WFWFSSXSX

INTRODUCTION

Thank you for choosing the MGSTN Fingertip Wireless Bluetooth Remote Control. This innovative device is designed to enhance your digital interactions, providing seamless control over various applications on your smartphone or tablet. Its compact, ergonomic ring shape ensures comfortable use for extended periods. With this remote, you can effortlessly navigate videos, capture photos, control media playback, and manage app pages without needing to touch your device. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new remote control.

PRODUCT OVERVIEW



The MGSTN Fingertip Wireless Bluetooth Remote Control, shown here in black, alongside its USB charging cable and a smartphone demonstrating its use. The image also displays other available color variants (pink and white).



The remote control positioned next to a laptop and a smartphone, highlighting its portability and convenience for various setups. Different color options of the remote are also visible.



Detailed dimensions of the remote control, indicating its compact and ergonomic design for comfortable wear on the finger.

SETUP GUIDE

1. Charging the Device

Before first use, ensure your remote control is fully charged.

- Connect the provided USB charging cable to the charging port on the remote control.
- Plug the other end of the cable into a standard USB power adapter (not included) or a computer's USB port.
- The indicator light will show charging status (refer to LED indicator section for details).
- Once fully charged, disconnect the cable.

2. Bluetooth Pairing

To use the remote, you must pair it with your smartphone or tablet via Bluetooth.

1. Ensure the remote control is charged and powered on.
2. On your mobile device, go to **Settings > Bluetooth**.
3. Turn on Bluetooth.

4. Search for available devices. The remote control should appear as "Bluetooth Remote" or similar.
5. Select the remote control from the list to pair.
6. Once paired, the indicator light on the remote will confirm the connection.

Your browser does not support the video tag.

This video demonstrates the Bluetooth connection process and various functionalities of the Fingertip Wireless Bluetooth Remote Control, including scrolling through content, liking posts, and taking photos/videos.

OPERATING INSTRUCTIONS

The remote control features intuitive buttons for various functions.



A close-up view of the remote control worn on a finger, illustrating its ergonomic design and button layout.

Button Functions:

Button	Function	Description
Up Arrow	Scroll Up / Previous	Navigates content upwards or to the previous item.

Button	Function	Description
Down Arrow	Scroll Down / Next	Navigates content downwards or to the next item.
Left Arrow	Scroll Left / Volume Down	Scrolls content left or decreases volume in media apps.
Right Arrow	Scroll Right / Volume Up	Scrolls content right or increases volume in media apps.
Center Button	Confirm / Play/Pause / Like / Take Photo/Video	Performs primary action: confirms selection, plays/pauses media, double-tap to like, single-tap to take photo, long-press to start/stop video recording.

Specific Use Cases:

- **Video Scrolling:** Use the Up/Down arrows to scroll through short videos (e.g., TikTok, Reels).
- **Liking Content:** Double-tap the Center button to "like" a video or post.
- **Media Playback:** Single-tap the Center button to play or pause videos/music.
- **Camera Control:**
 - Open your device's camera app.
 - Single-tap the Center button to take a photo.
 - Long-press the Center button to start video recording, and long-press again to stop.
- **Page Turning:** For e-books or comics, use the Left/Right or Up/Down arrows to turn pages.
- **App Navigation:** Some apps may allow basic navigation (e.g., entering/exiting homepage) using the remote's buttons.



A user comfortably scrolling through videos on a smartphone using the MGSTN remote control, demonstrating hands-free operation.



The remote control being used to remotely trigger a photo on a smartphone, ideal for group photos or selfies.

MAINTENANCE AND CARE

- **Cleaning:** Wipe the remote with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The device is not waterproof. Avoid exposure to water or excessive moisture.
- **Battery Life:** To prolong battery life, fully charge the device before long periods of inactivity.

TROUBLESHOOTING

Remote not connecting/pairing:

- Ensure the remote is charged.
- Make sure Bluetooth is enabled on your device.
- Move the remote closer to your device (within 10 meters).
- Forget the device in your phone's Bluetooth settings and try pairing again.
- Restart both the remote (if possible) and your mobile device.

Buttons not responding:

- Check if the remote is still connected via Bluetooth.
- Ensure the remote is fully charged.
- Some apps may not fully support all remote functions. Test with different applications.
- Try re-pairing the device.

Short battery life:

- Ensure you are using a compatible charging cable and adapter.
- Avoid extreme temperatures during charging and use.
- If the issue persists, contact customer support.

SPECIFICATIONS

Feature	Detail
Model Number	WFWFSSXSX
Connectivity	Bluetooth Wireless
Wireless Range	Up to 10 meters (33 feet)
Power Source	Rechargeable Battery
Material	Premium ABS
Color	Black (as per current model)
Compatible Devices	Phones, Tablets (iOS, Android)

WARRANTY AND SUPPORT

MGSTN products are designed for durability and performance. For specific warranty information, please refer to the warranty card included with your purchase or visit the official MGSTN website.

If you encounter any issues or have questions regarding your Fingertip Wireless Bluetooth Remote Control, please contact our customer support team.

- **Customer Support:** Refer to your product packaging or the MGSTN brand store on Amazon for contact details.
- **Online Resources:** Visit the [MGSTN Store on Amazon](#) for FAQs and additional product information.