

- Manuals.plus /
- › webeauty /
- › webeauty H3B One-Step Hot Air Brush Hair Dryer Instruction Manual

webeauty H3B

webeauty H3B One-Step Hot Air Brush Hair Dryer Instruction Manual

Model: H3B | Brand: webeauty

1. INTRODUCTION AND PRODUCT OVERVIEW

Thank you for choosing the webeauty H3B One-Step Hot Air Brush Hair Dryer. This innovative styling tool is designed to dry, smooth, and volumize your hair simultaneously, providing professional-grade results at home. Featuring a high-speed BLDC motor and negative ion technology, it aims to reduce drying time and minimize heat damage, leaving your hair smooth and shiny.



Figure 1: webeauty H3B One-Step Hot Air Brush Hair Dryer, showcasing its sleek design and oval brush head.

Key Features:

- **PRO High-Speed BLDC Motor:** Reaches 110,000 RPM, generating powerful airflow up to 17 M/s for faster drying.
- **Innovative Oval Brush Design:** Combines drying and styling for efficiency.
- **Gentle on Hair:** Advanced design with negative ions protects against heat damage and reduces frizz.
- **Versatile Styling Options:** Suitable for all hair types to create sleek, voluminous, or curly styles.
- **Multiple Heat/Speed Settings:** Includes 3 heat/speed settings plus a cool shot for styling flexibility.

2. IMPORTANT SAFETY INFORMATION

Please read all instructions before using this appliance. When using electrical appliances, especially when children are present, basic safety precautions should always be followed.

- Keep out of reach of children.

- Do not rinse or submerge in water.
- Keep the power plug and cord away from heated surfaces.
- Do not use a hair dryer while bathing.
- Always unplug the appliance immediately after use.
- Do not use this appliance near bathtubs, showers, basins, or other vessels containing water.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.

3. SETUP

Before first use, ensure the product is free from any packaging materials. Uncoil the power cord completely. Inspect the appliance for any visible damage. Ensure your hands are dry before plugging the appliance into a suitable electrical outlet.



Figure 2: Close-up view of the oval brush head with bristles and airflow vents.

4. OPERATING INSTRUCTIONS

Powering On/Off and Adjusting Settings:

1. Plug the appliance into a standard electrical outlet.
2. To turn on, press and hold the power button for 3 seconds. The indicator lights will illuminate.
3. Press the power button repeatedly to cycle through the 3 heat/speed settings: Low (Blue Light), Medium (Orange Light), High (Red Light).
4. To activate the Cool Shot function, press the snowflake button. This helps to set your style.
5. To turn off, press and hold the power button for 3 seconds.

High Speed No Heat Damage


Intelligent thermostat

200 million negative ions

Coanda Airflow Technology

Maximum wind speed - 23M/S

High Speed Brushless Motor - 110000 RPM



Coanda
Airflow Tech



Intelligent
Thermostatic Control



200 Million
negative ions




Figure 3: Diagram illustrating the 3 heat and 2 speed settings with corresponding indicator lights.

Styling Tips:

- For best results, towel-dry your hair to remove excess water before use.
- Divide your hair into manageable sections.
- Place the brush close to the roots and brush downwards, rotating slightly to create volume or curls.
- Use the Cool Shot to lock in your style for longer-lasting results.

TAKE HAIR SALON HOME



From wet to dry



Smooth your hair



Add shape to
your look

Figure 4: Visual guide for using the webeauty H3B to dry, smooth, and add shape to hair.

Official Product Videos:

Great Blow Dryer Brush, Quick, Easy, Magical!

Your browser does not support the video tag. Please update your browser to view this content.

Video 1: A seller demonstrates the quick and easy styling capabilities of the webeauty H3B Hot Air Brush, highlighting its magical results.

Smooth and Shiny Results with This Webeauty Blow Dryer Brush

Your browser does not support the video tag. Please update your browser to view this content.

Video 2: A seller showcases how the webeauty H3B delivers smooth and shiny hair, emphasizing its frizz-reducing negative ion technology.

Amazing Dryer Brush, so easy to use it well

Your browser does not support the video tag. Please update your browser to view this content.

Video 3: A seller demonstrates the ease of use and effective styling of the webeauty H3B Hot Air Brush.

Blow Dryer Brush Hot Air Brushes

Your browser does not support the video tag. Please update your browser to view this content.

Video 4: A seller provides a general overview of the webeauty H3B Blow Dryer Brush and its hot air styling capabilities.

Amazing hair styler you may like as well

Your browser does not support the video tag. Please update your browser to view this content.

Video 5: A seller highlights the webeauty H3B as an amazing hair styler, demonstrating its effectiveness.

5. MAINTENANCE

Regular cleaning ensures optimal performance and extends the lifespan of your webeauty H3B Hot Air Brush.

Cleaning the Air Filter:

1. Ensure the appliance is unplugged and completely cool before cleaning.
2. Gently twist and pull off the removable filter cap located at the bottom of the handle.
3. Use the provided cleaning brush or a soft, dry cloth to remove any accumulated dust, lint, or hair from the filter screen.
4. Reattach the filter cap by aligning it and twisting until it clicks securely into place.

Do not use harsh chemicals or abrasive cleaners on any part of the appliance. Wipe the exterior with a soft, damp cloth if needed.

6. TROUBLESHOOTING

If you encounter any issues with your webeauty H3B, please refer to the following common solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not properly plugged in; power outlet issue; internal fault.	Ensure plug is fully inserted. Try a different outlet. If issue persists, contact customer support.
Low airflow or reduced performance.	Clogged air filter.	Clean the air filter as described in the Maintenance section.
Hair is still frizzy after use.	Insufficient use of negative ion feature; improper technique.	Ensure you are using the appropriate heat setting and brushing slowly from roots to ends. The negative ion feature is always active when the device is on.

For issues not listed above, please contact webeauty customer support.

7. SPECIFICATIONS

- **Model Number:** H3B
- **Product Dimensions:** 11.02 x 3.15 x 1.97 inches
- **Item Weight:** 1.85 Pounds
- **Manufacturer:** webeauty
- **Material:** Metal
- **Wattage:** 1400 watts
- **Power Source:** Corded Electric
- **Motor Speed:** Up to 110,000 RPM
- **Airflow:** Up to 17 M/s

8. WARRANTY AND SUPPORT

The webeauty H3B One-Step Hot Air Brush Hair Dryer comes with a 1-year warranty to ensure your satisfaction and trust in our products. For any product-related inquiries, technical support, or warranty claims, please contact webeauty customer service through the retailer where the product was purchased or visit the official webeauty store online.

Legal Disclaimer: Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DHXKFLGD>

More documents and user manuals: <https://manuals.plus/>