

[Manuals.plus](#) /

- › [EUREKA ERGONOMIC](#) /
- › EUREKA ERGONOMIC Captain K47B 47-Inch Gaming Desk User Manual

EUREKA ERGONOMIC Captain K47B

EUREKA ERGONOMIC Captain K47B 47-Inch Gaming Desk User Manual

Model: Captain K47B

1. INTRODUCTION

Thank you for choosing the EUREKA ERGONOMIC Captain K47B 47-Inch Gaming Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before assembly and retain them for future reference.



Image 1.1: The EUREKA ERGONOMIC Captain K47B 47-Inch Gaming Desk, showcasing its carbon fiber texture and K-shaped frame in a typical gaming environment.

2. SAFETY INFORMATION

Please observe the following safety guidelines to ensure safe use and prevent damage to the product or injury.

- Always assemble the desk according to the provided instructions.
- Ensure the desk is properly anchored to the floor to prevent tipping, especially when heavy equipment is placed on it.
- Do not exceed the desk's weight limit of 150 lbs (68 kg) to maintain stability and prevent accidents.
- Keep small parts away from children during assembly to avoid choking hazards.
- Use appropriate tools as specified in the assembly guide.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or

damaged, please contact customer support.

- Desk Top Panel
- K-Frame Legs (Left and Right)
- Support Bars
- Cup Holder
- Headphone Hook
- Controller Stand
- Extra-Large Mouse Pad
- Cable Management Tray
- Hardware Pack (screws, bolts, Allen wrench)
- Assembly Instructions

4. SETUP AND ASSEMBLY

Follow these steps to assemble your EUREKA ERGONOMIC Captain K47B Gaming Desk. It is recommended to have two people for assembly.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble K-Frame Legs:** Attach the support bars to the K-shaped leg frames using the provided hardware. Ensure all connections are secure but do not fully tighten screws until the desk top is attached.
3. **Attach Legs to Desk Top:** Carefully place the desk top upside down on your soft surface. Align the assembled K-frame legs with the pre-drilled holes on the underside of the desk top. Secure them using the appropriate screws.
4. **Tighten All Screws:** Once all components are loosely assembled, carefully flip the desk upright. Then, systematically tighten all screws to ensure maximum stability.
5. **Install Accessories:** Attach the cup holder, headphone hook, controller stand, and cable management tray to their designated positions on the desk.
6. **Place Mouse Pad:** Position the extra-large mouse pad on the desk surface.

K Shaped Sturdy Construction




Image 4.1: Illustration of the K-shaped sturdy construction, highlighting the support bars and the 150 lbs weight capacity for enhanced stability.

5. OPERATING AND FEATURES

The EUREKA ERGONOMIC Captain K47B Gaming Desk is designed with several features to enhance your gaming and work experience.

5.1. Carbon Fiber Texture Surface

The desk features a sleek carbon fiber textured surface, providing a smooth and durable area for your gaming equipment and peripherals.

5.2. K-Frame Structure

The robust K-frame design ensures exceptional stability and durability, supporting your gaming setup without wobbling.

5.3. Integrated Accessories

The desk includes convenient accessories to keep your space organized:

- **Cup Holder:** Securely holds your beverage, preventing spills.

- **Headphone Hook:** Provides a dedicated spot to hang your headphones, keeping them within reach and off the desk surface.
- **Controller Stand:** Organizes your gaming controllers neatly.
- **Extra-Large Mouse Pad:** Offers an expansive and consistent surface for precise mouse movements.




Image 5.1: Detailed view of the integrated accessories: headphone hook, cup holder, controller stand, and the included extra-large mouse pad.

5.4. Cable Management System

The desk is equipped with a cable management system, including two cord grommets and a cable management tray, to help organize and conceal your cables for a tidy setup.

Cable Management System

- Two Cords Grommets
- Socket Box



Image 5.2: Illustration of the cable management system, demonstrating the cord grommets and the integrated socket box for organized wiring.

6. MAINTENANCE

Proper maintenance will extend the life and appearance of your gaming desk.

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the carbon fiber texture.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.
- **Avoid Excessive Weight:** Do not place items exceeding the 150 lbs (68 kg) weight limit on the desk.
- **Protect Surface:** Use coasters for drinks and avoid placing hot items directly on the desk surface.

7. TROUBLESHOOTING

If you encounter any issues with your desk, refer to the following common solutions:

- **Desk is Wobbly:** Ensure all assembly screws are fully tightened. Check that the desk is on a level surface. Adjust the leveling feet if present.
- **Missing Parts:** Refer to the "Package Contents" section. If parts are missing, contact EUREKA ERGONOMIC customer support with your purchase details.
- **Scratches on Surface:** While the carbon fiber surface is durable, minor scratches can occur. Avoid dragging sharp objects across the surface.

8. SPECIFICATIONS

Feature	Detail
Brand	EUREKA ERGONOMIC
Model	Captain K47B
Shape	Rectangular
Product Dimensions (D x W x H)	23.6"D x 47"W x 29.68"H (59.9cm D x 119.4cm W x 75.4cm H)
Top Material Type	Engineered Wood with Carbon Fiber Texture
Base Material	Metal (K-Frame)
Color	Black
Weight Capacity	150 lbs (68 kg)
Included Components	Desk, Keyboard Tray, Headphone Hook, Cable Management Tray, Cup Holder, Extra-Large Mouse Pad
Assembly Required	Yes

DIMENSION



Image 8.1: Detailed dimension diagram of the Captain K47B Gaming Desk, including the desk surface and overall height and width.

9. WARRANTY AND SUPPORT

EUREKA ERGONOMIC is committed to designing and manufacturing high-quality gaming desks. We take pride in our innovative designs, rigorous testing, and world-class manufacturing process.

For any questions, support, or warranty claims, please contact our customer support team. Our team is based in the U.S.A and is ready to assist you.

- **Customer Support:** Refer to the contact information provided with your purchase or visit the official EUREKA ERGONOMIC website.
- **Warranty Information:** Specific warranty details are typically included with your product packaging or available on the manufacturer's website. Please retain your proof of purchase for warranty service.

