

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [FUNWHOLE](#) /

> [FUNWHOLE Western General Store Lighting Building-Bricks Set Instruction Manual](#)

FUNWHOLE F9057-MT

FUNWHOLE Western General Store Lighting Building-Bricks Set Instruction Manual

Model: F9057-MT | Brand: FUNWHOLE

PRODUCT OVERVIEW

The FUNWHOLE Western General Store Lighting Building-Bricks Set (Model F9057-MT) is a detailed construction set comprising 1895 pieces, designed to replicate a 19th-century Western general store. This set includes integrated lighting elements to enhance its display. It is intended for individuals aged 16 years and up, offering an authentic and interactive building experience.



Image: The complete FUNWHOLE Western General Store set, showcasing the detailed exterior and the product packaging.

SETUP AND ASSEMBLY

This building-bricks set contains 1895 pieces, including 7 LED lights and 22 printed bricks. Assembly requires careful attention to the provided instruction manual. The set is organized into 10 brick bags to facilitate the building process.

Components Checklist:

- 1895 Building Bricks (organized in 10 numbered bags)
- 7 LED Lighting Elements
- 22 Printed Bricks
- Instruction Manual
- Wireless Connector for lighting

Note: 3 AA batteries are required for the lighting system and are not included in the set. Please ensure you have these batteries ready before beginning assembly.



Image: Overview of the set's components, including the main box, instruction manual, brick bags, and the separate lighting kit box.

Assembly Steps:

1. Unpack all components and verify against the parts list in the instruction manual.
2. Follow the step-by-step instructions provided in the manual, assembling the bricks according to the numbered bags.
3. Integrate the LED lighting elements as indicated in the manual. The design incorporates a wireless connector for easy integration and removal of sections.
4. Install 3 AA batteries into the designated battery compartment for the lighting system.

OPERATING THE LIGHTING SYSTEM AND FEATURES

The Western General Store set features an integrated lighting system that brings the model to life. Once assembled and batteries are installed, the lights can be activated to illuminate the interior and exterior details.



Image: A visual comparison demonstrating the building set with its integrated lights turned off and then turned on, highlighting the illuminated interior and exterior.

Key Features:

- **Integrated Lighting:** The set includes 7 LED lights designed to illuminate various parts of the general store, creating a realistic and atmospheric display.
- **Playable Structure:** The model features a removable wall, a quick-detachable roof, and a secretive hidden room, allowing for interactive play and exploration of the interior.
- **Wireless Connector:** Sections of the building, such as the upper floor, can be easily lifted off due to a wireless connector system, simplifying access to the interior and lighting components.



PLAYABLE STRUCTURE TO EXPLORE

Image: A close-up view illustrating the lift-off mechanism and the wireless connector, which allows for easy removal of building sections.

Interior Details:

The General Store boasts intricate interior details, including a counter, telephone, kerosene stove, workbench, and various displays of goods. These elements contribute to the authentic representation of a 19th-century Western establishment.

EXQUISITE INTERIOR DETAILS



POSTERS



GUEST SUITE



COUNTER



SECRET CHAMBER



INVENTORY STACKING ZONE

Image: A collage showcasing various interior details of the General Store, including a guest suite, the main counter area, a hidden secret chamber, and an inventory stacking zone with barrels and produce.

MAINTENANCE

Proper maintenance will ensure the longevity and appearance of your FUNWHOLE Western General Store set.

- **Cleaning:** To clean the building bricks, gently wipe them with a soft, dry cloth. For stubborn dust, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Dust Removal:** Use a soft brush or compressed air to remove dust from intricate areas and between bricks.
- **Battery Replacement:** If the lighting system dims or stops working, replace the 3 AA batteries. Ensure correct polarity when inserting new batteries. Remove batteries if the set will not be used for an extended period to prevent leakage.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to prevent discoloration or warping of the plastic bricks.

TROUBLESHOOTING

This section addresses common issues you might encounter with your building set.

Problem	Possible Cause	Solution
Missing Pieces	Manufacturing error or packaging oversight.	FUNWHOLE maintains a 97%+ defect-free rate. If pieces are missing, contact customer support for complimentary replacements.
Lights Not Working	Incorrect battery installation, dead batteries, or wiring issue.	<ul style="list-style-type: none">◦ Check battery polarity and ensure batteries are fresh.◦ Verify all lighting wires are securely connected as per the instruction manual.◦ Ensure the wireless connector is properly seated.◦ If issues persist, contact customer support.
Loose Connections/Parts	Bricks not fully pressed together.	Ensure all bricks are firmly pressed into place. The bricks are designed for excellent clutch power.

SPECIFICATIONS

- **Model Number:** F9057-MT
- **Product Dimensions (Assembled):** 10.04 x 12.01 x 9.84 inches
- **Item Weight:** 6.75 pounds
- **Number of Pieces:** 1895 Pcs
- **Number of LED Lights:** 7
- **Number of Printed Bricks:** 22
- **Manufacturer Recommended Age:** 16 years and up
- **Battery Requirement:** 3 x AA batteries (not included)
- **Manufacturer:** FUNWHOLE

WARRANTY AND SUPPORT

FUNWHOLE is committed to providing high-quality products and excellent customer service.

Quality Assurance:

The product is designed with a focus on quality, boasting a 97%+ defect-free rate. In the rare event of quality issues, such as missing parts or non-functional lights, complimentary replacements are provided.

Customer Support:

For any quality concerns or assistance, please refer to the service card included in your product packaging for contact details. FUNWHOLE is committed to responding to inquiries within 24 hours.

Your satisfaction is a priority. You can also connect with FUNWHOLE on social media for product feedback or service inquiries.



© 2025 FUNWHOLE. All rights reserved.