

## Jocoevol FDSER-001LY

# Jocoevol 6-Drawer Fluted Dresser User Manual

Model: FDSER-001LY

[Contents](#) [Overview](#) [Safety Information](#) [Package](#)  
[Assembly](#) [Usage](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Support](#)

## 1. PRODUCT OVERVIEW

The Jocoevol 6-Drawer Fluted Dresser (Model FD SER-001LY) is a versatile storage solution designed for bedrooms, living rooms, hallways, and entryways. It features a boho minimalist aesthetic with distinctive wave-like fluted panels and a natural wood finish. The dresser is equipped with six deep, smooth-gliding drawers, offering ample space for organizing various personal items. Its robust construction utilizes quality MDF wood and sturdy metal slides, ensuring durability and ease of use.



Image 1.1: The Jocoevol 6-Drawer Fluted Dresser, showcasing its natural wood finish and distinctive fluted panels.

## 2. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Anti-Tip Kit:** This dresser includes an anti-tip kit. It is crucial to install this kit to prevent accidental tipping, which can cause serious injury or death. Always secure the dresser to a wall using the provided hardware.
- **Weight Distribution:** Distribute weight evenly across drawers. Avoid placing excessively heavy items in the top drawers, as this can affect stability.
- **Children Safety:** Do not allow children to climb on or play with the dresser. Keep heavy items in lower drawers.
- **Assembly:** Ensure all parts are correctly assembled and fasteners are tightened before use. Periodically check and re-tighten fasteners as needed.
- **Placement:** Place the dresser on a level surface to ensure stability.



Image 2.1: Diagram illustrating the importance and correct installation of the anti-tip kit to prevent furniture tipping.

### 3. PACKAGE CONTENTS

Before beginning assembly, verify that all parts and hardware are present and undamaged. Refer to the detailed installation instructions included in your package for a complete list and identification of components. All parts and accessories are labeled with numbers for easy identification.

#### Typical Components Include:

- Dresser panels (top, bottom, sides, back)
- Drawer fronts, sides, and bottoms
- Metal drawer slides
- Assembly hardware (screws, dowels, cam locks, etc.)
- Anti-tip kit (straps, screws, wall anchors)
- Assembly tools (e.g., Allen wrench, if required)
- Instruction manual

If any parts are missing or damaged, please contact customer support immediately.

## 4. ASSEMBLY INSTRUCTIONS

---

Assembly is designed to be straightforward with detailed instructions provided. It is recommended to have two people for assembly to ensure stability and ease of handling larger components.

### Required Tools (Not Included):

- Phillips head screwdriver
- Hammer (for dowels)
- Drill (for wall anchors, if applicable)

### General Assembly Steps:

1. **Unpack and Identify:** Carefully unpack all components and lay them out on a clean, soft surface (e.g., a blanket or carpet) to prevent scratches. Match each part to the numbered labels in the instruction manual.
2. **Assemble the Frame:** Follow the manual to connect the side panels, bottom panel, and back panel using the specified hardware. Ensure all connections are secure.
3. **Install Drawer Slides:** Attach the metal drawer slides to the dresser frame according to the manual's diagrams. Pay attention to the orientation of the slides.
4. **Assemble Drawers:** Construct each of the six drawers by attaching the sides, front, and back to the drawer bottom. Install the corresponding drawer slides onto the assembled drawers.
5. **Insert Drawers:** Carefully slide the assembled drawers into the dresser frame, ensuring they glide smoothly.
6. **Install Anti-Tip Kit:** This is a critical step. Secure the dresser to a wall stud using the provided anti-tip hardware. Refer to the specific instructions for the anti-tip kit.

For detailed, step-by-step visual guidance, please refer to the comprehensive assembly manual included in your product packaging. Precise holes are pre-drilled to facilitate accurate and fast installation.

## 5. OPERATING AND USAGE

---

The Jocoevol 6-Drawer Fluted Dresser is designed for organizing and storing various household items. Its six spacious drawers provide ample storage capacity.

### Drawer Operation:

- **Opening/Closing:** Gently pull or push the drawers to open and close. The high-quality metal slide rails are designed for smooth and quiet operation.
- **Weight Capacity:** Avoid overloading drawers. Distribute items evenly to prevent strain on the drawer slides and maintain smooth functionality.
- **Top Surface:** The spacious top surface can be used to display decorative items, photos, plants, or lamps. Ensure items are stable and do not exceed the surface's weight capacity.

# 6-DRAWER DRESSER

Meet Your Storage Needs

Ample Storage Space



30+



20+



60+



12+



20+



40+



Image 5.1: An illustration of the dresser's ample storage capacity, demonstrating how various items like clothes, socks, and accessories can be organized within its six deep drawers.



Image 5.2: Visual representation of the dresser's overall dimensions (47.3" L x 31.6" H x 15.7" W) and individual drawer dimensions (22.5" x 12.2" x 8.5").

## 6. CARE AND MAINTENANCE

Proper care will help maintain the appearance and longevity of your Jocoevol dresser.

- **Cleaning:** The thickened dresser top and wood grain finish are scratch-resistant and waterproof. Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Wipe up spills immediately to prevent moisture damage.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the wood finish.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they are tight. Re-tighten if necessary to maintain structural integrity.



Image 6.1: A detailed view of the dresser's wood grain finish, highlighting its texture and quality.

## 7. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Drawers are difficult to open or close.	<ul style="list-style-type: none"><li>Drawer slides are not aligned correctly.</li><li>Hardware is loose.</li><li>Drawer is overloaded.</li><li>Obstruction in the slide mechanism.</li></ul>	<ul style="list-style-type: none"><li>Remove the drawer and re-check the installation of the drawer slides on both the drawer and the dresser frame. Ensure they are level and properly seated.</li><li>Tighten all screws on the drawer slides and drawer components.</li><li>Reduce the weight or redistribute items within the drawer.</li><li>Inspect the slide mechanism for any foreign objects and remove them.</li></ul>
Dresser feels wobbly or unstable.	<ul style="list-style-type: none"><li>Not placed on a level surface.</li><li>Assembly hardware is loose.</li><li>Anti-tip kit not installed or improperly installed.</li></ul>	<ul style="list-style-type: none"><li>Move the dresser to a level surface or use shims to stabilize it.</li><li>Check and tighten all assembly screws and fasteners.</li><li>Ensure the anti-tip kit is securely installed to a wall stud as per instructions.</li></ul>
Missing parts or damaged components.	Manufacturing or shipping error.	Do not proceed with assembly. Contact Jocoevol customer support immediately for replacement parts.

## 8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Jocoevol
Model Name	Drawer Dresser
Model Number	FDSER-001LY

Feature	Detail
Product Dimensions	15.7"D x 47.3"W x 31.6"H
Drawer Size (approx.)	22.5" L x 12.2" W x 8.5" H (internal)
Color	Natural Wood
Material	Quality MDF Wood, Metal Slides
Number of Drawers	6
Item Weight	85 Pounds
Assembly Required	Yes
Special Features	Boho Fluted Panels, Handleless Design, Anti-tip Kit Included, Scratch-resistant, Waterproof Top

## 9. CUSTOMER SUPPORT AND WARRANTY

Jocoevol is committed to providing excellent service. If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact us.

### Contact Information:

- Email:** Please refer to the contact information provided in your purchase documentation or on the Jocoevol official website. We aim to reply within 24 hours.
- Online Support:** Visit the [Jocoevol Store on Amazon](#) for additional product information and support resources.

### Warranty Information:

Specific warranty details are typically included with your product packaging. Please retain your proof of purchase for any warranty claims. The warranty generally covers manufacturing defects under normal use. Damage resulting from improper assembly, misuse, or neglect is not covered.