

[Manuals.plus](#) /

› [Donerton](#) /

› Donerton Wireless Earbuds I66 User Manual

Donerton I66

Donerton Wireless Earbuds User Manual

Model: I66

INTRODUCTION

Thank you for choosing Donerton Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your earbuds to ensure optimal performance and longevity. Please read this manual carefully before using the product and keep it for future reference.

WHAT'S IN THE BOX

- Charging Case x 1
- Wireless Earbud (L & R) x 2
- Replacement Ear Caps x 4 (S, M, L sizes)
- Type-C Charging Cable x 1
- Instruction Book x 1


PRODUCT OVERVIEW

The Donerton Wireless Earbuds (Model I66) are designed for a superior audio experience with advanced Bluetooth 5.4 technology, noise cancellation, and a comfortable ergonomic fit. The charging case features an LED power display for convenience.



Image: Donerton Wireless Earbuds in their charging case, showing the digital LED power display indicating 100% charge. The earbuds themselves are white with a subtle fingerprint icon indicating touch control areas.


Ergonomic Design & IP7 Waterproof



Ergonomic Design



IP7 Waterproof



S/M/L Eartips

Image: A person wearing the Donerton earbuds, highlighting their ergonomic design. Insets show a detailed ear canal fit diagram, water droplets on an earbud indicating IP7 waterproofing, and different ear tip sizes (S, M, L).

SETUP GUIDE

1. Initial Charging

Before first use, ensure the earbuds and charging case are fully charged.

1. Place both earbuds into the charging case.
2. Connect the Type-C charging cable to the charging port on the case and a USB power source.
3. The LED display on the case will show the charging progress. A full charge takes approximately 1.5 hours for the case.
4. The earbuds provide 6-8 hours of playback on a single charge, and the case provides an additional 37 hours, totaling 45 hours.

45Hrs Long Playtime and LED Display



1.5 Hrs
Full Charge



USB-C
Fast Charge



6-8 Hrs
Earbuds



Power display
of the earbud(L/R)



Charging case
power display





Image: Visual representation of the 45-hour total playtime, showing 1.5 hours for full charge, USB-C fast charge, and 6-8 hours for earbuds. The image also highlights the LED power display for both earbuds (L/R) and the charging case.

2. Pairing with Your Device

The earbuds feature one-step pairing for quick and easy connection.


1. Open the charging case. The earbuds will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn Bluetooth on.
3. Search for "I66" in the list of available devices and select it to connect.
4. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.
5. For subsequent uses, simply open the case, and the earbuds will automatically reconnect to the last paired device.

One Step Pairing



Open ///

Auto power on
and connect



Close ///

Auto disconnect
and power off



Smart Touch Control



Answer



Hang Up Call



Volume -



Volume +



Play/Pause



Previous



Next



Siri




Image: Demonstrates the one-step pairing process: open the case to auto-power on and connect, close to auto-disconnect and power off. Also shows the "I66" device name in a phone's Bluetooth settings.

Upgraded Bluetooth 5.4

Bluetooth 5.4 technology allows more stable connections with lower power consumption.



Connection Range

increase **50%**



Stable Connection

increase **75%**



Transfer speed Range

increase **100%**



Image: Illustrates the benefits of Bluetooth 5.4 technology, including increased connection range (50%), stable connection (75%), and transfer speed range (100%).

OPERATING INSTRUCTIONS

Smart Touch Controls

The earbuds feature highly sensitive touch sensors for easy control of various functions. The touch area is located on the outer surface of each earbud.

One Step Pairing



Open ///

Auto power on
and connect



Close ///

Auto disconnect
and power off



Smart Touch Control



Answer



Hang Up Call



Volume -



Volume +



Play/Pause



Previous



Next



Siri




Image: Displays the various smart touch control functions: Answer Call, Hang Up Call, Volume -, Volume +, Play/Pause, Previous Track, Next Track, and Siri/Voice Assistant activation.

Touch Control Functions

Action	Function
Single Tap (L/R)	Play/Pause music, Answer/End call
Double Tap (Left Earbud)	Volume Down
Double Tap (Right Earbud)	Volume Up
Triple Tap (Left Earbud)	Previous Track
Triple Tap (Right Earbud)	Next Track

Action	Function
Long Press (2 seconds)	Reject Call, Activate Voice Assistant (Siri, Google Assistant)

Audio Quality and Calls

The earbuds feature 13mm dynamic drivers for rich audio and CVC algorithm for clear calls.

Hi-Fi Stereo Sound

13mm speaker produce powerful bass and stunning streble.





13mm Drivers



Deep Bass



HiFi Sound

Image: An exploded view of an earbud showing the internal components, emphasizing the 13mm dynamic drivers, deep bass capabilities, and Hi-Fi stereo sound.

Crystal Clear Call

ENC Noise cancellation technology give you better call experience.



Image: A person using the earbuds while on a call, with an overlay illustrating the ENC (Environmental Noise Cancellation) technology and the placement of the main microphone for clear voice pickup, reducing noise by 40dB.

MAINTENANCE AND CARE

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials. Gently remove any earwax or debris from the ear tips and speaker mesh using a small brush or cotton swab.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.
- **Water Resistance:** The earbuds are IP7 waterproof, meaning they are protected against temporary immersion in water. However, they are not designed for swimming or showering. Avoid exposing the charging case to water. Ensure earbuds are dry before placing them back in the charging case to prevent damage.
- **Battery Care:** To prolong battery life, avoid fully discharging the earbuds and charging case frequently. Charge

them regularly, even if not in constant use.

TROUBLESHOOTING

Common Issues and Solutions

Problem	Possible Solution
Earbuds not pairing/connecting	◦ Ensure earbuds are charged. ◦ Turn off and on Bluetooth on your device. ◦ Forget "I66" from your device's Bluetooth list and re-pair. ◦ Place earbuds back in the case, close the lid, wait a few seconds, then open again.
Only one earbud working	◦ Ensure both earbuds are charged. ◦ Place both earbuds back in the charging case, close the lid, then open again to reset their connection. ◦ Try re-pairing the earbuds with your device.
Low volume or poor sound quality	◦ Adjust volume on both your device and using the earbud touch controls. ◦ Clean the earbud speaker mesh and ear tips. ◦ Ensure earbuds are properly seated in your ears for a good seal. ◦ Try different sized ear tips for a better fit.
Charging case not charging	◦ Check the Type-C charging cable and power adapter. ◦ Ensure the charging port on the case is clean and free of debris. ◦ Try a different charging cable or power source.

SPECIFICATIONS

Feature	Detail
Model Name	I66
Brand	Donerton
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.4
Bluetooth Range	15 Meters

Feature	Detail
Audio Driver Type	Dynamic Driver
Audio Driver Size	13 Millimeters
Battery Life (Earbuds)	6-8 hours (single charge)
Total Playtime with Case	Up to 45 hours
Charging Time (Case)	Approx. 1.5 hours (USB-C)
Control Type	Touch Control
Noise Control	Sound Isolation, ENC Noise Cancellation (for calls)
Water Resistance Level	IP7 Waterproof
Earbud Weight (Single)	3.9g
Compatible Devices	iOS 9.0+/Android 5.0+ devices with Bluetooth 5.0+ (Tablets, Laptops, Phones)
Color	Cloud White

CUSTOMER SUPPORT

For any questions, issues, or support needs regarding your Donerton Wireless Earbuds, please contact our customer service team. You can often find support information on the official Donerton website or through the retailer where you purchased the product.

Please have your model number (I66) and purchase details ready when contacting support.

Note: Specific warranty details may vary by region and retailer. Please refer to your purchase documentation for warranty information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question