

[Manuals.plus](#) /

› [HOMCOM](#) /

› HOMCOM Kitchen Island Cart with Rubber Wood Top on Wheels, Model 801-161V80CW - User Manual

HOMCOM 801-161V80CW

HOMCOM Kitchen Island Cart with Rubber Wood Top on Wheels

Model: 801-161V80CW

[Overview](#) [Safety Information](#) [Package Contents](#) [Setup & Assembly](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

1. PRODUCT OVERVIEW

This manual provides essential information for the safe and efficient use of your HOMCOM Kitchen Island Cart. This versatile cart features a durable rubber wood top, ample storage with drawers and adjustable shelves, and convenient mobility with locking wheels. Please read all instructions carefully before assembly and use.



Image 1.1: The HOMCOM Kitchen Island Cart, cream white with a natural wood top, positioned in a kitchen. It features two drawers, two double-door cabinets, and side racks.

2. SAFETY INFORMATION

Please observe the following safety guidelines to prevent injury or damage to the product:

- Exercise caution around sharp edges during assembly and use.
- Always engage the locking brakes on the wheels when the cart is stationary to prevent unintended movement.
- Do not exceed the maximum weight capacity of 45.36 kg (100 lbs) for the countertop.
- Ensure all screws and fasteners are securely tightened during assembly. Periodically check for tightness.
- Keep small parts and packaging materials away from children to avoid choking hazards.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. The package should contain:

- Main cart frame components (engineered wood panels)

- Rubber wood countertop
- Two drawers with hardware
- Four cabinet doors with hinges and handles
- Adjustable shelves (4 total)
- Four swivel casters (wheels), two with locking brakes
- Spice rack attachment
- Towel rack attachment
- Assembly hardware (screws, dowels, cam locks, etc.)
- Assembly Instructions (separate document)

4. SETUP & ASSEMBLY

Assembly of the HOMCOM Kitchen Island Cart is required. A detailed assembly instruction manual is included with your product. Please follow the step-by-step diagrams and instructions provided in that document.

General Assembly Tips:

- Clear a spacious area for assembly.
- Organize all parts and hardware before starting. It is recommended to lay out all pieces in order.
- A Phillips head screwdriver is required.
- Avoid overtightening small screws, especially when attaching drawer sliders, to prevent stripping or damage to the wood.
- Ensure components are correctly oriented as shown in the diagrams to avoid re-assembly.



Image 4.1: An illustration of the cart's storage, including two drawers, two cabinets, a side towel bar, and a spice rack. This image helps visualize the components during assembly.

5. OPERATING INSTRUCTIONS

Your kitchen island cart is designed for versatile use and easy functionality.

5.1 Using the Countertop

The varnished rubber wood countertop provides a durable and water-resistant surface for food preparation, serving, or as a display area. Its natural wood effect complements various kitchen decors.



VARNISHED RUBBERWOOD TABLETOP

 Water-resistant

 Longevity

Image 5.1: A close-up view of the varnished rubberwood tabletop, demonstrating its water-resistant and durable qualities, with various kitchen items placed on it.

5.2 Storage Compartments

The cart features two smooth-gliding drawers for cutlery and smaller items, and two double-door cabinets for larger kitchen essentials. The interior of the cabinets includes adjustable shelves.



Image 5.2: A detailed view of the open drawers, showcasing their capacity for organizing cutlery and other small kitchen tools.

5.3 Adjustable Shelves

The shelves within the cabinets can be adjusted to three different height levels to accommodate items of varying sizes. To adjust, remove the shelf, reposition the shelf pins to the desired height, and reinsert the shelf.

ADJUSTABLE SHELF DESIGN

Suits items in different sizes



Image 5.3: An illustration demonstrating the adjustable shelf design within the cabinets, indicating how shelves can be moved up or down to suit different item sizes.

5.4 Mobility and Brakes

Four smooth-rolling swivel casters allow for easy movement of the cart. Two of these casters are equipped with locking brakes. To secure the cart in place, press down on the brake levers. To move the cart, lift the brake levers.



EASY MOBILITY

Four castor wheels, two with brakes



Image 5.4: A close-up view of the cart's wheels, highlighting the easy mobility provided by the swivel casters and the secure locking mechanism on two of the wheels.

5.5 Spice Rack and Towel Bar

The integrated spice rack and towel bar on the side of the cart provide convenient access to frequently used items, optimizing your kitchen workspace.

6. MAINTENANCE

To ensure the longevity and appearance of your kitchen island cart, follow these simple maintenance guidelines:

- **Cleaning:** Wipe surfaces with a dry, soft cloth. For stubborn marks, a slightly damp cloth followed immediately by a dry cloth can be used. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Countertop Care:** The rubber wood top is varnished for protection. While water-resistant, promptly wipe up spills to prevent water damage.
- **Hardware:** Periodically check all screws, bolts, and fasteners to ensure they remain tight. Tighten as necessary to maintain structural integrity.
- **Wheels:** Keep the casters free of debris to ensure smooth movement.

7. TROUBLESHOOTING

If you encounter issues with your kitchen island cart, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Drawers stick or do not slide smoothly.	Misaligned drawer sliders; overtightened screws on sliders; debris in tracks.	Check that drawer sliders are correctly installed and aligned. Loosen screws slightly if overtightened. Clean tracks of any obstructions.
Cart wobbles or feels unstable.	Loose assembly hardware; uneven floor.	Ensure all assembly screws and bolts are securely tightened. If on an uneven floor, consider placing shims under the wheels or adjusting the item's position.
Wheels do not roll freely or brakes do not engage.	Debris in wheel mechanism; brake mechanism obstructed.	Clean wheels and brake mechanisms of any hair or debris. Ensure brake levers are fully engaged or disengaged.
Missing parts during assembly.	Packaging error; parts misplaced.	Carefully re-check all packaging materials. If parts are still missing, contact customer support with your model number and a description of the missing parts.

8. SPECIFICATIONS

Feature	Detail
Model Number	801-161V80CW
Overall Dimensions (W x D x H)	111 cm x 44.5 cm x 82.5 cm (43.7" W x 17.5" D x 32.5" H)
Countertop Size (L x W x D)	90 cm x 44.5 cm x 3 cm (35.4" L x 17.5" W x 1.2" D)
Material	Engineered Wood (Frame), Rubberwood (Countertop)
Color	Cream White
Maximum Weight Capacity	45.36 kg (100 lbs)
Item Weight	32.66 kg
Number of Shelves	4 (adjustable)
Included Components	Wheels, Spice Rack, Towel Rack, Cabinets, Drawers
Assembly Required	Yes (Instructions included)



Image 8.1: A diagram illustrating the key dimensions of the kitchen island cart, including width, depth, and height, along with the countertop size and weight capacity.

9. WARRANTY & SUPPORT

9.1 Manufacturer's Warranty

This product comes with a **90-Day Warranty Against Manufacturer Defects**. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For any questions, missing parts, or warranty inquiries, please contact the manufacturer:

- **Manufacturer:** Aosom Canada
- **Contact Information:** Markham, Ontario, CA Tel. 1-416-792-6088

Eligible for return or refund within 30 days of receipt, as per seller policy.

