

[Manuals.plus](#) /

› [SoBuy](#) /

› SoBuy BZR33-SCH Tilt-Out Laundry Cabinet User Manual

SoBuy BZR33-SCH

SoBuy BZR33-SCH Tilt-Out Laundry Cabinet User Manual

Model: BZR33-SCH | Brand: SoBuy

INTRODUCTION

Thank you for choosing the SoBuy BZR33-SCH Tilt-Out Bathroom Laundry Cabinet. This unit is designed to provide efficient storage and organization for your laundry room or bathroom, featuring two hidden drawers and double removable baskets. Please read this manual thoroughly before assembly and use to ensure proper installation and safe operation.



Figure 1: SoBuy BZR33-SCH Laundry Cabinet in a bathroom setting, closed.

SAFETY INFORMATION

WARNING: Failure to follow these safety instructions may result in injury or damage to the product.

- Always follow the assembly instructions carefully.
 - Do not exceed the maximum weight capacity of 154 pounds.
 - Be cautious of pinch points during assembly and operation of moving parts.
 - Use appropriate safety gear when lifting or moving the cabinet.
 - Keep the cabinet away from direct heat sources to prevent damage to the engineered wood frame.
 - Ensure the cabinet is placed on a stable, level surface to prevent tipping.
-

PACKAGE CONTENTS

Before beginning assembly, verify that all parts listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Item	Description	Quantity
Cabinet Panels	Various engineered wood panels for the cabinet frame, top, and doors.	1 set
Drawers	Components for two pull-out drawers.	2
Laundry Baskets	Removable fabric baskets for laundry.	2
Hardware Kit	Screws, dowels, cam locks, drawer slides, handles, and other fasteners.	1 kit
Assembly Manual	Step-by-step assembly instructions.	1

SETUP AND ASSEMBLY

The SoBuy BZR33-SCH cabinet requires self-assembly. A detailed instruction manual is included in the package. It is recommended to have two people for assembly to ensure stability and ease of construction. Please follow the provided step-by-step diagrams and instructions carefully.

Key Assembly Tips:

- **Identify all parts:** Lay out all components and hardware, comparing them against the parts list in the included manual.
- **Tools required:** Typically, a Phillips head screwdriver and a hammer are needed.
- **Drawer Rails:** Pay close attention to the orientation and installation of the drawer rails. Incorrect installation can affect drawer functionality. Refer to the specific diagrams for drawer rail placement.
- **Secure all fasteners:** Ensure all screws and cam locks are tightened securely for structural integrity. Do not overtighten.



Figure 2: Cabinet with one tilt-out hamper door open, showing the internal basket.

If you encounter any difficulties during assembly, refer to the troubleshooting section or contact customer support for assistance.

OPERATING INSTRUCTIONS

Using the Tilt-Out Laundry Baskets:

1. To access a laundry basket, gently pull the corresponding front panel outwards. The panel will tilt forward, revealing the removable basket.
2. The fabric baskets are designed to be easily removed for transport to your laundry area. Simply lift the basket out of its compartment.
3. After use, place the basket back into the compartment and push the front panel upwards until it closes securely.



Figure 3: Tilt-out hamper door open with laundry basket in place.

Using the Storage Drawers:

- The two top drawers provide additional storage for smaller items. Pull the drawer handles to open.
- Ensure not to overload the drawers to maintain smooth operation of the slides.



Figure 4: Top drawers open, showing internal storage space.

Weight Capacity: The maximum load capacity for the entire unit is 154 pounds. Distribute weight evenly and do not place excessively heavy items on the top surface or in the drawers/baskets.

MAINTENANCE

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the engineered wood finish.
 - **Spills:** Immediately wipe up any spills to prevent water damage or staining to the engineered wood.
 - **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
 - **Laundry Baskets:** The fabric laundry baskets can be spot cleaned as needed. Refer to the care label on the baskets for specific cleaning instructions.
-

TROUBLESHOOTING

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Loose fasteners; uneven floor.	Ensure all screws and cam locks are fully tightened. Place the cabinet on a level surface or use shims if necessary.
Drawers do not slide smoothly or get stuck.	Incorrect installation of drawer rails; overloaded drawer.	Review the assembly instructions for drawer rail installation, ensuring they are correctly oriented and aligned. Reduce the weight in the drawer.
Tilt-out hamper door does not close properly.	Obstruction; misaligned hinges.	Check for any items blocking the door's path. Verify that the hinges are correctly installed and tightened.
Missing or damaged parts.	Packaging error; shipping damage.	Do not proceed with assembly. Contact SoBuy customer support immediately for replacement parts.

SPECIFICATIONS

Feature	Detail
Brand	SoBuy
Model Number	BZR33-SCH
Color	Black
Material	Engineered Wood
Product Dimensions (D x W x H)	15"D x 30.7"W x 35.4"H (38.1 cm D x 78 cm W x 89.9 cm H)
Item Weight	56.1 pounds (25.45 kg)
Weight Capacity (Maximum)	154 pounds (69.85 kg)
Number of Drawers	2
Number of Compartments	2 (for laundry baskets)
Mounting Type	Floor Mount (Freestanding)
Assembly Required	Yes, self-assembly with included instructions.



Figure 5: Dimensional drawing of the SoBuy BZR33-SCH Laundry Cabinet.

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact SoBuy customer service directly. If you require assistance with assembly, missing parts, or have any questions regarding the product, please reach out to the manufacturer's support team.

Manufacturer: SoBuy

For contact details, please visit the official SoBuy website or refer to your purchase receipt.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question