

[manuals.plus](#) /

› [APPASO](#) /

› [APPASO 2 Handle Kitchen Faucet APS2981 Instruction Manual](#)

APPASO APS2981

APPASO 2 Handle Kitchen Faucet APS2981 Instruction Manual

Model: APS2981 | Brand: APPASO

1. PRODUCT OVERVIEW

The APPASO 2 Handle Kitchen Faucet (Model APS2981) is designed for modern kitchens, offering both functionality and aesthetic appeal. This faucet features a durable brushed nickel finish, dual handles for precise temperature control, and a versatile pull-down sprayer with multiple spray modes. It is suitable for 3-hole or 4-hole sink installations and includes a matching soap dispenser.

Key Features:

- Dual-Handle Design:** Separate metal lever handles for fine-tuning hot and cold water temperature.
- Premium Ceramic Cartridge:** Tested for 500,000 cycles to ensure reliable, leak-free operation.
- Durable Construction:** Made from high-quality SUS 304 stainless steel, resistant to fingerprints, scratches, rust, and corrosion.
- Versatile Pull-Down Sprayer:** Features three spray modes (SINGLE BROOM, STREAM, SPRAY) and an 18-inch retractable hose with 360° swivel for comprehensive sink coverage.
- Integrated Soap Dispenser:** Large capacity dispenser for hand soap, dish soap, or lotion, unifying kitchen style.
- Easy Installation:** Designed for quick DIY installation in approximately 20 minutes.



Easy to
Clean



Ultimate
Flexibility



Rust-Free
Beauty



Safe and Healthy
Material

Image 1: The APPASO 2 Handle Kitchen Faucet in brushed nickel, showcasing its high-arc design and integrated soap dispenser.

2. INSTALLATION GUIDE

Before You Begin:

- Ensure all necessary components are present as listed in the packaging.
- Turn off the main water supply to your kitchen sink.
- Clear the area under the sink for easy access.

- Gather basic tools: adjustable wrench, Phillips head screwdriver, plumber's putty or silicone sealant.

Step-by-Step Installation:

1. **Prepare the Sink:** Ensure your sink has 3 or 4 pre-drilled holes. If replacing an old faucet, remove it and clean the mounting surface.
2. **Install Faucet Body:** Insert the main faucet body into the center hole of the sink. Secure it from underneath with the provided washer and mounting nut.
3. **Install Handles:** Insert the hot and cold water handles into their respective holes. Secure them from underneath with their washers and nuts.
4. **Connect Water Hoses:** Connect the hot and cold water supply lines from the faucet to your home's water supply valves. Ensure a tight, leak-free connection.
5. **Install Pull-Down Hose:** Connect the pull-down sprayer hose to the designated connection point on the main faucet body.
6. **Attach Gravity Ball:** Install the gravity ball onto the pull-down hose under the sink. This ensures the sprayer retracts smoothly.
7. **Install Soap Dispenser:** Insert the soap dispenser pump into its designated hole. Secure it from underneath with the provided nut and attach the soap bottle.
8. **Test for Leaks:** Turn on the main water supply and check all connections for leaks. Operate the faucet and sprayer to ensure proper function.



SOAP DISPENSER

Just 3 Steps



Image 2: Detailed diagram illustrating faucet dimensions, maximum countertop thickness, and mounting hole size for installation.

MULTI-LAYER FILTRATION & REMOVABLE NOZZLE

Blue key is provided for easier removal & cleaning of the nozzle filter.




Image 3: Visual guide for connecting the hot and cold water hoses and installing the gravity ball for the pull-down sprayer.

Your browser does not support the video tag.

Video 1: Official APPASO video demonstrating the installation process for a 4-hole kitchen faucet, including component overview and connection steps.

3. OPERATING YOUR FAUCET

Water Flow and Temperature Control:

The faucet features two distinct handles for precise control over water temperature. The left handle controls hot water, and the right handle controls cold water. Adjust both handles to achieve your desired water temperature and flow rate.





Image 4: Close-up view of the dual handles, clearly marked for hot and cold water, demonstrating independent temperature control.

Spray Modes:

The pull-down sprayer offers three distinct spray modes to suit various tasks:

- **STREAM:** For filling pots and general washing.
- **SPRAY:** For powerful rinsing and cleaning.
- **SINGLE BROOM:** A concentrated, high-pressure stream for stubborn food debris.

Switch between modes using the buttons located on the sprayer head.



DOUBLE BROOM

Clean in a Flash



SPRAY

Powerful Cleaning



STREAM

Gentle & No Splash

Image 5: Visual representation of the three spray modes available on the pull-down sprayer: Stream, Spray, and Single Broom.

Pull-Down Sprayer:

The sprayer head can be pulled down from the main faucet body, extending up to 18 inches, and swivels 360 degrees. This flexibility allows for easy cleaning of all areas of your sink and filling containers outside the sink basin.

SUS304 STAINLESS STEEL

Stable and Long-lasting



7-LAYER
NANO & PVD



≥8UN
High Strength



35%~45%
Corrosion Resistance

Image 6: The pull-down sprayer in extended position, highlighting its reach and flexibility for various kitchen tasks.

4. MAINTENANCE

Cleaning:

The faucet's SUS 304 stainless steel construction with a brushed nickel finish is designed to be anti-fingerprint, rust-resistant, and corrosion-resistant. For daily cleaning, simply wipe the surface with a soft, dry cloth. For tougher spots, use a mild soap and water solution, then rinse and dry thoroughly. Avoid abrasive cleaners or harsh chemicals that can damage the finish.

Nozzle Maintenance:

The sprayer head features multi-layer filtration and a removable nozzle for easy cleaning. If you notice reduced water flow or irregular spray patterns, the nozzle may need cleaning. Use the provided blue key to carefully remove the aerator/nozzle, clean any debris, and then reattach it securely.



20" EXTENSION HOSE

- ◆ Convenience at Your Fingertips
- ◆ Pull-Out Power for Tackling any Kitchen Task

Image 7: Instructions for removing and cleaning the multi-layer filtration nozzle to maintain optimal water flow and spray performance.

5. TROUBLESHOOTING

If you encounter any issues with your APPASO faucet, please refer to the following common troubleshooting tips:

- **Low Water Pressure:** Check if the water supply valves are fully open. Inspect the aerator/nozzle for clogs and clean if necessary (refer to Maintenance section).
- **Leaks:** Ensure all connections are tightened properly. Check the O-rings and washers for damage and replace if needed.
- **Sprayer Not Retracting:** Verify that the gravity ball is correctly installed on the pull-down hose and that there are no obstructions under the sink preventing its movement.
- **Temperature Control Issues:** Ensure both hot and cold water supply lines are connected correctly.

For persistent issues or further assistance, please contact APPASO customer support.

6. SPECIFICATIONS

Feature	Detail
Brand	APPASO
Model Name	APS2981
Color	Brushed Nickel
Material	SUS 304 Stainless Steel, PEX Hose, ABS Plastic Sprayhead
Number of Handles	2
Mounting Type	3 to 4 Hole Sink
Special Features	360 Swivel, Dual Function Sprayer, Pull Down Sprayer
Maximum Flow Rate	1.8 Gallons Per Minute
Product Dimensions	16"D x 3"W x 12"H
Item Weight	4.4 pounds (2 Kilograms)

7. WARRANTY AND CUSTOMER SUPPORT

The APPASO 2 Handle Kitchen Faucet comes with a **limited warranty**, ensuring peace of mind regarding its quality and performance. We are committed to providing a worry-free experience for our customers.

If you find anything missing or faulty, or require any assistance with installation, operation, or maintenance, please do not hesitate to contact us. Our dedicated customer support team is ready to help.

Contact Information: Please reach out to APPASO Direct via Amazon's messaging service for prompt assistance.