

[Manuals.plus](#) /

› [Brabantia](#) /

› Brabantia Bo Touch Top Kitchen Trash Can Instruction Manual (Confident Gray, 9.5 Gal)

Brabantia Bo Touch Top Trash Can 9.5 Gal

Brabantia Bo Touch Top Kitchen Trash Can Instruction Manual

Model: 9.5 Gallon, Confident Gray

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your Brabantia Bo Touch Top Kitchen Trash Can. Designed for both functionality and aesthetics, this 9.5-gallon capacity trash can features a soft-touch opening system and adjustable non-skid legs, making it a practical addition to any home.



Image: The Brabantia Bo Touch Top Kitchen Trash Can in Confident Gray, showcasing its sleek design and raised legs.

SETUP

Follow these steps to set up your new Brabantia Bo Touch Top Kitchen Trash Can:

1. **Unboxing:** Carefully remove all packaging materials from the trash can and its components. Ensure all parts are present: the outer bin, inner bucket, and any included sample trash bags.
2. **Placement:** Position the trash can in your desired location. Its flat back design allows it to fit closely against a wall or in a corner.
3. **Adjusting Legs:** The trash can comes with adjustable non-skid legs. Ensure they are securely attached and adjust them if necessary to achieve a stable, level position. This also provides a comfortable working height and allows for easy cleaning underneath.
4. **Insert Inner Bucket:** Place the removable plastic inner bucket inside the outer bin.
5. **Insert Trash Bag:** Take one of the included Brabantia PerfectFit (Code R) trash bags or a compatible 9.5-gallon trash

bag. Line the inner bucket with the trash bag, ensuring the edges are neatly tucked over the rim of the inner bucket.



Image: A person demonstrating how to insert a trash bag into the removable inner bucket.

OPERATING INSTRUCTIONS

Using your Brabantia Bo Touch Top Kitchen Trash Can is simple and convenient:

- **Opening the Lid:** The Bo Touch Top features a soft-touch opening system. Gently press the lid to open it. The lid will stay open until you manually close it, providing easy access for disposing of waste.
- **Disposing of Waste:** Place your waste directly into the trash bag within the inner bucket. The wide opening minimizes spills.
- **Closing the Lid:** Gently press the lid down to close it. The soft-close mechanism ensures a quiet and smooth closure.
- **Removing Full Trash Bag:** When the trash bag is full, lift the inner bucket out of the outer bin. Secure the trash bag and dispose of it properly.
- **Replacing Trash Bag:** Insert a new trash bag into the inner bucket and place the inner bucket back into the outer bin.



Image: A person demonstrating how to dispose of an item into the trash can with the lid open.

MAINTENANCE

Regular cleaning will keep your Brabantia Bo Touch Top Trash Can in optimal condition:

- **Cleaning the Outer Bin:** Wipe the exterior with a soft, damp cloth and a mild detergent. Avoid abrasive cleaners or scouring pads, as these can damage the finish. Dry thoroughly with a soft cloth.
- **Cleaning the Inner Bucket:** The plastic inner bucket can be easily removed for cleaning. Wash it with warm, soapy water. For stubborn stains or odors, a mild disinfectant can be used. Rinse thoroughly and allow it to dry completely before placing it back into the outer bin.
- **Lid Cleaning:** The entire lid can be removed for more thorough cleaning. Wipe it with a damp cloth and mild detergent, then dry.
- **Legs:** Periodically check the adjustable legs to ensure they are clean and free from debris, maintaining stability and preventing scratches on your floor.



Image: A hand demonstrating the soft-touch opening mechanism of the trash can.

TROUBLESHOOTING

If you encounter any issues with your trash can, refer to the following common solutions:

- **Lid not opening/closing smoothly:**

- Check for any obstructions around the lid mechanism.
- Ensure the lid is properly seated on the bin.
- Clean the lid and surrounding area to remove any dirt or grime that might impede movement.

- **Trash bag tearing:**

- Ensure you are using the correct size (Code R) Brabantia PerfectFit trash bags or other high-quality 9.5-gallon bags.
- Avoid overfilling the inner bucket, which can put excessive strain on the bag.
- Check the rim of the inner bucket for any sharp edges that might be snagging the bag.

- **Unpleasant odors:**

- Thoroughly clean the inner bucket and outer bin as described in the Maintenance section.
- Ensure the lid closes completely to contain odors.
- Consider using odor-absorbing products designed for trash cans.

- **Bin wobbles:**

- Check that the adjustable legs are firmly attached and evenly adjusted on a flat surface.
- Ensure the floor surface is level.

SPECIFICATIONS

Feature	Detail
Brand	Brabantia
Model	Bo Touch Top Kitchen Trash Can
Capacity	9.5 Gallons (36 Liters)
Color	Confident Gray
Opening Mechanism	Press-Top (Soft-Touch)
Material	Plastic, Steel
Dimensions (L x W x H)	21.3" x 12.3" x 26.8"
Item Weight	12.21 Pounds
Special Features	C2C Certified (Bronze), Non-Scratch/Slip base, Perfect working height, Removable Bucket, Soft open/close
Included Components	1x Bo Trash Can, 1x Inner Bucket, Sample Trash Bags



Image: Diagram illustrating the inner bucket capacity (9.5 US Gallons / 36 Liters) and recommended bag code 'R'.

WARRANTY AND SUPPORT

Warranty Information

Your Brabantia Bo Touch Top Kitchen Trash Can is backed by a **10-year guarantee**, reflecting Brabantia's commitment to quality and durability. This guarantee covers manufacturing defects and ensures long-lasting performance of your product. For specific details regarding the terms and conditions of your warranty, please refer to the documentation included with your purchase or visit the official Brabantia website.

Customer Support

Should you have any questions, require assistance with setup, operation, or maintenance, or need to address a warranty claim, please contact Brabantia customer support. Contact information can typically be found on the official Brabantia website or on the product packaging.

PRODUCT VIDEO

Watch the official product video for an overview of Brabantia trash cans and their features.

Your browser does not support the video tag.

Video: An official Brabantia video showcasing various trash can models, highlighting their design, functionality, and ease of use in different home settings.

