

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [PGYTECH](#) /

> [PGYTECH 2-in-1 Roller Camera Backpack Instruction Manual \(Model P-CB-417\)](#)

## PGYTECH P-CB-417

# PGYTECH 2-in-1 Roller Camera Backpack Instruction Manual (Model P-CB-417)

This manual provides detailed instructions for the setup, operation, and maintenance of your PGYTECH 2-in-1 Roller Camera Backpack.

## PRODUCT OVERVIEW

The PGYTECH 2-in-1 Roller Camera Backpack offers versatile storage and transport solutions for photographers. It features dual modes (spinner suitcase and backpack), customizable storage with a DIY divider system, high-performance accessories including quick-release wheels, and organized compartments. Constructed from splash-proof PU fabric with YKK zippers, it ensures durability and security for your gear.



An overview image of the PGYTECH Roller Camera Backpack, highlighting its dual functionality as a roller and a backpack.

## SETUP AND CONFIGURATION

### Dual Mode Flexibility

The backpack can be used in two primary modes: spinner suitcase mode for urban and flat surfaces, and backpack mode for outdoor or complex terrains.

# Dual Modes, Seamless Switch



Illustration showing the backpack in both trolley case mode with spinner wheels and backpack mode with hidden straps.

## Customizable Storage System

The main compartment features a professional DIY divider system. These dividers are fully adjustable and secured with Velcro, allowing you to customize the internal layout to fit various camera bodies, lenses, and accessories.

# Customizable Storage for All Your Gear

Professional DIY Divider System:  
Storage & Secure Protection



Camera+Drone Mode



Multi Camera Mode



Travel Mode



Image showing the main compartment with adjustable dividers configured for different gear setups (Camera+Drone Mode, Multi Camera Mode, Travel Mode).

## Quick-Release Wheel System

The high-performance silent double wheels can be quickly disassembled. This feature allows for up to 8% more space, helping to meet airline carry-on standards.

# Quick-Release Wheel System for Enhanced Packing

Easily removable wheels for up to 8% more space while meeting cabin standards




Image demonstrating the quick-release mechanism for the wheels and a diagram comparing the backpack's dimensions with and without wheels to a general carry-on suitcase.

## OPERATING INSTRUCTIONS

### Switching Between Modes

To switch to backpack mode, deploy the hidden back panel straps. For spinner suitcase mode, ensure the wheels are attached and the telescopic handle is extended.

Official product video demonstrating the seamless transition between roller and backpack modes, showcasing the ease of deploying and stowing straps and handle.

### Accessing Main Compartment


The main compartment is accessed from the back panel when the backpack is laid flat. This design enhances security by preventing unauthorized access while wearing.

A seller video demonstrating the main compartment access from the back, highlighting the internal organization and modular dividers.

### Quick Side Access

For quick access to your camera or frequently used lenses, utilize the side zipper pockets. This allows you to retrieve gear without fully opening the main compartment.

# 10L Expandable Space for Your Essentials



# Digital Organizer Bag for Quick Security Check

Designed for batteries and accessories, this bag can be side-pocketed or used as a tote. Quick detach for easy access and hassle-free security checks




Image showing a user accessing a camera from the side pocket of the backpack.

## Using Expandable Space

The 10L expandable front compartment is ideal for larger items like gimbals, clothing, or additional accessories.

# Double Row Spinner Wheels for 360° Smooth Maneuvering

Stable Standing and Effortless Pulling





Image illustrating the expandable front compartment, showing how it can accommodate extra gear.

## Digital Organizer Bag

The included Digital Organizer Bag is designed for batteries and digital accessories, making airport security checks more efficient. It can be side-pocketed or used as a separate tote.



## Digital Organizer Bag for Quick Security Check

Designed for batteries and accessories, this bag can be side-pocketed or used as a tote. Quick detach for easy access and hassle-free security checks

Image showing the Digital Organizer Bag filled with batteries and cables, being presented for a security check.

## Telescopic Handle Operation

The three-stage aluminum telescopic handle ensures balanced and easy handling. The upgraded design features a backward tilt to prevent the suitcase from tipping forward when fully loaded.

# Change in the inclination of the Telescoping handle



The telescoping handle tilted backward  
Preventing the Suitcase from tipping forward when fully loaded

Diagram illustrating the improved backward tilt of the telescopic handle to enhance stability.

## CARE AND MAINTENANCE

---


The backpack is constructed from high-performance, splash-proof PU fabric. For general cleaning, wipe with a damp cloth. Avoid harsh chemicals.

### Zipper Care

The backpack features durable YKK zippers. Keep zippers clean and free of debris to ensure smooth operation.

### Rain Cover

A rain cover is included for added protection in heavy downpours. Store it in the designated top pocket when not in use.



## Quality Craftsmanship at Every Turn

Close-up image highlighting the splash-proof fabric and YKK zippers, emphasizing the quality craftsmanship.

### TROUBLESHOOTING TIPS

#### Backpack Tipping Forward

If the backpack tends to tip forward when used as a roller, ensure the telescopic handle is fully extended and locked. The upgraded design with backward tilt helps prevent this.

#### Airline Carry-on Compliance

While designed to meet airline standards, specific airline requirements may vary. Utilize the quick-release wheel system to gain up to 8% more space if needed. Always check with your airline for their latest carry-on dimensions.

#### Security Concerns

The main compartment zippers are lockable (lock not included). For added security, utilize the hidden AirTag pocket.

### PRODUCT SPECIFICATIONS

#### PGYTECH 2-in-1 Roller Camera Backpack Specifications

Feature	Detail
Product Dimensions	11.02 x 5.71 x 17.72 inches
Item Weight	7.9 pounds
Item model number	P-CB-417
Main material	15% polyurethane, 85% polyester fiber
External dimensions (Without wheels)	21.26 x 14.17 x 9.84 inches (540 x 360 x 250 mm)
External dimensions (With wheels)	23.23 x 14.17 x 9.84 inches (590 x 360 x 250 mm)
Internal dimensions	20.47 x 13.39 x 5.91 inches (520 x 340 x 150 mm)
Weight (Net Weight)	7.9lb / 3.6kg

Feature	Detail
Capacity	Can hold up to two DSLRs or mirrorless cameras, nine lenses, and 200-600mm lens or DJI drone

## WARRANTY AND SUPPORT

This product comes with a limited lifetime warranty. Normal wear and tear of the wheels are not included in the scope of support. For further support, please visit the PGYTECH Direct store on Amazon.

**Customizable Storage  
for All Your Gear**

Professional DIY Divider System:  
Storage & Secure Protection



**Camera+  
Drone Mode**



**Multi  
Camera Mode**



**Travel Mode**



Image showing the "Limited Lifetime Warranty" logo.