

Hunter CCC5C25C91

Hunter 52-inch White Indoor Ceiling Fan with Light Kit and Remote - Instruction Manual

Model: CCC5C25C91

1. INTRODUCTION

Thank you for choosing the Hunter 52-inch White Indoor Ceiling Fan. This fan is designed to provide optimal air circulation and lighting for medium to large rooms, including bedrooms, dens, dining rooms, kitchens, and offices. Featuring energy-efficient, dimmable LED bulbs and reversible blades, this fan offers both functionality and modern design. The included handheld remote control ensures convenient operation of fan speeds and lighting.



Image: The Hunter 52-inch White Indoor Ceiling Fan, showcasing its sleek design with five blades and an integrated light kit. Labels point to the reversible motor, reversible blades, and long-lasting LED bulbs.

2. SAFETY INFORMATION

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these instructions:

- Read all instructions carefully before beginning installation.
- Ensure the installation site is structurally sound and can support the fan's weight.
- Turn off power at the circuit breaker before wiring.
- Consult a qualified electrician if you are unsure about wiring procedures.
- Do not operate the fan with damaged blades.
- Keep hands and objects clear of rotating blades.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Assembly
- 5 Fan Blades (Light Oak/Matte White reversible)
- Integrated LED Light Kit
- Handheld Remote Control (with batteries)
- 4-inch Downrod for Standard Profile Mounting
- Mounting Hardware and Wiring Connectors




Image: A detailed view of the Hunter 52-inch White Indoor Ceiling Fan, highlighting its key features: reversible motor, reversible blades, and long-lasting LED bulbs. This image helps identify the main components.

4. SETUP AND INSTALLATION


The Hunter 52-inch Ceiling Fan is designed for easy installation with reduced hardware and pre-installed pieces. Follow the detailed instructions provided in the included manual for a smooth setup. Ensure power is off at the circuit breaker before starting.

4.1 Mounting the Fan


This fan supports standard profile mounting with the included 4-inch downrod. For rooms with low ceilings, the low-profile design ensures ample clearance. If you have existing wiring, installation will be straightforward.

4.2 Attaching the Blades

The fan features 5 reversible blades with Light Oak on one side and Matte White on the other. Choose the finish that best suits your room's aesthetic. Securely attach the blades to the motor housing as per the manual's diagrams.




REVERSIBLE BLADES



BLADE FINISH 1

LIGHT OAK



BLADE FINISH 2

MATTE WHITE

Which finish will you choose? This two sided blade is perfect when trying to match it with your room style.

Image: Close-up of the reversible fan blades, showing both the Light Oak and Matte White finishes. This illustrates the customization option for matching room decor.

4.3 Wiring the Light Kit

Connect the integrated LED light kit according to the wiring instructions. The LED bulbs are energy-efficient and dimmable, providing versatile lighting options.

Your browser does not support the video tag.

Video: A seller-provided review of the Hunter 52-inch fan, demonstrating its features and ease of installation. This video offers a

5. OPERATING INSTRUCTIONS

Your Hunter ceiling fan comes with a convenient handheld remote control for easy operation.

5.1 Fan Speed Control

The fan features a three-speed WhisperWind motor for powerful yet quiet air movement. Use the remote to adjust the fan speed to your desired level.

5.2 Light Control and Dimming

The integrated LED light kit can be turned on/off and dimmed using the remote. Hold down the light button to adjust brightness and create the perfect ambiance.

5.3 Reversible Motor (Summer/Winter Mode)

The fan's reversible motor allows for year-round comfort. In summer, set the blades to spin counter-clockwise to create a cooling downdraft. In winter, reverse the motor to spin clockwise on low speed, creating an updraft that circulates warm air trapped near the ceiling.

Hunter

**REVERSIBLE
MULTI-SPEED
MOTOR**

SUMMER MODE

Set blades to spin counter-clockwise to create a downdraft

WINTER MODE

Set blades to spin clockwise on low speed to create an updraft

Image: Diagram illustrating the reversible multi-speed motor for Summer Mode (counter-clockwise downdraft) and Winter Mode (clockwise updraft), enhancing year-round comfort.

Hunter

**REMOTE
INCLUDED**



Light dimming



Change speed



Battery included



Change direction



Image: The handheld remote control, detailing buttons for light dimming, changing fan speed, and changing fan direction. It also indicates that batteries are included.

Your browser does not support the video tag.

Video: A seller-provided review highlighting the Hunter Dempsey Low Profile Fan, including its quiet operation and remote control features. This video demonstrates the fan's performance and user convenience.

6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your ceiling fan.

- **Cleaning:** Use a soft, damp cloth to clean the fan blades and motor housing. Do not use abrasive cleaners or solvents.
- **Blade Inspection:** Periodically check that all blade screws are tight. Loose screws can cause wobbling and noise.
- **Light Kit:** The LED bulbs are long-lasting and generally do not require replacement. If issues arise, consult the troubleshooting section.

7. TROUBLESHOOTING

If you experience issues with your Hunter ceiling fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wiring; remote control issue.	Check circuit breaker; ensure all wiring connections are secure; replace remote batteries.
Fan wobbles	Loose blade screws; unbalanced blades; improper mounting.	Tighten all blade screws; use balancing kit (not included) if needed; re-check mounting.
Light does not work	Loose wiring; remote control issue; LED driver failure.	Check wiring connections; replace remote batteries; contact support if LED driver is suspected.
Fan is noisy	Loose screws; motor issue; blades hitting an obstruction.	Tighten all screws; ensure no obstructions; contact support if motor noise persists.

8. SPECIFICATIONS


- **Brand:** Hunter
- **Model Name:** CCC5C25C91
- **Product Dimensions:** 52"D x 52"W x 14.75"H
- **Color:** Matte White
- **Number of Blades:** 5 (Reversible: Light Oak/Matte White)
- **Motor Type:** AC WhisperWind Motor (3-speed, Reversible)
- **Light Kit:** Integrated, Dimmable LED
- **Control Method:** Handheld Remote
- **Mounting Type:** Downrod Mount (4-inch downrod included)
- **Air Flow Capacity:** 2901 Cubic Feet Per Minute
- **Wattage:** 9 watts
- **Voltage:** 120 Volts
- **Item Weight:** 19.6 Pounds
- **Indoor/Outdoor Usage:** Indoor
- **Specification Met:** ETL

Hunter

52
INCHES

LARGE ROOM

Fan Design May Vary



Standard:

4in downrod included

A: 10.59

B: 14.75

Angled:

36in downrod not included

A: 42.59

B: 46.75

Fan Dimensions

Image: A diagram illustrating the dimensions of the Hunter 52-inch ceiling fan for both standard (4-inch downrod) and angled mounting options. This helps users determine suitability for their space.

9. WARRANTY & SUPPORT

For warranty information and customer support, please refer to the documentation included with your product or visit the official Hunter Fan website. Additional protection plans may be available for purchase, offering extended coverage for your product.

For immediate assistance, you may also contact the seller directly through your purchase platform.