

[manuals.plus](#) /

› [SoBuy](#) /

› [SoBuy BZR175-N Wall-Mounted Bathroom Cabinet Instruction Manual](#)

SoBuy BZR175-N

SoBuy BZR175-N Wall-Mounted Bathroom Cabinet Instruction Manual

Model: BZR175-N | Brand: SoBuy

1. INTRODUCTION

This manual provides essential instructions for the assembly, installation, use, and maintenance of your SoBuy BZR175-N wall-mounted bathroom cabinet. Please read this manual thoroughly before beginning assembly or use to ensure safe and correct operation.



Image 1.1: The SoBuy BZR175-N wall-mounted cabinet integrated into a bathroom environment.

2. SAFETY WARNINGS

WARNING: To prevent tipping, ensure the cabinet is correctly mounted and securely fixed to the wall. Carefully read all assembly instructions before starting installation.

- Always follow the assembly instructions provided with the product.
- Do not overload the shelves. The maximum load capacity is 24 kg.
- Ensure all mounting hardware is securely fastened.
- Keep small parts away from children during assembly.
- If any parts are missing or damaged, do not proceed with assembly. Contact customer support.

3. PRODUCT SPECIFICATIONS

Table 3.1: SoBuy BZR175-N Cabinet Specifications

Feature	Detail
Brand	SoBuy

Feature	Detail
Model Number	BZR175-N
Color	Wood
Material	PB and MDF
Dimensions (L x W x H)	35 cm x 30 cm x 120 cm
Item Weight	20.35 kg
Maximum Load Capacity	24 kg
Assembly Required	Yes



4. SETUP AND ASSEMBLY

The SoBuy BZR175-N cabinet requires self-assembly. A detailed, illustrated assembly manual with numbered parts is included in the product packaging. Please follow these instructions carefully.

- 1. Unpack Components:** Carefully remove all parts from the packaging and verify against the parts list in the included manual.
- 2. Identify Hardware:** Separate and identify all screws, dowels, and other hardware.
- 3. Assemble Frame:** Follow the step-by-step diagrams to assemble the main frame of the cabinet.
- 4. Install Shelves:** Insert the adjustable shelves into your desired positions. Each shelf offers three height options.
- 5. Attach Doors:** Mount the doors using the provided hinges, ensuring smooth operation. The hinges are designed for soft closing.
- 6. Wall Mounting:** This is a wall-mounted unit. Use appropriate wall anchors and screws for your wall type to securely fix the cabinet. Refer to the specific wall mounting instructions in the manual.

Note: Tools required for assembly are typically not included. Please prepare a screwdriver and any necessary drilling equipment for wall mounting.



Image 4.1: Detail of the soft-close hinges for the cabinet doors.

5. OPERATING AND USAGE

The SoBuy BZR175-N cabinet is designed for organized storage in your bathroom. Its features include:

- **Adjustable Shelves:** The internal shelves can be adjusted to three different heights to accommodate various item sizes, from tall bottles to folded towels.
- **Two Doors:** The cabinet features two doors that open to reveal the storage compartments.
- **Soft-Close Hinges:** The doors are equipped with soft-close hinges for quiet and gentle closing, preventing slamming.

This cabinet can be paired with compatible SoBuy washbasin units (e.g., BZR169-N or BZR169-SET) for a cohesive bathroom design.



Image 5.1: Interior view of the cabinet with doors open, showcasing storage capacity.



Image 5.2: Example of items stored on an adjustable shelf.

6. MAINTENANCE

To ensure the longevity and appearance of your SoBuy BZR175-N cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Promptly wipe up any spills to prevent water damage or staining.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Environmental Conditions:** Avoid exposing the cabinet to excessive moisture or direct sunlight for prolonged periods, as this can affect the material.

7. TROUBLESHOOTING

If you encounter any issues with your SoBuy BZR175-N cabinet, consider the following:

- **Wobbly Cabinet:** Ensure all wall mounting hardware is securely fastened and that the cabinet is

level. Check all internal assembly screws.

- **Doors Not Closing Properly:** Inspect hinges for proper alignment. Adjust if necessary according to the assembly manual. Ensure no items inside the cabinet are obstructing the doors.
- **Damaged Parts:** If any part is damaged during assembly or use, cease use and contact SoBuy customer support for assistance.

8. WARRANTY AND SUPPORT

For warranty information or customer support regarding your SoBuy BZR175-N cabinet, please refer to the documentation included with your purchase or visit the official SoBuy website. Keep your proof of purchase for any warranty claims.

You can visit the [SoBuy Brand Store](#) for more information and contact options.