

Manuals.plus /

- › HP /
- › HP Omen 16 2024 Gaming Laptop User Manual

HP 16-AE0073CL-CTO

HP Omen 16 2024 Gaming Laptop User Manual

Model: 16-AE0073CL-CTO

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation of your HP Omen 16 2024 Gaming Laptop. It covers setup, features, usage guidelines, maintenance, and troubleshooting. Please read this manual thoroughly before using your device.



Figure 1.1: Front view of the HP Omen 16 2024 Gaming Laptop, showcasing its display and keyboard.

2. SETUP

2.1 Unpacking

Carefully remove all components from the packaging. Ensure the following items are present:

- HP Omen 16 Gaming Laptop
- 230W AC Adapter
- ONT 32GB USB Drive
- Documentation (this manual, warranty information)

2.2 Initial Power-On

1. Connect the 230W AC Adapter to the laptop's power input port and then to a power outlet.
2. Open the laptop lid.
3. Press the power button, typically located on the keyboard deck.
4. Follow the on-screen instructions to complete the Windows 11 Home setup process. This includes setting up your user account, network connection, and initial preferences.

3. OPERATING INSTRUCTIONS

3.1 Keyboard and Touchpad

The laptop features a Fullsize Single-Zone RGB Backlit Keyboard with a Numpad for enhanced productivity and gaming. The touchpad supports multi-touch gestures for navigation.

3.2 Display Settings

The 16.1" FHD (1920 x 1080) IPS Anti-Glare display offers a 144Hz refresh rate for smooth visuals. You can adjust display settings, including brightness and refresh rate, through Windows display settings.

3.3 Audio

Audio is provided by HyperX with dual speakers, delivering high-quality sound for gaming and multimedia. Adjust volume using the dedicated function keys or Windows sound settings.

4. KEY FEATURES

- **Processor:** 14th Generation Intel i7-14650HX 16-Core (Up to 5.2GHz with Intel Turbo Boost Technology, 30 MB Intel Smart cache, 16 cores, 24 threads).
- **Graphics:** NVIDIA GeForce RTX 4060 8GB GDDR6 dedicated graphics for high-performance gaming and content creation.
- **Memory:** Upgraded to 32GB DDR5 5600 MHz SDRAM for efficient multitasking.
- **Storage:** Upgraded to 1TB NVMe M.2 SSD for fast boot times and application loading.
- **Display:** 16.1" FHD (1920 x 1080) IPS Anti-Glare 300 nits, micro-edge, 144Hz Thin Bezel LCD.
- **Connectivity:** Intel Wi-Fi 6E AX211 (2x2) and Bluetooth 5.3, along with 10/100/1000Mbps LAN for robust network connections.
- **Camera:** 1080p FHD Camera with Privacy Shutter for secure video conferencing.
- **Operating System:** Pre-installed with Windows 11 Home.



Figure 4.1: Angled view of the HP Omen 16 2024 Gaming Laptop, highlighting its sleek design.

5. PORTS AND CONNECTORS

The HP Omen 16 laptop is equipped with various ports for connecting peripherals and external displays:

- **1x USB 3.2 Gen 1 Type-C:** Supports Power Delivery, DisplayPort, and Power-off Charging.
- **1x USB 3.2 Gen 1 Type-A:** Supports Power-off Charging and 5Gbps data transfer.
- **2x USB 3.2 Gen 1 Type-A:** Supports 5Gbps data transfer.
- **1x HDMI v2.1:** For connecting to external displays or TVs.
- **1x Headphone/Microphone Combo Jack:** For audio input and output.
- **1x Coaxial plug Power Jack:** For connecting the AC adapter.
- **1x RJ-45 LAN:** For wired Ethernet connection.



Figure 5.1: Side view of the HP Omen 16 2024 Gaming Laptop, illustrating its available ports.

6. MAINTENANCE

6.1 Cleaning

To clean your laptop, use a soft, lint-free cloth. For the screen, use a specialized screen cleaner. Avoid harsh chemicals or abrasive materials. Ensure the laptop is powered off and unplugged before cleaning.

6.2 Software Updates

Regularly update your Windows operating system, drivers (especially graphics drivers), and HP software to ensure optimal performance and security. You can check for updates through Windows Update and the HP Support Assistant application.

6.3 Battery Care

The laptop is equipped with a 4-cell 70Wh battery. To prolong battery life, avoid extreme temperatures, and if storing the laptop for extended periods, ensure the battery is charged to around 50%.

7. TROUBLESHOOTING

7.1 Common Issues and Solutions

- **Laptop does not power on:** Ensure the AC adapter is securely connected to both the laptop and a working power outlet. Try a different outlet.
- **No display:** Check if the laptop is powered on. If connected to an external monitor, ensure the correct input is selected on the monitor. Try pressing **Fn + F4** (or the appropriate function key for display output) to cycle through display modes.
- **Wi-Fi connectivity issues:** Verify that Wi-Fi is enabled in Windows settings. Restart your router and the laptop. Ensure drivers are up to date.
- **Slow performance:** Close unnecessary applications. Check for background processes consuming high resources. Ensure sufficient free storage space. Run a virus scan.
- **Keyboard backlight not working:** Check if the backlight is enabled via function keys (e.g., **Fn + F9** or similar, refer to keyboard icons) or Omen Gaming Hub software.

8. SPECIFICATIONS

Feature	Specification
Display Size	16.1 Inches
Screen Resolution	1920 x 1080 pixels (FHD)
Processor	14th Generation Intel i7-14650HX (2.9 GHz, up to 5.2 GHz)
RAM	32 GB DDR5 5600 MHz
Storage	1 TB NVMe M.2 SSD
Graphics Coprocessor	NVIDIA GeForce RTX 4060 8GB GDDR6
Wireless Type	Intel Wi-Fi 6E AX211 (802.11ax) and Bluetooth 5.3
Operating System	Windows 11 Home
Battery Life (Average)	Up to 6 Hours
Dimensions (LxWxH)	14.53 x 10.21 x 0.94 inches
Item Weight	5.11 lbs (approx. 10 pounds in spec, using description's 5.11 lbs as more precise for laptop weight)
Color	Platinum Silver

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your product or visit the official HP support website. HP provides various support resources, including drivers, software updates, and troubleshooting guides.

You can find more information and contact support at theHP Store on Amazon or the official HP support portal.

10. VIDEO RESOURCES

Currently, there are no official product videos from the seller available for embedding in this manual. Please check the product page or the manufacturer's website for any available video guides or demonstrations.