

## Fretta F6000

# Fretta Cold Press Juicer Machine User Manual

Model: F6000

For Cold Press Juicer Machines, 5.3" Self Feeding Slow Masticating Juicers Fit Whole Fruits & Vegetable Easy Clean Juice  
Extractor, Tritan Material BPA Free 250W

---

## 1. INTRODUCTION

---

Thank you for choosing the Fretta Cold Press Juicer Machine. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new juicer. Designed for optimal nutrient extraction, this slow masticating juicer features a 5.3-inch wide feed chute, a 54oz large-capacity hopper, and a powerful 250W motor, all constructed with BPA-free Tritan material for your health and convenience.



Figure 1.1: Fretta Cold Press Juicer Machine (Matcha)

The Fretta juicer utilizes cold press technology to gently extract juice, minimizing heat and oxidation to preserve maximum nutrients and enzymes. Its anti-drip cap design ensures a clean countertop, and the built-in safety sensor prevents operation unless all parts are securely in place. Enjoy fresh, healthy juices with ease.

Your browser does not support the video tag.

Video 1.1: Overview of the Fretta Cold Press Juicer Machine in operation, demonstrating its features and juice extraction capabilities.

## 2. IMPORTANT SAFETY INSTRUCTIONS

- **Read All Instructions:** Before using the juicer, carefully read and understand all instructions provided in this manual.
- **Electrical Safety:** Ensure the voltage indicated on the appliance corresponds to your local mains voltage before

connecting. Always unplug the juicer from the power outlet when not in use, before assembling or disassembling parts, and before cleaning.

- **Secure Assembly:** The juicer is equipped with a safety sensor. It will not operate unless all parts are correctly and securely assembled. Ensure the lid is properly locked in place before turning on the machine.
- **Avoid Foreign Objects:** Do not insert fingers or other objects into the feed chute while the juicer is operating. Use the provided food pusher only.
- **No Hard Materials:** Do not process hard materials such as ice, frozen fruits (unless specifically for sorbet function), or seeds with hard shells, as this may damage the auger or motor.
- **Cleaning:** Do not immerse the motor base in water or any other liquid. Refer to the "Cleaning & Maintenance" section for proper cleaning instructions. This appliance is **NOT** dishwasher safe.
- **Damage:** Do not operate the juicer if the cord or plug is damaged, or if the appliance malfunctions or has been dropped or damaged in any manner. Contact customer support for assistance.

### 3. PARTS AND COMPONENTS

---

Familiarize yourself with the components of your Fretta Juicer:

1. Motor Base with Control Dial
2. Juicing Bowl
3. Auger (Masticating Screw)
4. Fine Strainer (Filter)
5. Lid with 5.3-inch Wide Feed Chute and Smaller Inner Chute
6. Food Pusher
7. Juice Container (54oz capacity)
8. Pulp Container
9. Cleaning Brush

# Extra-wide Feeding Chute

Adding Ingredients without Pre-cutting



Figure 3.1: The 5.3-inch extra-wide feeding chute allows for whole fruits and vegetables.

# 54oz Large Capacity Hopper

## Make Batch Juicing Easier



Figure 3.2: The 54oz large capacity hopper simplifies batch juicing.

## 4. SETUP AND ASSEMBLY

Follow these steps to assemble your Fretta Juicer before first use:

1. Place the motor base on a stable, flat, and dry surface.
2. Align the juicing bowl with the motor base and rotate it clockwise until it locks securely into place.
3. Insert the auger into the center of the juicing bowl, ensuring it sits firmly.
4. Place the fine strainer (filter) over the auger, aligning it with the juicing bowl.
5. Attach the lid to the juicing bowl, aligning the arrows on the lid and bowl, then rotate clockwise until it clicks into the locked position. The safety sensor will prevent operation if not properly locked.
6. Position the juice container under the juice spout and the pulp container under the pulp outlet.
7. Ensure the anti-drip cap on the juice spout is open before juicing.

Your browser does not support the video tag.

## 5. OPERATING INSTRUCTIONS

---

### 5.1 Juicing Fruits and Vegetables

1. **Prepare Ingredients:** Wash all fruits and vegetables thoroughly. For the 5.3-inch wide feed chute, most whole fruits and vegetables like apples and oranges can be juiced without pre-cutting. For harder or fibrous ingredients (e.g., carrots, celery, ginger), it is recommended to cut them into smaller pieces to facilitate smoother juicing and prevent clogging. Remove large seeds or hard pits (e.g., avocado pits, peach pits).
2. **Load Hopper:** Place the prepared ingredients into the 54oz large-capacity hopper.
3. **Start Juicing:** Turn the control dial on the motor base to the "ON" position. The juicer will begin to process the ingredients.
4. **Use Food Pusher (if needed):** For ingredients that do not feed automatically, gently use the food pusher to guide them down the chute. Do not force ingredients.
5. **Collect Juice and Pulp:** Fresh juice will flow into the juice container, and dry pulp will be expelled into the pulp container.
6. **Finish:** Once all ingredients are processed, turn the control dial to "OFF" and unplug the appliance.

Your browser does not support the video tag.

Video 5.1: Demonstrates juicing various fruits and vegetables, including a pumpkin mango delight recipe.

### 5.2 Making Frozen Desserts (Sorbet)

Your Fretta juicer can also make delicious frozen desserts. Ensure fruits are fully frozen before use.

1. **Prepare Frozen Fruit:** Use pre-frozen fruits like berries, bananas, or mangoes. Allow them to thaw slightly for 5-10 minutes to soften just enough to be processed.
2. **Load:** Place the slightly thawed frozen fruit into the feed chute.
3. **Process:** Turn the control dial to "ON". The juicer will process the frozen fruit into a sorbet-like consistency.
4. **Collect:** The sorbet will come out of the juice spout. Collect it in a bowl.
5. **Serve:** Serve immediately or freeze for later.

Your browser does not support the video tag.

Video 5.2: Instructions for making mixed berry sorbet using the Fretta juicer.

Your browser does not support the video tag.

Video 5.3: Shows the versatility of the juicer in creating both fresh juice and frozen delights.

### 5.3 Reverse Function

If ingredients become jammed or the juicer stops during operation, use the "REV" (Reverse) function. Turn the dial to "REV" and hold it for a few seconds to clear the blockage. Release the dial to return to the "OFF" position, then switch back to "ON" to resume juicing. Do not hold the "REV" position for extended periods.

## 6. CLEANING & MAINTENANCE

---

Regular cleaning ensures optimal performance and extends the life of your Fretta Juicer. It is recommended to clean the juicer immediately after each use.

1. **Unplug:** Always unplug the juicer from the power outlet before cleaning.
2. **Disassemble:** Disassemble all removable parts: lid, auger, strainer, and juicing bowl.
3. **Rinse:** Rinse all disassembled parts under running water. Use the provided cleaning brush to remove any pulp residue from the strainer and other components.
4. **Wash:** For a more thorough clean, wash parts with warm, soapy water. Rinse thoroughly to remove all soap residue.
5. **Motor Base:** Wipe the motor base with a damp cloth. **Never immerse the motor base in water or any other liquid.**
6. **Drying:** Allow all parts to air dry completely before reassembling or storing.
7. **Storage:** Store the assembled juicer in a dry, clean place.

**Important: The juicer parts are NOT dishwasher safe. Hand washing is required.**



Figure 6.1: Easy cleaning of the juicer parts under running water.

Your browser does not support the video tag.

Video 6.1: A quick demonstration of disassembling and cleaning the Fretta juicer.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not properly assembled; power cord not plugged in; safety sensor not engaged.	Ensure all parts are securely locked into place. Check power connection.
Juicer stops during operation or jams.	Too much ingredient loaded at once; hard ingredients causing blockage.	Turn to "OFF", then use "REV" (Reverse) function for a few seconds to clear blockage. Reduce amount of ingredients or cut harder items into smaller pieces.
Low juice yield or wet pulp.	Ingredients processed too quickly; strainer clogged.	Feed ingredients slowly. Clean the strainer thoroughly after each use. Ensure the anti-drip cap is open.

Problem	Possible Cause	Solution
Excessive vibration or noise.	Improper assembly; hard ingredients.	Disassemble and reassemble all parts correctly. Ensure no foreign objects are in the juicer.

## 8. SPECIFICATIONS

---

**Brand:** Fretta

**Model Number:** F6000

**Color:** Matcha

**Special Feature:** Pulp Control

**Product Dimensions:** 7.5"D x 7.5"W x 13"H

**Finish Type:** Mirror Satin

**Capacity:** 3.4 Pounds (approx. 54oz hopper)

**Maximum Power:** 250 Watts

**Voltage:** 120V

**Item Weight:** 10.41 pounds

**Dishwasher Safe:** No

**Date First Available:** September 19, 2024

## 9. WARRANTY AND SUPPORT

---

For warranty information, please refer to the warranty card included with your product packaging. Keep your purchase receipt as proof of purchase for any warranty claims.

For technical support, troubleshooting assistance beyond this manual, or to inquire about replacement parts, please contact Fretta customer service. You can often find contact details on the official Fretta website or through the retailer where you purchased the product.

Visit the official Fretta Store for more information and products: [Fretta Store on Amazon](#).