

[Manuals.plus](#) /

› [Vagusicc](#) /

› Vagusicc C Shaped End Table with Charging Station (Model BZ18-End Table) - Instruction Manual

Vagusicc BZ18-End Table

Vagusicc C Shaped End Table with Charging Station

Model: BZ18-End Table

INTRODUCTION

This manual provides essential instructions for the assembly, operation, maintenance, and safety of your Vagusicc C Shaped End Table with Charging Station. Please read this manual thoroughly before use and retain it for future reference.

SAFETY INFORMATION

- Always follow the assembly instructions carefully to avoid injury.
- Do not exceed the maximum weight recommendation of **22 pounds** to maintain stability.
- Be cautious when adjusting the height to prevent pinching.
- Keep the charging station dry and do not overload it to prevent electrical hazards.
- Always unplug the charging station when not in use.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- 1 x Side Table
- 1 x Charging Station (integrated)
- 1 x Accessory Bag (containing screws, Allen Key, Screw Driver)
- Assembly Instructions

SETUP

Assembly Instructions

The Vagusicc C Shaped End Table is designed for simple and easy assembly. Detailed assembly instructions are included in the package, with all components and accessories clearly marked with numbers for straightforward identification. All necessary tools, including an Allen Key and screwdriver, are provided.

Follow the step-by-step guide provided in your package to assemble the table. Ensure all screws are tightened securely for stability.



Figure 1: Exploded view of the table components and assembly process.

Adjusting Height

The table features an adjustable height mechanism, allowing it to be set between 17.7 inches and 33 inches. To adjust the height, loosen the bracket screws on the vertical supports, slide the tabletop to your desired height, and then securely tighten the screws. This allows the table to fit perfectly over various furniture pieces like recliners, beds, or couches.

Pull it Closer

Slide it under the sofa for convenient working or studying.



Figure 2: The table's height can be adjusted to suit various furniture heights, from 17.7 to 33 inches.

OPERATING INSTRUCTIONS

Using the Charging Station

The integrated charging station provides convenient power access. It includes a standard AC outlet (125V/12A), a USB port (5V/2A), and a Type-C charger (5V/2A). Connect the table's 4.9ft power cable to a wall outlet. You can then plug in and charge multiple devices directly from the table, keeping cords organized and within reach.

Fits Small Spaces

Suitable for any space,
and makes your work easier



Figure 3: The built-in charging station features AC, USB, and Type-C ports for device charging.

Utilizing the Storage Pocket

A large storage bag (14.35" x 9.59") and four smaller cloth pockets are attached to the side of the table. These are ideal for organizing items such as tablets, magazines, remote controls, pens, and mobile phones, helping to keep your living space tidy.

Adjustable Height

Fit for Sofa and Bed Height 17.7-33 inch



Figure 4: The side storage pockets offer convenient organization for small items.

Sliding Under Furniture

The C-shaped design allows the table to easily slide under sofas, beds, or recliners, bringing the tabletop surface closer to you for comfortable use while working, eating, or relaxing. The slim profile ensures it fits into tight spaces.



63"



33"



17.7"



25lb




Figure 5: The C-shaped base allows the table to slide conveniently under furniture.

MAINTENANCE

Cleaning

To clean the table surface, simply wipe with a dry cloth. Avoid using harsh chemicals or abrasive cleaners that may damage the finish. The table surface is designed to be waterproof and anti-scratch for durability.



Figure 6: The table surface is waterproof and resistant to scratches.

Stability Check

Periodically check all screws and connections to ensure they remain tight. The table is equipped with four adjustable feet to prevent floor scratches and allow for slight adjustments on uneven surfaces, enhancing overall stability. The triangular metal joints and extended bottom frame also contribute to its sturdy construction.

TROUBLESHOOTING

- **Table Wobbles:** Ensure all assembly screws are fully tightened. Adjust the four leveling feet at the base of the table to compensate for uneven flooring.
- **Difficulty Adjusting Height:** Loosen the bracket screws sufficiently before attempting to slide the tabletop. Do not force the adjustment. If resistance is met, re-check for any obstructions.
- **Charging Station Not Working:** Verify that the table's power cable is securely plugged into a functional wall outlet. Check if the devices you are trying to charge are properly connected to the USB, Type-C, or AC ports. Avoid overloading the charging station.
- **Missing Parts:** Refer to the "Package Contents" section. If any parts are missing, contact customer support immediately.

SPECIFICATIONS

Brand	Vagusicc
Model Name	BZ18-End Table
Product Dimensions	12"D x 16"W x 17.7-33"H (Adjustable Height)
Item Weight	7.5 pounds
Maximum Weight Recommendation	22 Pounds
Color	Black
Material	Alloy Steel, Wood
Power Cable Length	4.9 ft

Charging Ports	1 x AC Outlet (125V/12A), 1 x USB Port (5V/2A), 1 x Type-C Port (5V/2A)
Special Features	Adjustable Height, Charging Station, Storage Bag, Portable, Space Saving, Easy Assembly

WARRANTY AND SUPPORT

Every Vagusicc end table is thoroughly and rigorously tested to ensure quality. If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact Vagusicc customer support. Refer to your purchase documentation for specific warranty details and contact information.

For further assistance, please visit the official Vagusicc store: [Vagusicc Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question