

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

› [Devoko](#) /

› Devoko Outdoor Storage Cabinet DV240309 User Manual

## Devoko DV240309

# Devoko Outdoor Storage Cabinet DV240309 User Manual

Model: DV240309

## INTRODUCTION

---

This manual provides essential information for the assembly, operation, maintenance, and care of your Devoko Outdoor Storage Cabinet, Model DV240309. Please read these instructions carefully before assembly and use to ensure safe and proper functionality of the product. Keep this manual for future reference.



Image: The Devoko Outdoor Storage Cabinet, Model DV240309, shown in a kitchen environment. The cabinet features a spacious tabletop, an open middle shelf, and a closed bottom compartment with two magnetic doors. Various household items are stored within, demonstrating its storage capacity.

## SAFETY INFORMATION

---

- Ensure all parts are present and undamaged before beginning assembly.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly to avoid damaging the wood.
- Place the cabinet on a level, stable surface to prevent tipping.
- Do not exceed the maximum weight capacity of 340 pounds.
- Keep small parts away from children during assembly.

## PACKAGE CONTENTS

---

Verify that all components listed below are included in your package. If any parts are missing or damaged, please contact customer support.

- Acacia Wood Panels (various sizes for top, sides, shelves, doors)
- Hardware Pack (screws, dowels, magnetic catches, handles)
- Assembly Tools (e.g., Allen wrench, screwdriver)
- Assembly Manual (this document or a separate printed guide)

## SETUP AND ASSEMBLY

---

Assembly is required for this product. Please follow the steps below carefully. It is recommended to have two people for assembly.

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface to prevent scratches. Refer to the included parts list to identify each piece.
2. **Assemble Side Panels:** Attach the side panels to the base frame using the provided screws and dowels. Ensure all connections are secure but do not overtighten.
3. **Install Shelves:** Insert the middle and bottom shelves into the designated slots or attach them to the side panels using the appropriate hardware.
4. **Attach Top Panel:** Secure the top panel to the assembled frame.
5. **Install Doors:** Attach the two magnetic doors to the front of the cabinet using the provided hinges. Ensure the doors swing freely and align properly.
6. **Attach Handles and Magnetic Catches:** Install the round handles onto the doors and secure the magnetic catches to the cabinet frame and doors to ensure they close securely.
7. **Final Check:** Once assembled, gently lift and move the cabinet to its desired location. Ensure it is stable and level. Tighten any loose connections if necessary.

[Details](#)[Size](#)[Storage](#)

# PRODUCT DIMENSIONS

220  
LBS

Sufficient storage space with load capacity up to 220LBS



Image: A detailed diagram illustrating the dimensions of the Devoko Outdoor Storage Cabinet. Key measurements such as overall length (42.1"), width (14.1"), height (32.2"), and internal shelf heights are clearly marked. The diagram also includes a visual indicator for load capacity.

## OPERATING INSTRUCTIONS

The Devoko Outdoor Storage Cabinet offers versatile storage solutions for various environments.

- **Storage Organization:** Utilize the three levels of storage: the spacious tabletop, the open middle shelf, and the closed bottom cabinet. This design allows for categorized storage of different items, from garden tools and outdoor supplies to kitchenware and decorative pieces.
- **Door Operation:** The cabinet features two magnetic doors with round handles. To open, gently pull the handle. To close, push the door until the magnetic catch engages, ensuring a secure closure.
- **Versatile Placement:** This cabinet is suitable for both indoor and outdoor use. It can function as an outdoor storage unit, a bar cart, a potting table on a patio, or an indoor sideboard, TV stand, or entryway table.

Details

Size

Storage

# STURDY AND SAFE DESIGN

Suitable for garden, yard, kitchen, living room, etc.




Image: The Devoko Outdoor Storage Cabinet positioned outdoors, demonstrating its use for storing garden essentials. The doors are open, revealing a watering can, hand trowels, and bags of potting mix, highlighting its "Sturdy and Safe Design" suitable for various environments.

[Details](#)[Size](#)[Storage](#)

# PRODUCT DETAILS


100% high quality acacia wood, stylish and durable



**Solid Structure**



**Magnetic Closures**



**Convenient Handle**

Image: A composite image detailing the features of the Devoko Outdoor Storage Cabinet. It highlights the solid acacia wood structure, the magnetic closures for secure door fastening, and the convenient wooden handles for easy access. This image emphasizes the product's quality and functional design.

## MAINTENANCE AND CARE

To ensure the longevity and appearance of your Devoko Outdoor Storage Cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe the cabinet regularly with a soft, damp cloth to remove dust and dirt. For stubborn stains, use a mild soap solution and dry immediately with a clean cloth. Avoid abrasive cleaners or harsh chemicals.
- **Wood Care:** The cabinet is made of high-quality acacia wood with an oil-based paint finish, designed for weather resistance. While it is scratch-resistant and wear-resistant, periodic reapplication of a suitable wood sealant or oil can further protect the wood and maintain its appearance, especially if exposed to harsh outdoor elements.
- **Protection:** Although designed for outdoor use, covering the cabinet during extreme weather conditions (heavy rain, snow, prolonged direct sunlight) can extend its lifespan and prevent premature fading or cracking.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary to maintain structural integrity.

## TROUBLESHOOTING

---

If you encounter any issues with your Devoko Outdoor Storage Cabinet, refer to the following common solutions:

- **Wobbly Cabinet:**
  - Ensure the cabinet is placed on a level surface.
  - Check all assembly screws and tighten any that are loose.
- **Doors Not Closing Properly:**
  - Verify that the magnetic catches are correctly aligned and securely attached to both the doors and the cabinet frame.
  - Check the door hinges for proper installation and alignment. Adjust if necessary.
- **Scratches or Minor Damage:**
  - For minor scratches, a wood repair kit or touch-up pen matching the acacia wood color can be used.
  - Consult a professional for significant damage.

## SPECIFICATIONS

---

<b>Model Number</b>	DV240309
<b>Brand</b>	Devoko
<b>Material</b>	Acacia Wood
<b>Color</b>	Brown
<b>Overall Dimensions (L x W x H)</b>	42.1" x 14.1" x 32.2" (106.9 cm x 35.8 cm x 81.8 cm)
<b>Item Weight</b>	48.5 lbs (22 kg)
<b>Weight Limit</b>	340 lbs (154 kg)
<b>Number of Shelves</b>	3 (1 open, 1 closed compartment base)
<b>Door Style</b>	Shutter
<b>Special Feature</b>	Scratch Resistant, Weatherproof Finish
<b>Assembly Required</b>	Yes



Image: The Devoko Outdoor Storage Cabinet shown in an outdoor patio setting, with its two magnetic doors closed. The cabinet serves as a functional and decorative piece, complementing the outdoor environment.

## WARRANTY INFORMATION

---

Specific warranty details for the Devoko Outdoor Storage Cabinet, Model DV240309, are typically provided at the point of purchase or included with the product packaging. Please refer to your purchase receipt or the documentation that came with your cabinet for comprehensive warranty terms and conditions. For any warranty claims or inquiries, please contact Devoko customer support directly.

## CUSTOMER SUPPORT

---

For further assistance, missing parts, or any questions regarding your Devoko Outdoor Storage Cabinet, please contact Devoko customer support. You can typically find contact information on the manufacturer's website or through the retailer where the product was purchased.

**Brand:** Devoko

**Model:** DV240309

© 2026 Devoko. All rights reserved.