**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## JVC HANP40TB

# JVC nearphones Open Ear True Wireless Headphones

Model: HANP40TB

User Instruction Manual

## 1. Introduction

Thank you for purchasing the JVC nearphones Open Ear True Wireless Headphones. These headphones are designed to provide a comfortable and secure listening experience while allowing you to remain aware of your surroundings. Featuring Bluetooth 5.4 technology, 16mm large drivers, and a Pivot Motion Mechanism, they offer up to 26 hours of playback and are IPX4 rated for water resistance.




Image: JVC nearphones Open Ear True Wireless Headphones and their charging case.

## 2. Package Contents

Please ensure all items are present in the package:

- JVC nearphones (Left and Right)
- Wireless Charging Case
- USB Charging Cable
- Instruction Manual (this document)

## 3. Getting Started (Setup)

### 3.1. Charging the Headphones and Case

Before first use, fully charge the headphones and the charging case. Place the headphones into the charging case, then connect the USB charging cable to the case and a power source. The indicator lights on the case will show charging status.




Image: The charging case provides extended battery life, offering up to 26 hours of total playback.

## 3.2. Pairing with a Device

1. Ensure the headphones are charged.
2. Open the charging case. The headphones will automatically enter pairing mode (indicator lights will flash).
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for available Bluetooth devices and select "JVC HANP40TB" from the list.
5. Once connected, the indicator lights on the headphones will change, and you will hear an audible confirmation.

## 3.3. Wearing the Headphones

The JVC nearphones feature a Pivot Motion Mechanism for a secure and comfortable fit. Gently place the earbud portion into your ear and rotate the pivot hook around the back of your ear until it feels stable. Adjust for optimal comfort and sound.




Image: The Pivot Motion Design ensures a secure and comfortable fit for various activities.

## 4. Operation

### 4.1. Basic Controls (Touch Controls)

The headphones are equipped with touch controls for various functions:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud during an incoming call.
- **Reject Call:** Press and hold on either earbud during an incoming call.
- **Activate Voice Assistant:** Triple tap on either earbud.

### 4.2. Sound Modes

The headphones offer three distinct sound modes: Normal, Bass, and High. To cycle through these modes, press and

hold the touch control area for approximately 2 seconds until you hear a confirmation tone indicating the mode change.

### 4.3. Open-Ear Listening

These headphones feature an open-ear design, which means they do not block your ear canal. This allows you to hear ambient sounds, such as approaching vehicles or conversations, while still enjoying your audio. This design enhances situational awareness, making them suitable for outdoor activities.





Image: The open-ear design allows users to listen to audio while remaining aware of their surroundings.

### 4.4. Single Ear Use

Either the left or right earbud can be used independently. Simply remove one earbud from the case, and it will automatically connect to your device if previously paired. The other earbud can remain in the case or be turned off.

## 5. Care and Maintenance

To ensure the longevity and optimal performance of your JVC nearphones, follow these care instructions:

- **Cleaning:** Wipe the headphones and charging case with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Water Resistance:** The headphones are IPX4 rated, meaning they are resistant to splashing water from any direction. They are not designed for submersion in water. Avoid exposing them to strong jets of water or prolonged immersion. Dry them thoroughly if they get wet before placing them back in the charging case.




Image: The IPX4 rating provides protection against splashes, making the headphones suitable for light rain or sweat.

- **Storage:** When not in use, store the headphones in their charging case to protect them from dust and damage. Store in a cool, dry place away from direct sunlight and extreme temperatures.

## 6. Troubleshooting

If you encounter issues with your JVC nearphones, please refer to the following common solutions:

| Problem | Possible Solution |
|---|---|
| Headphones do not turn on. | Ensure the headphones and charging case are fully charged. Place headphones in case and close lid, then reopen. |

| Problem | Possible Solution |
|---|---|
| Cannot pair with device. | Ensure Bluetooth is enabled on your device. Make sure headphones are in pairing mode (indicator lights flashing). Forget the device in your phone's Bluetooth settings and try pairing again. Ensure headphones are not connected to another device. |
| No sound or low volume. | Check volume levels on both the headphones and your connected device. Ensure headphones are properly seated in your ears. Try switching sound modes. |
| Intermittent connection. | Ensure your device is within the Bluetooth range (10 meters). Avoid obstacles between the headphones and your device. Reduce interference from other wireless devices. |
| Touch controls are unresponsive. | Ensure your fingers are clean and dry. Try restarting the headphones by placing them in the case and then taking them out. |

## 7. Specifications

| Feature | Detail |
|---|---|
| Model Name | NEARPHONES (HANP40T) |
| Connectivity Technology | Wireless (Bluetooth 5.4) |
| Bluetooth Range | 10 Meters |
| Audio Driver Size | 16 Millimeters |
| Frequency Response | 20 Hz to 20,000 Hz |
| Impedance | 16 Ohm |
| Battery Life (Headphones + Case) | Up to 26 Hours |
| Water Resistance Level | IPX4 (Waterproof) |
| Control Type | Touch Control, Voice |
| Material | Plastic |
| Item Weight | 5 ounces |
| Product Dimensions | 2.99 x 1.81 x 5.79 inches |

## 8. Warranty and Support

### 8.1. Warranty Information

For information regarding the product warranty, please refer to the warranty card included in your product packaging or visit the official JVC website. Protection plans may also be available for purchase separately.

### 8.2. Customer Support

If you require further assistance or have questions not covered in this manual, please contact JVC customer support. You can find contact information and additional resources on the official JVC website:

**Visit the Official JVC Store on Amazon**

© 2024 JVC. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

**Open the live page**

**https://manuals.plus/asin/B0DJ1T38RW**

More documents and user manuals: **https://manuals.plus/**