

Diamond Antenna BB7V

Diamond Antenna BB7V Multi-Band Vertical Antenna User Manual

Model: BB7V | Brand: Diamond Antenna

1. INTRODUCTION

The Diamond Antenna BB7V is a multi-band vertical antenna designed for amateur radio operators. It provides wide frequency coverage from 2 to 30 MHz, supporting various HF and VHF bands for reliable long-distance communication. This manual provides essential information for the safe and effective installation, operation, and maintenance of your BB7V antenna.

2. SAFETY INFORMATION

Read all safety instructions before installing or operating the antenna. Failure to follow these instructions may result in personal injury or equipment damage.

- **Power Lines:** Never install the antenna near power lines. Maintain a safe distance from all electrical wires.
- **Lightning:** Install proper lightning protection and grounding for the antenna system. Disconnect the antenna from your radio during electrical storms.
- **Working at Heights:** Use appropriate safety equipment when working on masts or towers. Ensure stable footing and use fall protection.
- **Grounding:** Ensure the antenna mast and coaxial cable shield are properly grounded according to local electrical codes.
- **RF Exposure:** Maintain a safe distance from the antenna during transmission to avoid excessive RF exposure.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- BB7V Multi-Band Vertical Antenna elements
- Mounting hardware (U-bolts, clamps, nuts, washers)

- Balun/Matching unit (integrated or separate)
- Instruction manual (this document)

4. SETUP AND INSTALLATION

The BB7V antenna is designed for outdoor base station installation on a mast or pole. Follow these steps carefully for proper setup.

4.1 Mounting the Antenna

Select a sturdy mast or pole that can support the antenna's weight and withstand wind loads. The antenna should be mounted vertically.

1. Assemble the antenna elements according to the diagrams provided in the manufacturer's specific assembly guide (if separate from this manual).
2. Attach the antenna's mounting bracket to the mast using the supplied U-bolts and clamps. Ensure all hardware is tightened securely to prevent rotation or slippage in high winds.



Figure 1: Close-up view of the BB7V antenna's base and mounting hardware securely attached to a vertical mast. The coaxial connection point is visible at the bottom of the cylindrical unit.



Figure 2: The Diamond Antenna BB7V vertical antenna fully assembled and mounted on a mast, extending upwards against a clear blue sky. This image shows the overall structure and vertical orientation.

4.2 Coaxial Cable Connection

1. Connect a high-quality 50-ohm coaxial cable (e.g., RG-8X, RG-213) to the antenna's SO-239 connector.
2. Ensure the connection is tight and weatherproof using self-amalgamating tape or a weather-sealing boot.
3. Route the coaxial cable away from the mast and other metallic objects to minimize interference.

4.3 Grounding

Proper grounding is crucial for safety and performance.

- Connect the antenna mast to a good earth ground using heavy gauge wire (e.g., #10 AWG or larger).
- Consider using a lightning arrestor in the coaxial feed line near the entry point to your building.

5. OPERATING INSTRUCTIONS

Once installed, the BB7V antenna is ready for operation across its specified frequency range.

- **Transceiver Connection:** Connect the other end of your 50-ohm coaxial cable to the antenna port of your amateur radio transceiver.
- **SWR Check:** Before transmitting, always check the Standing Wave Ratio (SWR) across the desired operating band using an SWR meter. The BB7V is designed for wideband operation, but minor SWR adjustments may be beneficial for optimal performance on specific frequencies.
- **Frequency Range:** The antenna operates effectively from 2 to 30 MHz. Utilize your transceiver's capabilities to select the desired band and frequency.
- **Power Output:** Adhere to the maximum power rating specified for the antenna and your transceiver's capabilities.

6. MAINTENANCE

Regular maintenance ensures the longevity and performance of your BB7V antenna.

- **Visual Inspection:** Periodically inspect the antenna, mast, and all connections for signs of corrosion, loose hardware, or physical damage, especially after severe weather.
- **Connection Integrity:** Check coaxial cable connections for tightness and weatherproofing. Reapply weather-sealing tape if necessary.
- **Cleaning:** Clean the antenna elements with a mild detergent and water if they become excessively dirty. Avoid abrasive cleaners.
- **Grounding System:** Verify the integrity of your grounding system annually.

7. TROUBLESHOOTING

If you encounter issues with your BB7V antenna, consider the following common problems and solutions:

Problem	Possible Cause	Solution
High SWR	Loose connections, damaged coaxial cable, improper grounding, nearby metallic objects.	Check all connections, inspect coaxial cable, verify grounding, ensure clear space around antenna.
Poor Signal Reception/Transmission	High SWR, antenna damage, incorrect frequency selection, transceiver issue.	Address high SWR, inspect antenna for damage, confirm transceiver settings, test with another antenna if possible.
Intermittent Operation	Loose connections, weather-related issues (water ingress).	Tighten all connections, re-weatherproof coaxial cable, inspect for water damage.

8. SPECIFICATIONS

- **Frequency Range:** 2 to 30 MHz
- **Antenna Type:** Multi-Band Vertical Antenna
- **Impedance:** 50 Ohms
- **Manufacturer:** Diamond Antenna
- **Color:** Silver

9. WARRANTY INFORMATION

The Diamond Antenna BB7V comes with a **1-year limited warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by improper installation, lightning strikes, misuse, or unauthorized modifications. Please retain your proof of purchase for warranty claims.

10. SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Diamond Antenna customer support through their official website or authorized dealers. Provide your product model (BB7V) and proof of purchase when seeking support.

© 2026 Diamond Antenna. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question