

[Manuals.plus](#) /

> [AIYAPLAY](#) /

> AIYAPLAY Kids Tool Bench Instruction Manual - 102 Pieces with Electric Drill, Model 350-163V00YL

AIYAPLAY 350-163V00YL

AIYAPLAY Kids Tool Bench Instruction Manual

Model: 350-163V00YL

INTRODUCTION

Thank you for choosing the AIYAPLAY Kids Tool Bench. This 102-piece toy workbench set is designed to provide an engaging and educational play experience for children aged 3-6 years. It includes a variety of tools and an electric drill, fostering creativity and developing fine motor skills. This manual provides essential information for the safe setup, operation, maintenance, and troubleshooting of your new toy.



Image: Overview of the AIYAPLAY Kids Tool Bench and its 102 included accessories.

1. SETUP INSTRUCTIONS

Carefully unpack all components and ensure all 102 pieces are present. Assembly of the workbench is required. Follow the visual guide below for proper assembly.

1.1. Component Check

LEARN IN THE GAME



Image: Detailed view of the 102 accessories included with the tool bench, such as screws, nuts, tools, and workbench parts.

Before assembly, verify that all parts shown in the 'Rich Accessories' image are accounted for. If any parts are missing, please contact customer support.

1.2. Battery Installation

- The electric drill requires two (2) 1.5V AA batteries (not included).
- The workbench interactive sound panel requires three (3) 1.5V AA batteries (not included).
- Ensure batteries are inserted with the correct polarity (+/-).
- Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.

1.3. Workbench Assembly

Assemble the workbench structure by connecting the legs to the main tabletop and base. Secure all connections firmly. Refer to the included assembly diagram for step-by-step instructions.



Image: Dimensions of the assembled tool bench, illustrating its height, width, and depth.

2. OPERATING INSTRUCTIONS

The AIYAPLAY Kids Tool Bench offers various interactive features for an immersive play experience.

2.1. Interactive Sound Panel

- The workbench features four interactive buttons.
- Press each button to activate different sounds: music, sawing, hammering, and drilling.



Image: The interactive sound panel with buttons for various tool sounds and music.

2.2. Electric Drill Operation

- Ensure batteries are correctly installed in the electric drill.
- Press the trigger to activate the drill. It will vibrate and buzz, mimicking a real drill.
- Use the drill with the provided toy screws and nuts on the workbench or other compatible surfaces.

2.3. Using Hand Tools

The set includes various hand tools such as a hammer, wrench, and pliers. These tools can be used for imaginative play, such as tightening toy nuts and bolts or 'repairing' items on the workbench.



Image: Close-up of a child engaging with the workbench, using a toy wrench on the gears.

3. MAINTENANCE

Proper care will ensure the longevity and safety of the AIYAPLAY Kids Tool Bench.

3.1. Cleaning

- Wipe all surfaces with a damp cloth and mild soap.
- Do not immerse electronic components (drill, workbench sound panel) in water.
- Allow all parts to dry completely before storage.

3.2. Storage

The tool bench is designed for convenient storage. It features a handy storage grid, and both sides of the tool bench can be folded to save space.



Image: Integrated storage solutions on the tool bench, including a grid and a cabinet.

- Store all accessories in the designated storage areas to prevent loss.
- Keep the toy in a cool, dry place away from direct sunlight.

4. TROUBLESHOOTING

Problem	Possible Cause	Solution
Electric drill/workbench sounds not working	Batteries are dead or incorrectly installed.	Check battery polarity. Replace with fresh 1.5V AA batteries.
Missing parts after unpacking	Packaging error or accidental discard.	Refer to the 'Rich Accessories' image in Section 1.1. Contact customer support if parts are genuinely missing.
Workbench unstable after assembly	Connections not fully secured.	Re-check all assembly points and ensure they are firmly connected.

5. PRODUCT SPECIFICATIONS

- **Model Number:** 350-163V00YL
- **Dimensions (Assembled):** 60 cm (L) x 23 cm (W) x 59 cm (H)
- **Recommended Age:** 3-6 years
- **Approved Age:** 3+ years
- **Number of Pieces:** 102
- **Battery Requirements:** 5 x 1.5V AA batteries (not included) - 2 for drill, 3 for workbench.
- **Materials:** PP, ABS (Child-friendly materials)



Image: Details on the safe construction and materials (PP, ABS) used in the tool bench.

6. WARRANTY AND SUPPORT

For information regarding warranty, returns, or technical support, please refer to the retailer's policy where the product was purchased or contact AIYAPLAY customer service directly. Please have your model number (350-163V00YL) and purchase details ready when contacting support.

