

[Manuals.plus](#) /

› [Effireli](#) /

› User Manual for Effireli YKR-P/002E Replacement Remote Control

## Effireli YK-YKR-P/002E

# Effireli YKR-P/002E Replacement Remote Control

## USER MANUAL

### 1. Product Overview

---

This manual provides instructions for the Effireli YKR-P/002E replacement remote control, designed for use with various AUX Air Conditioner models. This remote is a direct replacement and requires no complex programming or setup.




Figure 1: Front view of the Effireli YKR-P/002E Replacement Remote Control, showing the display screen and various function buttons.

**Compatible Models:**

- ASW-H12A2INV
- YKR-P/001E
- YKRP/002E
- YKR-P/002E
- YKR-P/003E

*Note: If your specific air conditioner model is not listed, or if your original remote appears significantly different, please verify compatibility before use.*

## 2. Setup

---

The Effireli YKR-P/002E remote control is designed for immediate use without the need for programming. Simply insert batteries, and it is ready to operate your compatible AUX Air Conditioner.

### 2.1. Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch to open it.
3. Insert two AAA batteries (not included), ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Close the battery compartment cover securely.

Once batteries are installed, the remote is ready for operation. Point the remote towards the air conditioner's receiver and press the desired function button.

## 3. Operating Instructions

---

This section details the primary functions of the buttons on your replacement remote control.




Figure 2: Angled view of the remote, highlighting the button layout and model number.

**POWER Button:** Turns the air conditioner ON or OFF.

**MODE Button:** Cycles through operating modes such as Cool, Heat, Fan, Dry, and Auto.

**SPEED Button:** Adjusts the fan speed (e.g., Low, Medium, High, Auto).

**TEMP Up/Down Buttons (↑ / ↓):** Adjusts the desired temperature setting.

**°C/°F Button:** Toggles the temperature display between Celsius and Fahrenheit.

**SWING Buttons (←→ / ↑↓):** Controls the horizontal and vertical swing of the air conditioner's louvers.

**TURBO Button:** Activates maximum cooling or heating for rapid temperature change.

**TIMER Button:** Sets the ON/OFF timer for the air conditioner.

**iFavor Button:** Activates a pre-set preferred operating mode.

- iFeel Button:** Activates a function that senses the temperature at the remote's location for more precise control.
- HEALTH Button:** Activates air purification or health-related functions (if supported by AC unit).
- SLEEP Button:** Adjusts settings for comfortable sleep, often by gradually increasing temperature and reducing fan speed.
- iClean Button:** Initiates a self-cleaning function for the indoor unit (if supported by AC unit).
- Anti-FUNGUS Button:** Activates a function to prevent mold and mildew growth (if supported by AC unit).
- DISPLAY Button:** Controls the display on the air conditioner unit (e.g., turns it on/off).

## 4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your remote control.

### 4.1. Battery Replacement

Replace batteries when the remote's range decreases or the display becomes dim. Always replace both batteries simultaneously with new ones of the same type (AAA).

### 4.2. Cleaning

Wipe the remote control with a soft, dry cloth. Do not use liquid cleaners, sprays, or abrasive materials, as these can damage the remote's surface or internal components.

### 4.3. Storage

If the remote will not be used for an extended period, remove the batteries to prevent leakage and potential damage to the remote.

## 5. Troubleshooting

If you experience issues with your remote control, refer to the following common problems and solutions:

| Problem                                          | Possible Cause                                                                                  | Solution                                                                                                                        |
|--------------------------------------------------|-------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------|
| Remote not responding.                           | Dead or incorrectly installed batteries.                                                        | Replace batteries, ensuring correct polarity (+/-).                                                                             |
| Remote has short range or intermittent response. | Weak batteries; Obstruction between remote and AC unit; Remote not pointed directly at AC unit. | Replace batteries; Remove obstructions; Ensure direct line of sight to AC unit's receiver.                                      |
| Certain functions do not work.                   | Function not supported by your specific AC model; Remote malfunction.                           | Verify if your AC unit supports the function; If not, the button will have no effect. If other functions work, contact support. |

## 6. Specifications

|                    |                           |
|--------------------|---------------------------|
| Model Number       | YK-YKR-P/002E             |
| Brand              | Effireli                  |
| Product Dimensions | 7.09 x 1.89 x 0.79 inches |

|                                 |                         |
|---------------------------------|-------------------------|
| Item Weight                     | 2.12 ounces             |
| Special Feature                 | No Programming Required |
| Max Number of Supported Devices | 1                       |
| Compatible Devices              | Air Conditioner         |
| Connectivity Technology         | Infrared                |

## 7. Warranty and Support

Your Effireli YKR-P/002E replacement remote control comes with the following assurances:

- **30-Day Money-Back Guarantee:** If you are not satisfied with your purchase, you may return it within 30 days for a full refund.
- **12-Month Warranty:** A 12-month warranty covers manufacturing defects from the date of purchase. Returns and exchanges are accepted within this warranty period.

For warranty claims, technical support, or compatibility inquiries, please refer to the contact information provided by your retailer or the product packaging. Ensure you have your purchase details and model number ready when contacting support.

© 2024 Effireli. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

**<https://manuals.plus/asin/B0DJ2DBZ85>**

More documents and user manuals: **<https://manuals.plus/>**