



Manuals.plus /

› **Rowood /**

› Rowood Sakura Bonsai 3D Wooden Puzzle (Model TG415) - Instruction Manual

Rowood TG415

Rowood Sakura Bonsai 3D Wooden Puzzle (Model TG415) - Instruction Manual

1. INTRODUCTION

Welcome to the world of Rowood 3D Wooden Puzzles! This instruction manual provides comprehensive guidance for assembling your Sakura Bonsai 3D Wooden Puzzle, Model TG415. Designed for enthusiasts aged 14 and up, this kit offers a rewarding and engaging building experience without the need for glue. Once completed, your Sakura Bonsai will serve as an elegant decorative piece.

2. PRODUCT OVERVIEW

The Rowood Sakura Bonsai is a beautifully designed 3D wooden puzzle that captures the essence of a cherry blossom tree. Crafted from eco-friendly wood, the model features intricate details including detachable cherry blossoms and layered moss for a realistic 3D effect. The finished model measures approximately 6.3 x 4.3 x 6.6 inches.



Image 2.1: The fully assembled Rowood Sakura Bonsai 3D Wooden Puzzle.

SAKURA BONSAI



Easy
DIY Assembly



Lovely
Home Decor



Great
Gift Choice



Image 2.2: Key features of the Sakura Bonsai puzzle, emphasizing ease of assembly, decorative appeal, and suitability as a gift.

3. SAFETY INSTRUCTIONS

Please read and understand all safety instructions before beginning assembly. This product contains small parts and is not suitable for children under 3 years of age due to choking hazards. Adult supervision is recommended for younger builders (ages 14+ recommended).

- **Choking Hazard:** Small parts. Not for children under 3 years.

- Keep all components away from pets.
- Handle wooden pieces carefully to avoid splinters.
- Dispose of packaging materials responsibly.

4. PACKAGE CONTENTS

Your Rowood Sakura Bonsai 3D Wooden Puzzle kit includes the following components:

- Pre-cut wooden sheets with various puzzle pieces (labeled A1, A2, etc.).
- Bags of small flower pieces (labeled P1, P2, etc.).
- Detailed graphical instruction manual.
- Product Safety Instructions booklet.



Image 4.1: The various wooden sheets and bags of flower pieces included in the kit.

5. ASSEMBLY INSTRUCTIONS

Follow these step-by-step instructions carefully to assemble your Sakura Bonsai. The manual uses visual icons to guide you through the process. Refer to the icon legend in your printed manual for detailed explanations.

- **Icon Legend:** Your instruction manual includes a page explaining various icons. For example:
 - An exclamation mark in a red circle indicates "Special attention in assembly."
 - A hand with a piece of sandpaper indicates "Polish the parts with sandpaper." This is useful if pieces are

too tight.

- An arrow indicating a change in perspective means "Perspective changed."
- A gear icon indicates "Ensure the connection of gears smoothly."
- **Preparation:** Carefully detach all pieces from the wooden sheets. Use a small tool or your fingers to gently push them out. Identify each piece by its label (e.g., A1, A2, B1, B2).
- **Step-by-Step Assembly:** The manual provides numbered steps with clear diagrams. Each step shows which pieces to use and how they connect. Pay close attention to the orientation of pieces and any arrows indicating direction.
- **Interlocking Design:** This puzzle uses an interlocking design, meaning no glue is required. Pieces should fit snugly. If a piece is too tight, gently sand the edges as indicated by the sandpaper icon.
- **Flower Placement:** The small flower pieces (P1, P2, P3, P4) are typically added towards the final stages of assembly to create the cherry blossom effect. Follow the diagrams for their correct placement and distribution on the branches.

Watch the official assembly video for a visual guide:

Video 5.1: An official video from Rowood Direct demonstrating the assembly process of the Sakura Bonsai 3D Wooden Puzzle.



Image 5.2: Detailed view of the assembled bonsai, highlighting the 3D flower branches, layered moss, and the sturdy base.

6. MAINTENANCE

To ensure the longevity and appearance of your completed Sakura Bonsai 3D Wooden Puzzle, follow these simple maintenance tips:

- **Dusting:** Gently dust the model regularly with a soft, dry cloth or a soft brush to prevent dust buildup.
- **Avoid Moisture:** Keep the model away from water and high humidity to prevent warping or damage to the

wood.

- **Direct Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause the colors to fade over time.
- **Handling:** Handle the assembled model with care to prevent pieces from detaching.

7. TROUBLESHOOTING

If you encounter any issues during assembly, consider the following:

- **Tight Pieces:** If a piece does not fit easily, do not force it. Refer to the sandpaper icon in your manual and gently sand the edges of the piece until it fits snugly.
- **Loose Connections:** Ensure all interlocking tabs are fully inserted into their corresponding slots.
- **Missing Pieces:** Double-check the packaging and work area. If a piece is genuinely missing, please contact Rowood customer support.
- **Difficulty with Instructions:** Review the icon legend and diagrams carefully. If you are still unsure, the official video (Video 5.1) can provide additional visual guidance.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	6.3 x 6.69 x 0.04 inches (packaging dimensions)
Assembled Dimensions	Approximately 6.3 x 4.3 x 6.6 inches
Item Weight	8.5 ounces
Model Number	TG415
Recommended Age	14 years and up
Number of Pieces	263
Assembly Time	Approximately 1.5 hours
Material	Eco-friendly wood

Image 8.1: Product dimensions and key assembly details for the Sakura Bonsai puzzle.

9. SUPPORT

For any questions, concerns, or assistance with your Rowood Sakura Bonsai 3D Wooden Puzzle, please contact our responsive support team. We are committed to ensuring a hassle-free experience for all our customers.

Manufacturer: Rowood