Hatteker HT-910

Hatteker Men's Electric Foil Shaver HT-910 User Manual

Model: HT-910

1. Introduction

Thank you for choosing the Hatteker Men's Electric Foil Shaver HT-910. This advanced wet and dry electric razor is designed to provide a smooth, comfortable, and precise shaving experience for various facial hair needs, including head shaving for bald men. Featuring a 4-blade floating system, pop-up trimmer, and smart LED display, this cordless and rechargeable shaver is built for convenience and performance. Please read this manual thoroughly before first use to ensure proper operation, maintenance, and safety.



Figure 1: Hatteker HT-910 Electric Foil Shaver and included accessories (charging cable, cleaning brush, protective cap).

2. Product Features

- **4-Blade Floating Electric Foil Shaver:** The innovative 4-blade floating foil shaving system is designed to perfectly fit the contours of your facial and neck areas, providing a smooth and comfortable shaving experience. Stainless steel cutting heads help avoid spots and irritation, meeting skin-friendly shaving needs.



Figure 2: Detail of the 4-blade floating foil system, designed to adapt to facial contours for an efficient shave.

- **Precision Pop-Up Trimmer:** Achieve clean grooming results with the straight precision trimmer located among the foil blades, ideal for precise and detailed cutting of hard-to-reach facial hair. The pop-up trimmer is perfect for trimming sideburns, mustaches, and beards with a simple push to activate.



Figure 3: The integrated pop-up trimmer for precise detailing and the middle trimmer for difficult hairs.

- **Long-lasting & Portable Design:** Equipped with a built-in rechargeable battery, the shaver provides up to 60 minutes of runtime after just 1.5 hours of Type-C charging. Its cordless, lightweight design and included storage bag make it highly suitable for business trips and travel.



Figure 4: Illustration of the powerful built-in battery and convenient Type-C charging port.

- **IPX6 Waterproof & Wet/Dry Shave:** The shaver is fully washable with an IPX6 waterproof rating, allowing for easy cleaning under running tap water. It supports both quick dry shaves and wet shaves with shaving gel or foam, reducing the risk of skin nicks and cuts.



Figure 5: The shaver is fully washable, making cleaning simple and hygienic.

- **Smart LED Display:** The high-definition LED display accurately shows the battery percentage, charging reminder, and cleaning reminder. A long press of the switch button for five seconds activates the travel lock, enhancing convenience and safety.
- **Ergonomic Design:** The shaver features an anti-slip pattern on the switch button for a firm grip. Its smooth textured body resists fingerprints and is easy to clean and store. The discreet luxury gray finish makes it an excellent choice for men's grooming.

3. Setup

1. **Unpacking:** Carefully remove the shaver and all accessories from the packaging. Check for any damage or missing parts.
2. **Initial Charge:** Before first use, fully charge the shaver. Connect the Type-C charging cable to the shaver's charging port and plug the other end into a suitable USB power adapter (not included). The LED display will show the charging status. A full charge takes approximately 1.5 hours.

3. **Protective Cap:** Remove the protective cap from the shaver head before use. Keep the cap for storage and travel.

4. Operating Instructions

4.1 General Shaving

1. **Power On:** Press the power button once to turn on the shaver. The LED display will illuminate, showing the remaining battery life in minutes.
2. **Dry Shaving:** For a quick and convenient shave, ensure your face is clean and dry. Hold the shaver at a right angle to your skin and move it in short, circular motions against the direction of hair growth.
3. **Wet Shaving:** For a smoother, more comfortable shave, apply shaving gel or foam to your face. Use the shaver in the same manner as dry shaving. Rinse the shaver head frequently during wet shaving to prevent clogging.



Figure 6: The shaver is suitable for both wet and dry shaving, offering versatility for your grooming routine.

4. **Contouring:** The floating foil system adapts to the contours of your face and neck. Apply gentle pressure and let the shaver glide over your skin.

5. **Power Off:** Press the power button again to turn off the shaver.

4.2 Using the Pop-Up Trimmer

1. **Activate Trimmer:** With the shaver turned on, push the pop-up trimmer switch located on the back of the shaver upwards to extend the trimmer blade.
2. **Trimming:** Use the pop-up trimmer for precise shaping of sideburns, mustaches, and beards. Hold the trimmer perpendicular to the skin and move it slowly to achieve desired lines.
3. **Retract Trimmer:** Push the pop-up trimmer switch downwards to retract the trimmer blade when finished.

4.3 Travel Lock Function

- To activate the travel lock, press and hold the power button for approximately 5 seconds until a lock icon appears on the LED display. This prevents accidental activation during travel.
- To deactivate the travel lock, press and hold the power button again for approximately 5 seconds until the lock icon disappears.

5. Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the lifespan of your shaver. The Hatteker HT-910 is designed for easy cleaning due to its IPX6 waterproof rating.

1. **Step 1: Remove Blade Cover:** Press the release buttons on the sides of the shaver head and gently lift the blade cover off.
2. **Step 2: Clean with Brush:** Use the provided cleaning brush to remove any loose hair from the blades and the inner chamber of the shaver head.
3. **Step 3: Rinse Shaving Head:** Hold the detached shaving head under running tap water to rinse away remaining hair and debris.
4. **Step 4: Rinse Inner Blades:** If necessary, carefully remove the inner blades and rinse them separately under running water. Allow all parts to air dry completely before reassembling.
5. **Reassembly:** Once dry, carefully place the inner blades back into position and reattach the blade cover until it clicks into place.



Figure 7: Step-by-step guide for cleaning the shaver head and blades under running water.

Important: Always ensure the shaver is turned off before cleaning. Avoid using harsh chemicals or abrasive cleaners on the shaver.

6. Troubleshooting

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is low or depleted. Travel lock is activated.	Charge the shaver fully. Deactivate the travel lock by pressing and holding the power button for 5 seconds.
Poor shaving performance.	Blades are dull or clogged with hair.	Clean the shaver head and blades thoroughly as per Section 5. Consider replacing the shaver head if performance does not improve after cleaning.
Skin irritation after shaving.	Incorrect shaving technique. Skin not prepared properly.	Ensure you are shaving against the direction of hair growth with gentle pressure. Try wet shaving with gel or foam. Ensure skin is clean before shaving.
Shaver makes unusual noise.	Hair caught in blades or internal mechanism.	Clean the shaver head and blades thoroughly. If the noise persists, contact customer support.

7. Specifications

Model Name: HT-910

Brand: Hatteker

Power Source: Battery Powered (1 Lithium Ion battery included)

Charging Time: Approximately 1.5 hours

Runtime: Up to 60 minutes

Waterproof Rating: IPX6 (Whole body washable)

Recommended Uses: Beard, Facial Hair, Head Shaving

Manufacturer: Hatteker

Package Dimensions: 7.83 x 5.2 x 2.64 inches

Item Weight: 11.36 ounces

Country of Origin: China

8. Safety Information

Please adhere to the following safety guidelines to prevent injury or damage to the product:

- Avoid using the shaver while it is charging.
- Clean the shaver after each use by removing the blade cover and rinsing it under tap water.
- Allow the shaver to dry completely before storing it.
- Always follow the instructions in this user manual for safe and optimal operation.
- Keep the shaver out of reach of children.

- Do not disassemble or attempt to repair the shaver yourself. Contact qualified personnel for service.
- Do not immerse the charging cable or power adapter in water.
- Wattage: 5 watts. Ensure your power source is compatible.

9. Warranty and Support

Specific warranty details are not provided in the available product information. For warranty claims, technical support, or any product-related inquiries, please contact Hatteker customer service through the retailer where the product was purchased or refer to the official Hatteker website for contact information.

© 2025 Hatteker. All rights reserved.