topzee JE-32B

TOPZEE Cold Press Juicer Instruction Manual

Model: JE-32B

Introduction

Welcome to the world of fresh, nutritious juicing with your new TOPZEE Cold Press Juicer. This manual provides essential information for the safe and efficient operation, maintenance, and care of your appliance. Designed for efficiency, convenience, and safety, this masticating juicer ensures minimal effort and maximum output for your juicing needs.

Important Safety Information

Please read all instructions carefully before using the juicer. Keep this manual for future reference.

- Always ensure the juicer is properly assembled before operation.
- Do not operate the juicer if any parts are damaged or missing.
- Keep hands and utensils out of the feed chute during operation to prevent injury. Use the food pusher provided.
- The juicer features an automatic safety lock: it will stop working if the cover of the feed chute is opened. This ensures safety, especially for children and the elderly.
- Unplug the juicer from the power outlet before cleaning or when not in use.
- Do not immerse the motor base in water or any other liquid.
- This appliance is for household use only.

Product Overview

Familiarize yourself with the components of your TOPZEE Cold Press Juicer.



Figure 1: Fully assembled TOPZEE Cold Press Juicer, demonstrating its operation with fruits in the feed chute and fresh juice flowing into a

glass.

- **Feed Chute:** Large 5.4-inch opening for whole fruits and vegetables.
- **Spiral Auger:** Innovative design for efficient pulp separation and juice extraction.
- **Dual-Layer Filter:** Detachable strainers for twice-filtering, reducing clogging and residue.
- **Motor Base:** Houses the motor and control buttons.
- **Pulp Container:** Collects separated pulp.
- **Juice Container:** Collects extracted juice.
- **Food Pusher:** For safely guiding produce into the chute.

Setup & Assembly

The TOPZEE Cold Press Juicer is designed for quick and easy assembly, typically in three simple steps.

1. Place the motor base on a stable, flat surface.
2. Align and attach the juicing bowl assembly (which includes the spiral auger and dual-layer filter) onto the motor base. Ensure it clicks securely into place.
3. Place the feed chute cover onto the juicing bowl assembly, ensuring it is properly locked. The safety lock mechanism will prevent operation if not correctly aligned.
4. Position the pulp container and juice container under their respective spouts.



Figure 2: Simplified assembly of the TOPZEE juicer, highlighting its user-friendly design with only three main parts.

Operating Instructions

Follow these steps for optimal juicing results:

1. Ensure the juicer is assembled correctly and the juice and pulp containers are in place.
2. Plug the power cord into a suitable electrical outlet.
3. Prepare your fruits and vegetables. Thanks to the 5.4-inch wide feed chute, most whole fruits and vegetables can be juiced without pre-cutting. For very large items or fibrous vegetables, you may cut them into smaller pieces if necessary.
4. Turn the juicer ON.
5. Slowly feed the produce into the feed chute. Use the food pusher to gently guide the produce down. Do not force produce into the chute.
6. The innovative spiral auger will masticate the produce, separating juice from pulp.
7. The dual-layer filter ensures a smooth, pure juice by filtering twice.
8. Once juicing is complete, turn the juicer OFF and unplug it.



Figure 3: The 5.4-inch wide feed chute allows for whole fruit juicing, minimizing preparation time.



Figure 4: The innovative spiral auger maximizes juice extraction and minimizes waste through a multi-stage process.

Maintenance & Cleaning

Regular cleaning ensures the longevity and optimal performance of your juicer.

- **Disassembly:** Press the release button to detach the juicing body from the motor base. Disassemble the feed chute cover, spiral auger, and dual-layer filter.
- **Washing:** All detachable parts are dishwasher safe, making cleanup effortless. For manual cleaning, rinse all parts under running water. Use the included cleaning brush to remove any stubborn pulp residue from the filter.
- **Motor Base:** Wipe the motor base with a damp cloth. Do not submerge it in water.
- **Drying & Storage:** Ensure all parts are completely dry before reassembling or storing the juicer. Store in a clean, dry place.



Figure 5: Easy cleaning options: all detachable parts are dishwasher safe, and a bonus cleaning brush is included for thorough manual cleaning.



Figure 6: The detachable dual-layer filter ensures silky smooth juice and is easy to clean, preventing clogging.

Troubleshooting

If you encounter any issues, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Juicer does not turn on.	Not properly assembled or plugged in. Safety lock engaged.	Ensure all parts are securely locked into place and the power cord is firmly plugged in. Check the feed chute cover is closed correctly.
Juicer stops during operation.	Overload or blockage. Feed chute cover opened.	Turn off and unplug. Clear any blockage. If the feed chute cover was opened, close it securely. Use the reverse function if needed.
Excessive pulp in juice.	Filter clogged or produce too soft.	Clean the dual-layer filter thoroughly. For very soft produce, consider mixing with firmer items.

Problem	Possible Cause	Solution
Produce is not juicing effectively.	Produce too large or too much at once.	Cut produce into smaller pieces if necessary. Feed produce slowly and gently.



Figure 7: The Anti-Blocking Reverse Function helps clear obstructions for uninterrupted juicing.

Specifications

Brand: topzee

Model Name: JE-32B

Color: Black

Special Features: Whole Fruit Processing, Reverse Function & Safety Design

Product Dimensions: 17.24"D x 7.59"W x 13.66"H

Finish Type: Brushed

Recommended Uses: Citrus Fruits, Fruits, Vegetables

Blade Material: Stainless Steel

Dishwasher Safe Parts: Yes

Item Weight: 9.81 pounds

UPC: 860013285173

ASIN: B0DJ2P6QMG

First Available: December 26, 2024

Warranty & Customer Support

For any questions, concerns, or warranty claims, please contact TOPZEE customer support.
Email: Support@topzee.com

Figure 8: Contact information for TOPZEE Customer Support.

© 2024 TOPZEE. All rights reserved.