

AWEI T36

AWEI T36 Bluetooth Earbuds User Manual

Model: T36

Wireless Earbuds with Big Bass Stereo Sound and IPX4 Waterproofing

INTRODUCTION

Thank you for choosing the AWEI T36 Bluetooth Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your new earbuds. Please read this manual carefully before use to ensure optimal performance and longevity of your device.

Package Contents

- AWEI T36 Wireless Earbuds (Left and Right)
- Charging Case
- USB-C Charging Cable
- Eartips (various sizes)
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your AWEI T36 earbuds and charging case.



Image: AWEI T36 earbuds securely placed inside their open charging case, showcasing the sleek black design of both the earbuds and the case interior.

Earbud Components

- **Touch Control Area:** For managing music playback, calls, and voice assistant.
- **Microphone:** For clear call performance.
- **Charging Contacts:** Located at the bottom of each earbud.
- **LED Indicator:** Shows pairing status and battery level.

Charging Case Components

- **Earbud Charging Slots:** Securely hold and charge the earbuds.
- **USB-C Charging Port:** For charging the case.
- **LED Indicator:** Displays charging status of the case.

SETUP

1. Charging the Earbuds and Case

Before first use, fully charge both the earbuds and the charging case.

1. Place the earbuds into the charging case, ensuring they are correctly seated. The earbuds' LED indicators will light up to show they are charging.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer's USB port.
3. The charging case LED indicator will show charging progress. A full charge takes approximately 1.5 hours for the case.



Image: AWEI T36 earbuds and their charging case resting on a circular charging pad, illustrating the product's battery life and charging capabilities. The image indicates a 320mAh charging case, 4-5 hours playtime, and 1.5 hours charging time.

Note: The product specifications indicate 7 hours of continuous use per charge for earbuds and 35 hours of playback with the charging case.

2. Pairing with Your Device

The earbuds support Bluetooth 5.3 for a stable and fast connection.

1. First-time Pairing:

- Open the charging case. The earbuds will automatically power on and enter pairing mode.
- On your device (smartphone, tablet, laptop), enable Bluetooth.
- Search for "AWEI T36" in the list of available Bluetooth devices and select it to connect.
- Once connected, you will hear a confirmation tone, and the earbud LED indicators will turn off or flash slowly.

2. Subsequent Pairing:

- Once paired, the earbuds will automatically connect to the last paired device when taken out of the charging case, provided Bluetooth is enabled on the device.



Image: A smartphone displaying a game, with the AWEI T36 earbuds and their charging case in the foreground, illustrating the Bluetooth connection. The image highlights "Bluetooth 5.1 Faster & More Stable" (*Note: Product specifications state Bluetooth 5.3 for this model, which offers improved performance.*)

Both Earbuds are Hosts Both Earbuds are Main Engines

The both earbuds are equipped with Airoha chips, which can be used in series or separately



Image: Two AWEI T36 earbuds, one in its open charging case and one outside, demonstrating that both earbuds can function independently as "hosts" or "main engines" for flexible use.

OPERATING INSTRUCTIONS

The AWEI T36 earbuds feature smart touch controls for easy operation.

One-Touch Operation Mini & Handy

By tapping the earbuds, you can easily switch music, adjust volume, answer/ring off the phone, etc.



Image: A visual guide to the one-touch operation of the AWEI T36 earbuds, detailing touch commands for music playback (pause/play, previous/next song) and call management (answer/reject, activate voice assistant).

Music Playback

- **Play/Pause:** Short tap on either earbud.
- **Next Song:** Tap the right earbud twice.
- **Previous Song:** Tap the left earbud twice.
- **Volume Control:** (Specific gesture not detailed in image, typically long press or multiple taps. Refer to device settings if not working as expected.)

Call Management

- **Answer Call:** Short tap on either earbud.
- **Reject Call:** Tap and hold either earbud for 2 seconds.
- **End Call:** Short tap on either earbud during a call.

Voice Assistant

- **Activate Voice Assistant (Siri/Google Assistant):** Tap either earbud three times.

Power On/Off

- **Power On:** Earbuds automatically power on when removed from the charging case.
- **Power Off:** Earbuds automatically power off when placed back into the charging case and the lid is closed.

MAINTENANCE

Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Use a cotton swab lightly dampened with isopropyl alcohol to clean the charging contacts on both the earbuds and inside the case.
- Do not use abrasive cleaners or immerse the earbuds or case in water.

Storage

- Store the earbuds in their charging case when not in use to protect them and keep them charged.
- Avoid storing the device in extreme temperatures (hot or cold) or in highly humid environments.

Battery Care

- To preserve battery life, charge the earbuds and case regularly, even if not used frequently.
- Avoid completely draining the battery before recharging.

IPX4 Waterproofness For Unfettered Exercises

Effectively prevent the erosion from sweat & rain in entire exercise process



Image: AWEI T36 earbuds and their charging case with water droplets on them, emphasizing their IPX4 waterproof rating, which protects against sweat and light rain during exercise.

TROUBLESHOOTING

If you encounter any issues with your AWEI T36 earbuds, please refer to the following common solutions:

- **Earbuds not pairing with device:**

- Ensure the earbuds are fully charged.
- Make sure Bluetooth is enabled on your device and the earbuds are within range (up to 10 meters).
- Forget "AWEI T36" from your device's Bluetooth list and try pairing again.
- Place both earbuds back into the charging case, close the lid, wait a few seconds, then open the lid to reset them.

- **Only one earbud working:**

- Ensure both earbuds are charged.
- Place both earbuds back into the charging case, close the lid, then open it again. This often re-syncs them.
- Clean the charging contacts on both earbuds and inside the case.

- **Earbuds not charging:**
 - Check if the charging cable is securely connected to both the case and the power source.
 - Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
 - Try a different USB-C cable or power adapter.
- **Low volume or poor sound quality:**
 - Adjust the volume on both your device and the earbuds.
 - Ensure the eartips are properly seated in your ears to create a good seal. Try different sized eartips.
 - Clean any earwax or debris from the earbud speaker mesh.

SPECIFICATIONS

Feature	Description
Model Name	T36
Brand	AWEI
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	Up to 10 meters (33 feet)
Earbud Battery Life	Up to 7 hours (single charge)
Total Playtime (with case)	Up to 35 hours
Charging Time (Case)	Approx. 1.5 hours
Water Resistance	IPX4 (Sweat and splash proof)
Control Type	Touch Control
Earpiece Shape	In-Ear
Material	Silicone (Eartips)
Included Components	Earbuds, Charging Case, USB-C Cable, Eartips, User Manual

WARRANTY AND SUPPORT

AWEI products are manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or customer service, please refer to the warranty card included in your package or visit the official AWEI website.

For further assistance, please contact AWEI customer support with your product model number (T36) and purchase details.

