

[Manuals.plus](#) /

› [EUGAD](#) /

› EUGAD 0246WY Bathroom Cabinet Under Washbasin Instruction Manual

EUGAD 0246WY

EUGAD 0246WY Bathroom Cabinet Under Washbasin Instruction Manual

Model: 0246WY

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your EUGAD 0246WY Bathroom Cabinet Under Washbasin. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and care will ensure the longevity and functionality of your cabinet.



Image: The EUGAD 0246WY Bathroom Cabinet installed under a washbasin, showcasing its design and integration into a bathroom environment.

SAFETY INSTRUCTIONS

- Always follow the assembly instructions step-by-step.
- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Ensure all screws and fasteners are securely tightened before using the cabinet. Do not overtighten.
- Do not stand or climb on the cabinet.
- Place the cabinet on a flat, stable surface to prevent tipping.
- If any parts are missing or damaged, do not proceed with assembly. Contact customer support immediately.

PACKAGE CONTENTS

Before assembly, verify that all components are present and undamaged. The package should include:

- Cabinet panels (top, bottom, sides, back, drawer components, door panels)
- Hardware kit (screws, dowels, hinges, drawer runners, handles, magnetic closures, adjustable foot pads)

- Assembly instructions (this manual)

Refer to the detailed parts list provided in the separate assembly guide for specific quantities and identification.

SETUP AND ASSEMBLY

Assembly of the EUGAD 0246WY cabinet is designed to be straightforward. It is recommended to have two people for assembly. A Phillips head screwdriver and a hammer may be required (not included).

1. **Prepare the Area:** Clear a spacious, clean, and flat area for assembly. Lay down a blanket or cardboard to protect the cabinet parts and your floor.
2. **Identify Parts:** Unpack all components and identify them using the provided parts list.
3. **Assemble the Frame:** Connect the side panels to the bottom and top panels using the designated hardware. Ensure the back panel groove is correctly aligned.
4. **Install Drawer Runners:** Attach the smooth runners to the cabinet side panels and the drawer components as per the instructions.
5. **Assemble the Drawer:** Construct the drawer box and install the drawer handle.
6. **Attach Doors:** Secure the metal hinges to the door panels and then attach the doors to the cabinet frame. Install the linear handles and magnetic closures.
7. **Insert Adjustable Shelf:** The internal shelf can be adjusted to different heights or removed entirely to accommodate various item sizes.
8. **Install Adjustable Foot Pads:** Screw the adjustable foot pads into the base of the cabinet. These allow for minor height adjustments to ensure stability on uneven floors.
9. **Positioning:** Carefully move the assembled cabinet to its desired location under the washbasin. The cabinet features a siphon cutout (approximately 15x20cm WxD) to fit around most standard sink plumbing. Verify the dimensions of your sink's siphon and the available space before final placement.



Image: Detailed dimensional drawing of the cabinet, including overall size, drawer dimensions, and internal shelf space, along with the siphon cutout at the back.



Image: Close-up views highlighting key hardware components: sturdy metal hinges for the doors, smooth runners for the drawer, and sleek linear handles for both the drawer and doors.

OPERATING INSTRUCTIONS (USAGE)

The EUGAD 0246WY cabinet is designed to provide organized storage in your bathroom.

- **Drawer Usage:** The top drawer offers convenient storage for smaller items such as toiletries, cosmetics, or accessories. It features two internal compartments for better organization.
- **Cabinet Storage:** The space behind the grid doors is divided by an adjustable shelf, creating two compartments. This allows for flexible storage of taller bottles or stacked items. The grid doors protect contents from dust while providing ventilation.
- **Adjustable Shelf:** To adjust the shelf height, simply remove the shelf and reposition the support pins into the desired holes. Ensure the shelf is level and securely seated before placing items on it.



Image: The top drawer of the cabinet pulled open, revealing internal compartments suitable for organizing small bathroom essentials.

Removable Shelves



Image: A comparison showing the cabinet's interior with the adjustable shelf in place and with the shelf removed, demonstrating flexible storage options.

MAINTENANCE

To keep your EUGAD 0246WY cabinet in optimal condition, follow these maintenance guidelines:

- **Cleaning:** The melamine-plated surface is water-repellent and easy to clean. Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Spills:** Promptly wipe up any water spills to prevent moisture damage, especially around edges and seams.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary, but do not overtighten.
- **Ventilation:** The grid doors provide ventilation, but ensure the bathroom is adequately ventilated to prevent excessive humidity buildup inside the cabinet.

Magnetic Doors



Water-repellent and Easy-to-clean Material



Adjustable Foot Pads



Image: Visual representation of the cabinet's magnetic door closure, the water-repellent and easy-to-clean surface material, and the adjustable foot pads for leveling.

TROUBLESHOOTING

If you encounter any issues with your EUGAD 0246WY cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Uneven floor; loose connections.	Adjust the foot pads at the bottom of the cabinet until stable. Check and tighten all assembly screws.
Drawer does not slide smoothly.	Improperly installed runners; obstruction.	Ensure drawer runners are correctly aligned and securely attached. Check for any objects obstructing the drawer path.
Doors do not close properly or are misaligned.	Hinges not adjusted; magnetic closure misaligned.	Adjust the screws on the hinges to align the doors. Ensure the magnetic closure components are correctly positioned.
Missing parts.	Packaging error.	Do not proceed with assembly. Contact EUGAD customer support with your purchase details.

Problem	Possible Cause	Solution
---------	----------------	----------

SPECIFICATIONS

Brand	EUGAD
Model Number	0246WY (Meuble sous Lavabo)
Color	Light Oak + Black
Material	Engineered Wood, Metal
Product Dimensions (D x W x H)	11.81" x 23.62" x 23.62" (30 x 60 x 60 cm)
Item Weight	13.8 Kilograms
Mounting Type	Floor Mount
Number of Drawers	1
Door Style	Shutter (Grid Doors)
Required Assembly	Yes

WARRANTY INFORMATION

EUGAD products are manufactured to high-quality standards. For specific warranty details regarding your 0246WY Bathroom Cabinet, please refer to the warranty card included with your purchase or visit the official EUGAD website. Typically, warranties cover manufacturing defects under normal use conditions.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact EUGAD customer support:

- **Website:** Visit the official EUGAD website for FAQs and contact forms.
- **Email:** Refer to your purchase documentation for customer service email addresses.
- **Phone:** Check the EUGAD website for regional customer service phone numbers.

Please have your model number (0246WY) and purchase information ready when contacting support.