

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- > [EUGAD](#) /
- > [EUGAD Under-Sink Bathroom Cabinet Model 0246WY Instruction Manual](#)

EUGAD 0246WY

EUGAD Under-Sink Bathroom Cabinet Model 0246WY Instruction Manual

Model: 0246WY | Dimensions: 60x30x60 cm | Color: Light Oak



1. INTRODUCTION

Thank you for choosing the EUGAD Under-Sink Bathroom Cabinet. This manual provides essential information for the safe assembly, proper use, and maintenance of your new cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

1.1 Product Overview

The EUGAD Under-Sink Bathroom Cabinet is designed to provide practical storage solutions for your bathroom. It features a robust construction from high-quality E1 MDF panels, ensuring durability and a strong load-bearing capacity. The melamine-coated surface offers water resistance and wear resistance for long-lasting use. The cabinet includes a spacious drawer, two louvered doors, and an adjustable shelf, accommodating various bathroom essentials. A specific siphon cutout is integrated to fit most standard washbasins.



Figure 1.1: The EUGAD Under-Sink Bathroom Cabinet in a typical bathroom environment, showcasing its design and functionality.

1.2 Safety Information

Important Safety Notice:

- Do not use this product in areas with excessively high humidity or in direct contact with standing water.
- Ensure all connections are securely tightened during assembly and periodically check for stability.
- Keep small parts and packaging materials away from children to prevent choking hazards.

2. COMPONENTS AND PARTS LIST

Before assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- MDF Panels (various sizes for cabinet body, drawer, doors, and shelf)
- Metal Hinges (for louvered doors)
- Smooth Drawer Runners

- Linear Handles (for drawer and doors)
- Magnetic Door Closures
- Adjustable Foot Pads
- Assembly Hardware (screws, dowels, cam locks, etc.)



Figure 2.1: Exploded view and dimensions of the cabinet components. This image illustrates the various parts and their measurements, including the siphon cutout and drawer dimensions.

3. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is designed to be straightforward with the provided illustrated instructions and hardware. It is recommended to assemble the cabinet on a soft, clean surface to prevent scratches.

1. **Unpack and Identify:** Carefully unpack all components and lay them out. Compare them with the parts list to ensure everything is present.
2. **Assemble the Frame:** Connect the side panels to the base and top panels using the provided hardware. Ensure all connections are firm.
3. **Install Drawer Runners:** Attach the smooth runners to the designated side panels for the drawer.
4. **Assemble the Drawer:** Construct the drawer using its individual panels and attach the linear handle. Insert

the drawer into the installed runners.

5. **Attach Back Panel:** Secure the back panel, ensuring the siphon cutout aligns with your plumbing. The siphon cutout measures 15x20 cm (Width x Depth). Please verify your sink's siphon dimensions and available space beforehand.
6. **Install Doors:** Attach the louvered doors to the cabinet frame using the metal hinges. Ensure they open and close smoothly.
7. **Attach Door Handles and Magnetic Closures:** Secure the linear handles to the doors and install the magnetic closures to ensure the doors remain shut.
8. **Insert Adjustable Shelf:** Place the adjustable shelf into the desired position within the cabinet. The shelf can be adjusted up or down by 3.2 cm or removed entirely for flexible storage.
9. **Attach Adjustable Foot Pads:** Screw the adjustable foot pads onto the bottom of the cabinet legs. Adjust them to level the cabinet on uneven surfaces.

Removable Shelves



Figure 3.1: Illustration of the adjustable shelf feature. The left side shows the shelf in place, while the right side shows it removed, allowing for taller items.



Figure 3.2: Detail of the drawer in use, demonstrating its capacity and how it fits under a washbasin.

4. OPERATING AND USAGE

The EUGAD Under-Sink Bathroom Cabinet is designed for efficient storage and organization of bathroom items.

- **Drawer:** Utilize the large drawer for storing smaller items, toiletries, or frequently accessed essentials.
- **Louvered Doors:** The two louvered doors protect the cabinet's interior from dust and moisture while providing good ventilation. The magnetic closures ensure the doors stay securely shut.
- **Adjustable Shelf:** The internal shelf can be adjusted to three different heights or removed completely to accommodate items of varying sizes, such as tall bottles or stacked towels.
- **Siphon Cutout:** The integrated siphon cutout allows the cabinet to fit neatly under most standard washbasins, maximizing space utilization.

5. CARE AND MAINTENANCE

Proper care will extend the life and maintain the appearance of your EUGAD cabinet.

- **Cleaning:** The melamine-coated surface is water-repellent and easy to clean. Wipe with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals.
- **Moisture:** While the surface is water-resistant, avoid prolonged exposure to excessive moisture or standing water. Promptly wipe away any spills.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight and secure. Tighten if necessary.
- **Ventilation:** The louvered doors aid in ventilation, but ensure the bathroom is adequately ventilated to prevent excessive humidity buildup.



Figure 5.1: The water-repellent surface allows for easy cleaning and protection against splashes.

6. TROUBLESHOOTING

If you encounter any issues with your cabinet, please refer to the following common problems and solutions:

Problem: Doors do not close properly or hinges feel loose.

Solution: Check the hinge screws and tighten them if they are loose. Ensure the magnetic closures are correctly aligned and securely attached. Adjust the cabinet's foot pads to ensure it is level, as an uneven surface can affect door alignment.

Problem: Drawer does not slide smoothly or gets stuck.

Solution: Verify that the drawer runners are correctly installed and free from obstructions. Ensure all screws securing the runners are tight. Check if the drawer itself is assembled squarely. Avoid overloading the drawer.

Problem: Cabinet feels wobbly or unstable.

Solution: Ensure all assembly hardware (screws, cam locks) are fully tightened. Adjust the foot pads on the bottom of the cabinet to stabilize it on uneven flooring. If possible, place the cabinet against a wall for added stability.

7. SPECIFICATIONS

Feature	Detail
Brand	EUGAD
Model Number	0246WY
Color	Light Oak + Black
Product Dimensions (L x W x H)	60 x 30 x 60 cm
Product Weight	13.8 kg
Material	E1 MDF Panels, Melamine Coating, Carbon Steel

Special Features	Adjustable Divider/Shelf, 2 Louvered Doors, Siphon Cutout
Mounting Type	Freestanding
Door Style	Louvered
Included Components	Assembly hardware kit
Siphon Cutout Dimensions	15 x 20 cm (Width x Depth)

8. WARRANTY INFORMATION

EUGAD products are manufactured to high-quality standards. Specific warranty details may vary by region and retailer. Please refer to your purchase receipt or contact your point of sale for information regarding warranty coverage. Generally, the warranty covers manufacturing defects under normal use.

Note: No explicit warranty period or terms were provided with the product information.

9. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact EUGAD customer service.

- **Online Support:** Visit the official EUGAD store for FAQs and contact options: [EUGAD Store on Amazon](#)
- **Email/Phone:** Refer to the contact information provided with your purchase documentation.

