Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

esonstyle S8

esonstyle S8 Sleep Earbuds User Manual

Model: S8 | Brand: esonstyle

Introduction

Thank you for choosing the esonstyle S8 Sleep Earbuds. These earbuds are designed to provide a comfortable and immersive audio experience, especially for side sleepers, while effectively reducing external noise. Featuring advanced Bluetooth 5.3 technology and a compact, ergonomic design, the S8 earbuds are perfect for sleep, relaxation, and daily activities. Please read this manual carefully to ensure proper use and maintenance of your new earbuds.

Product Overview

Package Contents

- esonstyle S8 Sleep Earbuds (Left and Right)
- Wireless Charging Case
- USB-C Charging Cable
- User Manual

Key Features

- **Invisible Design for Sleep:** Provides a comfortable and snug seal in the ear canal, effectively blocking external noise for a peaceful sleep environment.
- **Seamless Bluetooth 5.3 Connectivity:** Utilizes advanced Bluetooth 5.3 technology for a fast, stable, and lag-free connection with various smart devices.
- **IPX6 Waterproof Rating:** Offers excellent protection against water and sweat, suitable for sleeping, running, exercising, and other activities.
- **Long-Lasting Battery:** Up to 4 hours of music playback on a single charge, with the 350 mAh charging case providing an additional 20 hours of use.
- **Ergonomic Design for Side Sleepers:** Made from high-quality soft silicone, these earbuds are slim and compact, ensuring a comfortable fit without pressure, even when sleeping on your side.
- **Touch Control:** Intuitive touch controls for managing playback and calls.
- **Built-in Microphone:** Allows for clear hands-free calls.

Setup

1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case. Place the earbuds into the charging case. Connect the USB-C charging cable to the case and a power source. The indicator lights on the case will show the charging status.



Image: esonstyle S8 Sleep Earbuds in their charging case, illustrating the 4 hours of playback time for the earbuds and an additional 20 hours provided by the charging case, totaling 24 hours.

A full charge for the case typically takes about 1.5 hours. The earbuds provide up to 4 hours of playback, and the charging case extends this to 24 hours.

2. Bluetooth Pairing

1. Ensure the earbuds are charged and inside the charging case.
2. Open the charging case. The earbuds will automatically enter pairing mode.
3. On your device (smartphone, tablet, laptop), go to Bluetooth settings and turn Bluetooth on.
4. Search for "esonstyle S8" (or similar name) in the list of available devices and select it to connect.
5. Once connected, you will hear a confirmation tone, and the earbuds will be ready for use.



Image: A detailed close-up of an esonstyle S8 Sleep Earbud, highlighting its internal components and the Bluetooth 5.3 chip, emphasizing fast and stable wireless transmission.

3. Wearing the Earbuds

The esonstyle S8 earbuds are designed for maximum comfort, especially for side sleepers. Follow these steps for optimal fit:

1. Identify the Left (L) and Right (R) earbuds.
2. Gently insert the earbud into your ear canal.
3. Adjust the earbud so it sits snugly and comfortably, ensuring the soft silicone fin is tucked into your ear's concha for stability.



Image: A visual guide demonstrating the correct way to insert the esonstyle S8 Sleep Earbuds into the ear and how to tuck them for a secure and comfortable fit.

The low-profile design ensures they do not cause discomfort when lying on your side.

Operating Instructions

The esonstyle S8 earbuds feature intuitive touch controls on each earbud.

Music Playback

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the Right earbud.
- **Previous Track:** Double tap on the Left earbud.
- **Volume Up:** Triple tap on the Right earbud.
- **Volume Down:** Triple tap on the Left earbud.

Call Management

- **Answer/End Call:** Single tap on either earbud.
- **Reject Call:** Press and hold either earbud for 2 seconds.

Voice Assistant

- **Activate Voice Assistant:** Press and hold either earbud for 3 seconds.

Your browser does not support the video tag.

Video: An official product video demonstrating the comfort and suitability of esonstyle S8 Sleep Earbuds for side sleepers, highlighting their compact design and noise reduction capabilities for a peaceful night's rest.

Maintenance

To ensure the longevity and optimal performance of your esonstyle S8 Sleep Earbuds, follow these maintenance guidelines:

- **Cleaning:** Regularly wipe the earbuds and charging case with a soft, dry, lint-free cloth. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds are IPX6 waterproof, meaning they are resistant to strong jets of water and sweat. However, they are not designed for submersion in water. Avoid prolonged exposure to water.
- **Storage:** When not in use, store the earbuds in their charging case to protect them from dust and damage. Store in a cool, dry place away from extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly, even if not in constant use.



Image: A person exercising, demonstrating the IPX6 waterproof rating of the esonstyle S8 Sleep Earbuds, indicating their resistance to sweat and rain.

Troubleshooting

If you encounter any issues with your esonstyle S8 Sleep Earbuds, please refer to the following common solutions:

Problem	Possible Solution
Earbuds not pairing/connecting.	◦ Ensure earbuds are charged and in pairing mode (open case). ◦ Turn off and on Bluetooth on your device. ◦ Forget "esonstyle S8" from your device's Bluetooth list and try pairing again. ◦ Ensure earbuds are within the 15mm maximum range of your device.

Problem	Possible Solution
No sound or low volume.	◦ Check volume levels on both earbuds and your connected device. ◦ Ensure earbuds are properly seated in your ears. ◦ Reconnect the earbuds to your device.
Earbuds not charging.	◦ Ensure the charging cable is securely connected to both the case and the power source. ◦ Check if the charging contacts on the earbuds and inside the case are clean and free of debris. ◦ Try a different USB-C cable or power adapter.
Sound cutting in and out.	◦ Move closer to your connected device to reduce interference. ◦ Avoid physical obstructions between the earbuds and your device. ◦ Ensure no other devices are interfering with the Bluetooth signal.

Specifications

Feature	Detail
Brand	esonstyle
Model Name	S8
Color	Black
Ear Placement	In-Ear
Form Factor	In-Ear
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth 5.3
Noise Control	Passive Noise Cancellation
Impedance	50 Ohm
Frequency Range	20 Hz - 20,000 Hz
Water Resistance Level	IPX6 (Waterproof)
Product Weight	58 Grams
Product Dimensions	2.2 x 1.4 x 1.5 cm
Battery Type	Lithium Polymer (2 required, included)
Average Battery Life (Earbuds)	4 Hours

Feature	Detail
Total Playback Time (with Case)	24 Hours
Charging Time	1.5 Hours
Control Type	Touch Control
Compatible Devices	Tablets, Laptops, Desktop Computers, Mobile Phones
Specific Product Uses	Sleeping, Fitness, Entertainment
Included Components	User Manual, Earbuds, Wireless Charger, Wireless Charging Case

Warranty and Support

esonstyle products are manufactured to the highest quality standards. For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official esonstyle website. Keep your purchase receipt as proof of purchase for any warranty claims.
For further assistance, you may also contact the retailer where you purchased the product.

© 2024 esonstyle. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJ2YQ6DM

More documents and user manuals: **https://manuals.plus/**