

[Manuals.plus](#) /

› [VECELO](#) /

› VECELO 62-Inch TV Stand with Power Outlets User Manual

VECELO KHD-TV01-BRN-160-UP-BC071

VECELO 62-Inch TV Stand with Power Outlets User Manual

Model: KHD-TV01-BRN-160-UP-BC071

Brand: VECELO

1. INTRODUCTION

Thank you for choosing the VECELO TV Stand with Power Outlets. This media entertainment center is designed to provide a stylish and functional solution for your home entertainment needs. Featuring a chic vintage style, practical open storage, and an integrated charging station, it is suitable for televisions up to 75 inches. This manual provides essential information for safe assembly, operation, and maintenance of your new TV stand.

2. IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Do not overload shelves:** Ensure the tabletop and shelves are not overloaded beyond their stated weight capacities to prevent tipping or collapse. The tabletop supports up to 200 lbs, and open shelves support up to 68 lbs.
- **Secure all parts:** Ensure all parts and screws are firmly attached before use. Regularly check connections for tightness.
- **Small objects:** Be cautious of small objects near open shelves, especially if children or pets are present.
- **Electrical components:** Keep electrical components (power strip) dry and away from heat sources. Do not expose to liquids.
- **Ventilation:** The open design benefits heat dissipation for electronics. Do not block ventilation areas.
- **Placement:** Place the TV stand on a level, stable surface. Use the adjustable foot pads to ensure stability on uneven floors.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer service.

- 1 x VECELO TV Stand (disassembled components)
- 1 x Tool Kit (including necessary hardware)
- 1 x Instructions Manual



Figure 3.1: Exploded view and dimensions of the TV stand components.

4. ASSEMBLY INSTRUCTIONS

Assembly of the VECELO TV Stand is designed to be straightforward. All parts are clearly labeled, and the included instructions guide you through each step.

1. **Prepare the Area:** Clear a spacious, clean area for assembly. Lay out all parts and hardware, matching them to the labels in the instruction guide.
2. **Follow Step-by-Step Guide:** Refer to the detailed assembly instructions provided in the package. Each step will illustrate which parts to connect and which hardware to use.

3. **Tighten Connections:** Ensure all screws and fasteners are securely tightened. Do not overtighten to avoid damaging the material.
4. **Install Adjustable Feet:** Attach the adjustable foot pads to the bottom of the stand. These can be adjusted to stabilize the stand on uneven surfaces.
5. **Final Check:** Once assembled, gently shake the stand to ensure it is stable and all connections are secure before placing any items on it.



Figure 4.1: Assembled TV stand ready for use.

5. OPERATING INSTRUCTIONS

The VECELO TV Stand is designed for ease of use, featuring open storage and a convenient built-in power station.

5.1 Using the Power Outlets / Charging Station

Your TV stand is equipped with a power strip featuring 4 AC outlets (125V/12A) and 5 USB charging ports (5V/2A). This

allows you to power your TV, game consoles, sound systems, and other electronic devices directly from the stand.

- **Connect to Wall Outlet:** Plug the power cord of the TV stand into a standard wall electrical outlet.
- **Plug in Devices:** Connect your TV, media players, gaming consoles, and other devices to the AC outlets. Use the USB ports to charge your smartphones, tablets, or other USB-powered devices.
- **Cable Management:** Utilize the open design to manage cables, ensuring they are not tangled or obstructing the shelves.



Figure 5.1: Integrated power outlets and USB charging ports.

5.2 Utilizing Open Storage Shelves

The 3-tier open storage shelves provide ample space for media devices, books, decorative items, and more. The open design promotes air circulation, which is beneficial for heat dissipation from electronic components, preventing overheating.



Figure 5.2: Open storage shelves for organization and heat dissipation.

6. MAINTENANCE

Proper care will ensure the longevity and appearance of your VECALO TV Stand.

- **Cleaning:** Wipe with a dry cloth for general dusting. For more stubborn marks, wipe with a damp cloth and immediately dry with a clean, soft cloth. Avoid harsh chemicals or abrasive cleaners.
- **Spills:** Immediately wipe up any spills to prevent damage to the engineered wood surfaces.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.



Figure 6.1: Premium MDF board surface, easy to clean.

7. TROUBLESHOOTING

If you encounter any issues with your VECELO TV Stand, refer to the following common solutions:

- **Stand is Wobbly:**

Solution: Ensure the stand is placed on a level surface. Adjust the individual foot pads at the bottom of the stand until it is stable. Check that all assembly screws are tightened.

- **Power Outlets Not Working:**

Solution: Verify that the TV stand's main power cord is securely plugged into a functional wall outlet. Check if the wall outlet itself is receiving power (e.g., by plugging in another device). Ensure devices are properly plugged into the power strip.

- **Missing Parts During Assembly:**

Solution: Double-check the packaging and all contents against the parts list in the instruction manual. If parts are genuinely missing, contact VECELO customer service for assistance.

8. SPECIFICATIONS

Feature	Detail
Model Number	KHD-TV01-BRN-160-UP-BC071
Product Dimensions (L x W x H)	62.99 x 16.22 x 15.74 inches
Item Weight	35.3 pounds
Material	Engineered Wood, Metal
Number of Shelves	3
Tabletop Weight Capacity	180 lbs
Open Shelves Weight Capacity	68 lbs
Power Outlets	4 AC Outlets (125V/12A)
USB Charging Ports	5 USB Ports (5V/2A)

Feature	Detail
Power Cord Length	6.5 FT
Color	Brown
Care Instructions	Wipe with Dry Cloth, Wipe with Damp Cloth
Country of Origin	China
UPC	840408945080

9. WARRANTY AND SUPPORT

VECELO is committed to providing high-quality products and customer satisfaction. While specific warranty details are not provided in this manual, if you have any questions, concerns, or require assistance with your TV stand, please do not hesitate to contact our customer service team.

Please have your model number (KHD-TV01-BRN-160-UP-BC071) and purchase information ready when contacting support to ensure a quicker resolution.

For further assistance, please refer to the contact information provided on your purchase receipt or the VECELO official website.

© 2025 VECELO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DJ31RPST>

More documents and user manuals: <https://manuals.plus/>