ZZB WP-03B

ZZB WP-03B Portable Bluetooth Speaker User Manual

Model: WP-03B | Brand: ZZB

INTRODUCTION

Welcome to your new ZZB WP-03B Portable Bluetooth Speaker. This manual provides detailed instructions for setup, operation, and maintenance to ensure you get the best experience from your device. The speaker delivers powerful, balanced stereo sound with deep bass, features TWS (True Wireless Stereo) functionality, IPX5 water resistance, and integrated lights for an enhanced audio-visual experience. Its compact design and long 12-hour playtime make it ideal for various indoor and outdoor activities.

WHAT'S IN THE BOX

- ZZB WP-03B Portable Bluetooth Speaker
- Power Cable
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.

Image: The ZZB WP-03B speaker showcasing its IPX5 water resistance with water splashing around it.

Image: Front view of the ZZB WP-03B speaker, highlighting its compact design and speaker grille.

Image: Side view of the speaker, detailing the control buttons for power, volume, and playback.

Control Buttons and Ports:

- **Power Button:** Press and hold to turn on/off.
- **'+' Button:** Press to increase volume; press and hold for next track.
- **'-' Button:** Press to decrease volume; press and hold for previous track.
- **Play/Pause Button:** Press to play/pause music, answer/end calls; double-press for TWS pairing.
- **Charging Port:** USB-C port for charging the speaker.
- **AUX-in Port:** 3.5mm input for wired audio connection.
- **TF-SD Card Slot:** For playing music directly from a memory card.

Image: The speaker attached to a backpack, demonstrating its portable design and integrated strap.

SETUP

Charging the Speaker

Before initial use, ensure the speaker is fully charged to maximize battery life.

1. Connect the provided power cable to the charging port on the speaker.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate during charging. It will turn off or change color when fully charged.

Bluetooth Pairing

Connect your speaker wirelessly to your Bluetooth-enabled device.

1. Press and hold the Power button to turn on the speaker. A voice prompt or indicator light will confirm it is on.
2. The speaker will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
3. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
4. Select "WP-03B" (or similar model name) from the list of devices.
5. Once paired, the speaker will provide an audible confirmation, and the LED light will become solid.

Portable Bluetooth speaker

Waterproof bass

Image: A smartphone displaying a music player interface, wirelessly connected to the ZZB WP-03B speaker.

OPERATING INSTRUCTIONS

Basic Functions

- **Power On/Off:** Press and hold the Power button.
- **Play/Pause:** Press the Play/Pause button once.
- **Volume Up:** Press the "+" button.
- **Volume Down:** Press the "-" button.
- **Next Track:** Press and hold the "+" button.
- **Previous Track:** Press and hold the "-" button.
- **Answer/End Call:** Press the Play/Pause button once during an incoming call.
- **Reject Call:** Press and hold the Play/Pause button during an incoming call.

TWS (True Wireless Stereo) Pairing

To achieve a stereo sound experience, you can pair two WP-03B speakers together.

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), double-press the Play/Pause button. It will enter TWS

pairing mode.

3. The two speakers will automatically connect to each other. An audible prompt will confirm successful TWS pairing.

4. Once TWS paired, connect your device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.

Image: Two ZZB WP-03B speakers demonstrating TWS pairing for a wider stereo soundstage.

Lighting Effects

The speaker features integrated color lights that automatically synchronize with the beat of the music, enhancing the atmosphere.

AUX-in Mode

Connect non-Bluetooth devices using a 3.5mm audio cable (not included) to the AUX-in port. The speaker will automatically switch to AUX mode.

TF-SD Card Mode

Insert a TF-SD card into the designated slot. The speaker will automatically detect and play audio files from the card.

MAINTENANCE

- Keep the speaker clean by wiping it with a soft, dry cloth.
- Avoid using harsh chemicals or abrasive cleaners.
- Store the speaker in a cool, dry place when not in use.
- Ensure the charging port cover is securely closed to maintain IPX5 water resistance.

TROUBLESHOOTING

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Speaker does not turn on	Low battery	Charge the speaker fully.
Cannot pair via Bluetooth	Speaker not in pairing mode / Device Bluetooth off / Too far apart	Ensure speaker is in pairing mode (flashing LED). Turn on Bluetooth on your device. Move speaker and device closer.
No sound	Volume too low / Paused / Incorrect source	Increase volume on speaker and device. Press Play. Check if AUX or TF-SD card is inserted.
Poor sound quality	Low battery / Obstructions / Too far apart	Charge the speaker. Remove obstructions between speaker and device. Move closer.
TWS pairing fails	Speakers already paired to another device / Not in TWS pairing mode	Disconnect speakers from any other Bluetooth devices. Ensure both are in TWS pairing mode.

SPECIFICATIONS

Feature	Detail
Model Name	WP-03B
Brand	ZZB
Speaker Type	Portable Speaker
Color	Gray
Product Dimensions	1.6"D x 2.9"W x 3"H
Item Weight	6 ounces
Waterproof Rating	IPX5
Connectivity Technology	Bluetooth 5.3
Bluetooth Range	Up to 100 Feet
Speaker Maximum Output Power	10 Watts
Audio Output Mode	Stereo
Battery	1 Lithium Ion (included)
Playtime	Up to 12 hours
Included Components	Power Cable

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official ZZB website. Keep your purchase receipt for warranty claims.