

[Manuals.plus](#) /

› [Notmise](#) /

› Notmise Metal Garage Shelving Unit Instruction Manual

Notmise garage shelving

Notmise Metal Garage Shelving Unit Instruction Manual

Model: garage shelving

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Notmise Metal Garage Shelving Unit. Designed for heavy-duty storage, this 5-tier adjustable steel shelving unit offers a 3000 lbs capacity, making it ideal for organizing tools and equipment in garages, basements, and other industrial or home environments. Its robust construction and thoughtful features ensure secure and efficient storage.

SAFETY INFORMATION

WARNING: Do Not Exceed The Maximum Load Capacity of 3000 Pounds (600 lbs per shelf).

- Ensure the shelving unit is assembled on a flat, stable surface.
- Distribute weight evenly across shelves to prevent tipping or structural strain.
- Do not climb on the shelving unit.
- Keep small children and pets away from the unit during assembly and while in use.
- Regularly inspect the unit for any loose connections or damage.

PARTS LIST

Before beginning assembly, ensure all parts are present and undamaged. Refer to the included packaging for a complete list of components. Key components include:

- Vertical Support Columns (Dual-Layer)
- Horizontal Beams
- Steel Shelf Panels with Reinforced Bottom Bracing
- Anti-Fall Safety Rails
- Plastic Protective Foot Pads
- Hardware (if any, though advertised as tool-free/bolt-free)



Figure 1: Overview of the Notmise 5-Tier Metal Garage Shelving Unit.

SETUP AND INSTALLATION

The Notmise shelving unit features a bolt-free slotted design for quick and easy assembly without the need for complex tools. It can also be split into two separate units for flexible arrangement.

Assembly Steps:

1. **Prepare the Area:** Clear a spacious, level area for assembly.
2. **Assemble the Frame:** Connect the vertical support columns with the horizontal beams using the bolt-free slotted design. Ensure all connections are secure. A rubber hammer may be used to gently tap components into place for a tight fit.
3. **Install Shelf Panels:** Place the steel shelf panels onto the assembled frame. The reinforced bottom bracing should face downwards for maximum support.

4. **Attach Safety Rails:** Secure the anti-fall safety rails to the edges of each shelf. These rails provide an added layer of protection, preventing items from slipping off.
5. **Add Foot Pads:** Attach the plastic protective foot pads to the bottom of the vertical columns to protect your flooring.
6. **Adjust Shelf Heights:** The height of each shelf is fully adjustable. To adjust, carefully remove the shelf panel, reposition the horizontal beams to the desired slot on the vertical columns, and then re-place the shelf panel.
7. **Optional: Split into Two Units:** If desired, the unit can be separated into two smaller, independent shelving units. Follow the assembly instructions for each smaller unit.



Figure 2: Visual guide for quick installation steps.



Figure 3: Detail of anti-fall safety rails, powder-coated exterior, and plastic protective foot pads.

OPERATING INSTRUCTIONS

Your Notmise shelving unit is designed for versatile storage. Utilize the adjustable shelf heights to accommodate items of various sizes, from small tools to large boxes and equipment.

- **Loading:** Place heavier items on lower shelves for increased stability. Distribute weight evenly across each shelf.
- **Adjustability:** To reconfigure shelf heights, unload the shelf, detach the beams from the columns, reposition them to the desired height, and re-secure the shelf panel.
- **Capacity:** The unit has a maximum weight capacity of 3000 pounds, with each shelf supporting up to 600 pounds. Adhere strictly to these limits.



Figure 4: Example of the shelving unit in a garage setting, demonstrating its storage capabilities.



Figure 5: Illustration of adjustable shelf heights and the unit's ability to split into two.

MAINTENANCE

To ensure the longevity and optimal performance of your Notmise shelving unit, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the shelves and frame with a damp cloth to remove dust and dirt. For stubborn grime, a mild soap solution can be used. Follow with a dry cloth to prevent rust.
- **Inspection:** Periodically check all connections and components for tightness and stability. Tighten any loose parts as needed.
- **Load Management:** Avoid overloading shelves beyond their stated capacity. Distribute heavy items evenly to prevent warping or damage.

TROUBLESHOOTING

If you encounter any issues with your shelving unit, consider the following common solutions:

- **Unit Wobbles:** Ensure the unit is on a level surface. Check all connections to confirm they are fully engaged and secure.

- **Shelf Sagging:** Verify that the weight on the shelf does not exceed the individual shelf capacity (600 lbs) and that weight is distributed evenly.
- **Difficulty Assembling:** Ensure components are aligned correctly with the slotted design. A rubber mallet can assist in seating parts firmly.

SPECIFICATIONS

Feature	Detail
Brand	Notmise
Model Name	garage shelving
Product Dimensions	16"D x 36"W x 72"H
Number of Shelves	5
Weight Limit (Total)	3000 Pounds
Weight Limit (Per Shelf)	600 Pounds
Material	Metal (All-Steel Shelves)
Special Features	Adjustable, Detachable, Durable, Expandable, Heavy Duty, Anti-Fall Safety Rails, Dual-Layer Columns, Reinforced Bottom Bracing, Tool-Free Installation
Finish Type	Black
Assembly Required	Yes
Installation Type	Freestanding
Room Type	Classroom, Garage, Kitchen, Living Room, Office

STORAGE SHELVES HEAVY DUTY SHELVING



Figure 6: Key dimensions of the shelving unit.

WHY CHOSE OUR PRODUCTS



Double Column

- ✓ Double layer thickening
- ✓ Stronger and more stable
- ✓ Capable of carrying greater weight

VS

Single Column

- ✗ Relatively thin
- ✗ Not enough support
- ✗ Not stable enough to shake easily



Figure 7: Maximum load capacity of the shelving unit.

WARRANTY AND SUPPORT

For specific warranty information, please refer to the documentation included with your product or contact Notmise customer support directly. Notmise is committed to providing durable and reliable storage solutions.

For further assistance or inquiries, please visit the official Notmise store on Amazon: [Notmise Store](#)

© 2024 Notmise. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

How do I obtain the missing connector pieces for my Notmise 82-inch 6-tier freestanding metal garage shelving unit purchased from Amazon?

To obtain the missing connector pieces for your Notmise Metal Garage Shelving Unit, you should follow these steps: Contact the Seller via Amazon: Since the unit was purchased through Amazon, the fastest way to get...

[Read full answer](#)