

## Dremel 7760-PET

# Dremel PawControl 7760-PET Dog Nail Grinder and Trimmer User Manual

Model: 7760-PET

## INTRODUCTION

The Dremel PawControl 7760-PET is a cordless and rechargeable pet grooming tool designed for safely and gently trimming the nails of dogs, cats, and small animals. This kit provides an alternative to traditional nail clippers, offering precise control and ease of use for both novice and experienced groomers. Its compact and lightweight design, combined with a variable speed slide switch, ensures comfortable and effective grooming.



Image: The Dremel PawControl 7760-PET nail grinder shown with its various accessories, including sanding bands, mandrels, and the USB charging cable.

## WHAT'S IN THE KIT

- 7760 4V Li-on cordless pet nail groomer
- 9 sanding accessories (including 402 – EZ Lock Mandrel, 407 - 1/2" 60 Grit Sanding Band & Mandrel, 408 - 1/2" 60 Grit Sanding Band, 952 - 3/8" Aluminum Oxide Grinding Stones (2x), SD60-PGK (4x))
- USB charging cable
- User manual
- Quick start guide
- 2 year card
- AT01-PGA – Pet Grooming Attachment
- Wrench

## SETUP

### Charging the Device

The Dremel PawControl is equipped with a 4-volt Lithium-Ion battery. Before first use, fully charge the device. Connect the provided USB charging cable to the tool and a compatible USB power source. The indicator light will show charging status. Ensure the device is not in use while charging.

# CONVENIENT USB CHARGING



Image: A hand holding the Dremel PawControl nail grinder with the USB charging cable connected, illustrating the convenient charging method.

## Attaching Accessories

The Dremel PawControl features a patented EZ twist nose cap for easy accessory changes. To attach a sanding accessory:

1. Ensure the tool is turned off.
2. Press and hold the shaft lock button.
3. Unscrew the nose cap.
4. Insert the desired sanding accessory into the collet.
5. Tighten the collet nut securely using the provided wrench.
6. Re-attach the nose cap.

For optimal nail trimming, attach the pet nail guard attachment. This attachment features a 45-degree paw guide for proper nail trimming angle and dust collection.

## ACCESSORY QUICK-CHANGE



## EASY-TO-USE FOR PETS OF ALL SIZES

Dogs

Turtles

Cats

Guinea Pigs

RECHARGEABLE  
4-VOLT BATTERY

Image: A diagram highlighting key features of the Dremel PawControl, including accessory quick-change, one-button operation, and the rechargeable 4-volt battery.

## OPERATING INSTRUCTIONS

### Preparing Your Pet

Acclimating your pet to the Dremel PawControl is crucial for a stress-free grooming experience. Begin by allowing your pet to become familiar with the tool's sound and vibration. Turn on the tool and hold it near your pet, offering praise and treats. Gradually introduce the tool to their paw, allowing them to feel the vibration on their paw before beginning to trim their nails.

# STRESS FREE GROOMING



Image: A person gently grooming a dog's nails with the Dremel PawControl, demonstrating a stress-free grooming approach.

## Nail Trimming Process

The Dremel PawControl features a variable speed slide switch with 4 adjustable speed settings (8000 RPM to 25000 RPM) for precise control based on your pet's size and nail thickness.

1. Select a low speed setting initially, increasing as your pet becomes comfortable.
2. Firmly support the toe and nail in one hand. Gently push the bottom of the paw pad to extend the nail slightly for easier grooming.
3. Position the pet nail guard attachment over the nail. The 45-degree angle guides the nail for optimal trimming.
4. Gently trim the tips of your pet's nail. Spend no more than 3 seconds on each nail to prevent heat buildup and allow the nails to cool.
5. Repeat for all nails, providing praise and treats throughout the process.



**INCLUDES A  
NAIL GUARD  
FOR COMFORT + CONFIDENCE**

Image: A close-up of the Dremel PawControl showing the transparent nail guard attachment, designed for comfort and confidence during grooming.



Image: A side-by-side comparison of a dog's paw before and after grooming with the Dremel PawControl, showing the trimmed nails.

## MAINTENANCE

### Cleaning the Device

Regular cleaning ensures optimal performance and longevity of your Dremel PawControl. After each use, remove the nail guard and any attached accessories. Use a soft, dry cloth to wipe away nail dust and debris from the tool and accessories. Do not use water or liquid cleaners directly on the tool.

### Accessory Replacement

Sanding accessories will wear down over time. Replace them when they become less effective to maintain efficient grooming. Refer to the "Attaching Accessories" section for instructions on changing accessories.

### Storage

Store the Dremel PawControl and its accessories in a clean, dry place away from direct sunlight and extreme temperatures. Ensure the tool is fully charged before storing for extended periods to preserve battery health.

## TROUBLESHOOTING

- **Tool not turning on:** Ensure the battery is fully charged. If the issue persists, contact customer support.
- **Reduced grinding effectiveness:** Replace worn-out sanding accessories. Ensure the accessory is securely attached.
- **Pet discomfort during grooming:** Ensure your pet is properly acclimated to the tool. Use the lowest speed setting initially. Limit grinding time to 3 seconds per nail to prevent heat buildup.
- **Excessive noise:** Some noise is normal, especially at higher speeds. If the noise is unusual or excessive, ensure all parts are securely fastened and there are no obstructions.

## SPECIFICATIONS

<b>Brand</b>	Dremel
<b>Model Number</b>	7760-PET
<b>Voltage</b>	4 Volts
<b>Power Source</b>	Battery Powered (Lithium Ion)
<b>Maximum Rotational Speed</b>	25000 RPM
<b>Minimum Speed</b>	8000 RPM
<b>Item Weight</b>	0.58 Kilograms (1.28 pounds)
<b>Special Features</b>	Cordless, Lightweight, Variable Speed

## SAFETY INFORMATION

- Always use the tool in a well-ventilated area to avoid inhaling dust.
- Keep the tool away from water and other liquids to prevent electrical shock.
- Do not use the tool while it is charging.
- Always wear safety glasses when using the tool to protect your eyes from flying debris.
- Never leave the tool unattended while in use.
- Always store the tool in a safe and secure location when not in use.

## WARRANTY AND SUPPORT

The Dremel PawControl 7760-PET comes with a 2-year warranty. For warranty claims, technical support, or any product-related inquiries, please refer to the contact information provided in your quick start guide or visit the official Dremel website.

You can also visit the [Dremel Store on Amazon](#) for more information and products.