

Gvirtue BN59-01432A

User Manual for Gvirtue BN59-01432A Solar Voice Replacement Remote Control

Model: BN59-01432A

INTRODUCTION

This manual provides comprehensive instructions for the Gvirtue BN59-01432A Solar Voice Replacement Remote Control. Designed for seamless compatibility with 2023 Samsung Neo QLED 8K HDR Ultra HD Smart TVs, this remote offers advanced features such as solar charging, USB-C charging, voice control, and dedicated shortcut buttons for popular streaming services. Please read this manual thoroughly to ensure proper use and maintenance of your new remote control.

KEY FEATURES

- **Broad Compatibility:** Specifically designed for 2023 Samsung Neo QLED 8K HDR Ultra HD Smart TVs, including models like 65QN800C, 75QN800C, 85QN800C, 65QN900C, 75QN900C, and 85QN900C.
- **Dual Charging Options:** Features a built-in solar rechargeable battery and supports USB Type-C interface charging, reducing the need for frequent battery replacements.
- **Voice Control Functionality:** Enables hands-free navigation, content search, channel changes, and volume adjustments through voice commands.
- **Dedicated Shortcut Buttons:** Includes direct access buttons for Netflix, Disney+, and Prime Video for quick streaming access.
- **Easy Pairing:** Simple pairing process by holding specific buttons for a few seconds.
- **Durable Construction:** Made from premium ABS material, designed for high responsiveness and long-distance transmission.

SETUP AND PAIRING

Before using your new remote control, it must be paired with your Samsung Smart TV. Follow these steps:

1. Ensure your Samsung Smart TV is powered on.
2. On the Gvirtue remote control, simultaneously press and hold the **Return** (⏮) and **Play/Pause** (⏸) buttons for 3 to 5

seconds.

3. The light above the power button on the remote will flash, indicating it is in pairing mode.
4. Once the light stops flashing and remains solid, the pairing is complete. A confirmation message may appear on your TV screen.



Image: Visual guide for pairing the remote control with a Samsung Smart TV, showing the steps on the TV screen and the remote.

Your browser does not support the video tag.

Video: Demonstrates the pairing process for the Gvirtue remote control with a Samsung Smart TV, showing the button presses and on-screen confirmation.

OPERATING INSTRUCTIONS

Basic Navigation

- Use the directional pad (up, down, left, right) to navigate menus and select items.

- Press the **Center** button to confirm selections.
- The **Return** button takes you back to the previous screen.
- The **Home** button (↓) takes you to the TV's home screen.
- Use the **Volume Up/Down** and **Channel Up/Down** buttons for audio and channel control.

Voice Function

The remote features a voice search function for convenient control. After successful pairing:

1. Press the **Voice** button (microphone icon) on the remote.
2. Speak clearly into the remote's microphone. You can search for content, change channels, adjust volume, or issue other commands.
3. For example, say "I want to watch Netflix" or "Please open Prime Video."



BN59-01432A

Solar Replacement for Samsung Neo QLED 8K HDR Ultra HD Smart TVs,

Compatible with the following models:

43Q60C	50LS03C	50QN95B	55QN900C	60S90C
43Q70C	50Q60C	50S90C	55QN90C	65LS03C
43Q80C	50Q70C	55LS03C	55QN95B	65Q60C
65QN900C	70S90C	75QN90C	85QE1C	98Q80C
65QN90C	75LS03C	75QN95B	85QN800C	43CU8000F
65QN95B	75Q60C	77S90C	85QN850C	50CU8000D
65S90C	75Q70C	77S95C	85QN85C	50CU8000F
65S95C	75Q80C	83S90C	85QN900C	55CU8000D
70Q60C	75QE1C	85LS03C	85QN90C	55CU8000F
70Q70C	75QN800C	85QN95B	85QN95B	65CU8000D
70QN850C	75QN850C	85Q60C	85S90C	65CU8000F
70QN85C	75QN85C	85Q70C	98Q60C	85CU8000D
70QN90C	75QN900C	85Q80C	98Q80C	85CU8000F




Image: The remote control with the voice search microphone button highlighted, illustrating its use for voice commands.

Shortcut Buttons

Quickly access your favorite streaming platforms using the dedicated shortcut buttons:

- Press the **Netflix** button to launch Netflix.
- Press the **Disney+** button to launch Disney+.
- Press the **Prime Video** button to launch Amazon Prime Video.

CHARGING THE REMOTE

The Gvirtue BN59-01432A remote control offers two convenient charging methods:

Solar Charging

The remote has a built-in solar panel on its back. To charge using solar power, simply place the remote with the solar panel facing a light source (natural sunlight or indoor lighting). The remote will automatically charge, reducing the need for external power.

NO MORE BATTERIES!

Forget about batteries using the solar cell at the back to charge it or with the USB-C port at the bottom (cable not included)



Solar charge



USB-C
charging port



Image: The back of the remote control, highlighting the solar charging panel.

USB Type-C Charging

For faster charging or when solar charging is not feasible, use a USB Type-C cable (not included) to charge the remote. The USB-C port is located at the bottom of the remote.

1. Connect one end of a USB Type-C cable to the charging port on the remote.
2. Connect the other end of the cable to a USB power adapter (e.g., phone charger, computer USB port).
3. The remote's indicator light may show charging status.



Image: The bottom of the remote control, showing the USB-C charging port and a charging cable connected.

COMPATIBILITY

This Gvirtue BN59-01432A remote control is compatible with the following 2023 Samsung Neo QLED 8K HDR Ultra HD Smart TV models:

65QN800C

75QN800C
85QN800C
65QN900C
75QN900C
85QN900C

And other compatible 2023 Samsung Neo QLED 8K HDR
Ultra HD Smart TVs.





Remote Replacement for Pairing TV

Hold down the BACK  and
PLAY/PAUSE  buttons at
the same time about 3-5 second
until the light above power
button lights up.

Image: The remote control displayed alongside a list of compatible Samsung TV models, emphasizing its broad compatibility.

SPECIFICATIONS

Problem	Possible Cause	Solution
---------	----------------	----------

Remote not responding.	Low battery or not paired.	Charge the remote via solar or USB-C. Re-pair the remote with your TV (see "Setup and Pairing" section).
Voice function not working.	Not paired correctly or microphone issue.	Ensure the remote is successfully paired. Speak clearly and close to the microphone.
Shortcut buttons not launching apps.	App not installed or remote not fully paired.	Verify the apps are installed on your TV. Re-pair the remote if necessary.
Short transmission distance.	Obstructions or interference.	Ensure no objects are blocking the signal path between the remote and TV. Reduce electronic interference.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the remote. Avoid using liquid cleaners or abrasive materials.
- **Storage:** Store the remote in a cool, dry place away from direct sunlight when not in use for extended periods.
- **Charging:** Regularly expose the solar panel to light or charge via USB-C to maintain optimal battery performance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	Low battery or not paired.	Charge the remote via solar or USB-C. Re-pair the remote with your TV (see "Setup and Pairing" section).
Voice function not working.	Not paired correctly or microphone issue.	Ensure the remote is successfully paired. Speak clearly and close to the microphone.
Shortcut buttons not launching apps.	App not installed or remote not fully paired.	Verify the apps are installed on your TV. Re-pair the remote if necessary.
Short transmission distance.	Obstructions or interference.	Ensure no objects are blocking the signal path between the remote and TV. Reduce electronic interference.

WARRANTY AND SUPPORT

Gvirtue products are manufactured with high-quality standards. For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official Gvirtue website. Keep your purchase receipt as proof of purchase for any warranty claims.

For further assistance, you may contact Gvirtue customer service through their Amazon store page:[Gvirtue Store on Amazon](#).

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0DJ7263HJ>

More documents and user manuals: **<https://manuals.plus/>**