PAIDASHU P38S01

PAIDASHU 22.5W 27000mAh Power Bank User Manual

Model: P38S01

Introduction

Thank you for choosing the PAIDASHU 22.5W 27000mAh Power Bank. This portable charger is designed to provide reliable and fast charging for your electronic devices on the go. Featuring advanced PD3.0 and QC4.0 fast charging technology, a large capacity, and multiple output ports, it ensures your devices stay powered throughout your day. Please read this manual carefully before use to ensure optimal performance and safety.

Safety Information

- Do not expose the power bank to extreme temperatures, direct sunlight, or fire.
- Do not immerse the power bank in water or other liquids.
- Avoid dropping, hitting, or disassembling the device.
- Keep out of reach of children.
- Use only certified charging cables and adapters.
- If the power bank swells, emits smoke, or shows other abnormalities, discontinue use immediately.
- Dispose of the power bank according to local regulations for electronic waste.

Package Contents

Please check the package for the following items:

- PAIDASHU 22.5W 27000mAh Power Bank (Model P38S01)
- USB-A to USB-C Charging Cable
- User Manual

Product Overview

The PAIDASHU P38S01 Power Bank features a sleek design with multiple ports and an intelligent LED display for convenient use.

Key Features:

- **22.5W Fast Charging:** Supports PD3.0 and QC4.0 protocols for rapid charging of compatible devices.
- **27000mAh High Capacity:** Provides multiple charges for smartphones, tablets, and other USB-powered devices.
- **Multiple Ports:** Equipped with 3 output ports (2x USB-A, 1x USB-C) and 2 input ports (Micro USB, USB-C) for versatile charging.
- **LED Digital Display:** Shows the exact remaining battery percentage.

Port Layout and Indicators:





Image: Detailed view of the power bank's ports and power button. From left to right: USB-A1 Output (22.5W), Micro-USB Input (18W), USB-C Input/Output (PD20W/18W), USB-A2 Output (22.5W), and the Power Button.

- **USB-A1 Output:** 22.5W fast charging output.
- **Micro-USB Input:** 18W input for charging the power bank.
- **USB-C Input & Output:** Supports PD20W output and 18W input for charging devices or recharging the power bank.
- **USB-A2 Output:** 22.5W fast charging output.
- **Power Button:** Press once to check battery level or initiate charging.
- **LED Digital Display:** Shows the battery percentage (0-100%).

Setup

Charging the Power Bank:

Before first use, fully charge your power bank. To charge the power bank:

1. Connect the provided USB-A to USB-C cable (or a Micro-USB cable) to the appropriate input port on the power bank (Micro-USB or USB-C).
2. Connect the other end of the cable to a USB wall charger (not included). For faster charging, use a PD or QC compatible wall charger.
3. The LED display will show the charging progress, indicating the battery percentage increasing.
4. Once the display shows "100%", the power bank is fully charged. Disconnect it from the power source.



Image: The power bank's USB-C port is used for both input (charging the power bank) and output (charging a device). This image illustrates the versatility of the USB-C port for both charging the power bank and charging a device simultaneously.

Operating Instructions

Charging Your Devices:

1. Connect your device's charging cable to one of the power bank's output ports (USB-A1, USB-A2, or USB-C).
2. Connect the other end of the cable to your device.
3. The power bank will automatically begin charging your device. If not, press the power button once to activate charging.

4. The LED display will show the power bank's remaining battery percentage.
5. You can charge up to three devices simultaneously using the available output ports.



Image: A smartphone is connected to the power bank via a USB-C cable, indicating active fast charging. The power bank's digital display shows "100%", signifying a full charge. This demonstrates the power bank's ability to deliver 22.5W fast charging.



Image: A person is shown using the power bank to charge a tablet while sitting outdoors, highlighting the device's portability and convenience for travel or daily use.



Image: The power bank is shown connected to and charging three different devices: a smartphone, a tablet, and another smartphone. This illustrates the power bank's capacity for simultaneous charging of multiple devices with its 22.5W super fast charging capability.

Checking Battery Level:

Press the power button once. The LED digital display will illuminate, showing the current battery percentage of the power bank.

Maintenance

- Clean the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the power bank in a cool, dry place away from direct sunlight and moisture.
- If not used for extended periods, charge the power bank at least once every three months to maintain battery health.

Troubleshooting

Problem	Possible Solution
Power bank not charging	• Ensure the charging cable is securely connected to both the power bank and the wall charger. • Try a different charging cable or wall charger. • Check if the wall outlet is functional.
Device not charging from power bank	• Press the power button on the power bank to activate charging. • Ensure the device's charging cable is securely connected to both the power bank and the device. • Try a different charging cable or a different output port on the power bank. • Check if the power bank has sufficient charge.
Slow charging	• Ensure you are using a fast-charging compatible cable and your device supports fast charging. • When charging the power bank, use a PD or QC compatible wall adapter for optimal speed. • Charging multiple devices simultaneously may reduce individual charging speeds.

Specifications

Feature	Detail
Model Number	P38S01
Brand	PAIDASHU
Battery Capacity	27000 mAh
Output Power	22.5W (Max)
Input Ports	Micro USB (18W), USB-C (18W)
Output Ports	2x USB-A (22.5W), 1x USB-C (PD20W)
Fast Charging Protocols	PD3.0, QC4.0
Battery Type	Lithium Polymer
Dimensions (L x W x H)	15 x 8 x 3.8 cm
Weight	400 g

Feature	Detail
Special Feature	Digital LED Display

Warranty and Support

This PAIDASHU Power Bank is covered by a **1-year warranty** from the date of purchase. This warranty covers manufacturing defects and workmanship. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.
For warranty claims or technical support, please contact your retailer or the PAIDASHU customer service team with your purchase details and model number.

© 2024 PAIDASHU. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question