

Gurexl B0DJ7FH4PS

Gurexl 67-inch Tall Farmhouse Storage Cabinet User Manual

Model: B0DJ7FH4PS

INTRODUCTION

Thank you for choosing the Gurexl 67-inch Tall Farmhouse Storage Cabinet. This manual provides essential information for the safe assembly, operation, and maintenance of your new cabinet. Please read these instructions carefully before beginning assembly and retain them for future reference.

This versatile storage cabinet features an auto-sensing LED light, a 2-in-1 USB and USB-C charging station, and adjustable shelving, making it suitable for various rooms such as kitchens, dining rooms, or living areas.

SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in injury or property damage.

- Always assemble the cabinet on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not use damaged parts.
- Do not overtighten screws during assembly, as this may damage the material.
- For safety, it is highly recommended to secure the cabinet to a wall using the provided anti-tip kit. This prevents accidental tipping, especially in homes with children or pets.
- Do not exceed the weight capacity of the shelves. Distribute weight evenly.
- Keep electrical components (LED lights, charging ports) away from water or excessive moisture.
- Unplug the cabinet from the power source before cleaning or performing any maintenance.

PACKAGE CONTENTS

Before assembly, verify that all components are present. Refer to the detailed assembly instructions provided in the product packaging for a complete list of parts and hardware.

- Cabinet panels (top, bottom, sides, back)
- Doors with acrylic inserts
- Adjustable shelves
- Hardware kit (screws, dowels, hinges, handles)
- LED light strip and power adapter
- USB/USB-C charging module
- Anti-tip safety kit
- Assembly instructions manual

SETUP AND ASSEMBLY

Detailed assembly instructions with labeled parts are included in your product packaging. Please follow them step-by-step for proper construction.

Key Assembly Steps:


1. **Unpack and Organize:** Lay out all parts and hardware on a clean, soft surface. Identify each component using the provided parts list.
2. **Assemble Frame:** Connect the main cabinet panels according to the diagrams in the assembly manual.
3. **Install Shelves:** Insert the adjustable shelves into the desired positions. The bottom cabinet shelves are removable to accommodate taller items.
4. **Attach Doors:** Secure the doors using the provided hinges and attach the handles. The acrylic doors offer a 180-degree expansion for easy access.
5. **Install LED Lighting:** Place the LED light strip in the designated area. Connect it to the power adapter.
6. **Install Charging Station:** Integrate the USB and USB-C charging module into the countertop section.
7. **Secure with Anti-Tip Kit:** For safety, attach the anti-tip kit to the top rear of the cabinet and secure it to a wall stud.

PRODUCT DIMENSION

Farmhouse Corner Cabinet



Bottom Size:



Top Plate Size:




Figure 1: Product Dimensions. This image illustrates the overall height and specific measurements of the cabinet's sections, crucial for planning placement and assembly.

FARMHOUSE

Living Room Cabinet Collection



Figure 2: Anti-Tip Kit Installation. This image demonstrates how to properly install the anti-tip kit to secure the cabinet to the wall, enhancing stability and safety.

OPERATING INSTRUCTIONS

Auto Sensor LED Lighting:

The cabinet features an integrated LED light with an auto-sensing mode and adjustable colors and brightness.

- **Color Adjustment:** Short press the light control button to cycle through three dimmable colors: blue, white, and warm white.
- **Brightness Adjustment:** Long press the light control button to adjust the brightness level.
- **Auto-Sensing Mode:** When activated, the light will automatically turn on when a person is detected within 1-2 meters and turn off when no motion is detected, saving energy.



3 Color Lights

Short press to adjust the hue Dimmable



Dimmable

Long press to adjust the brightness



Figure 3: LED Light Controls. This image illustrates the functionality of the LED lighting system, showing how to change colors and adjust brightness.

Human Sensor Lights

When the human body sensor is turned on, the light will automatically light up when the person is about 1-2 meters



Figure 4: Human Sensor Lights in Operation. This image demonstrates the automatic activation of the LED lights when motion is detected, highlighting the convenience of the auto-sensing feature.

2-in-1 Charging Station:

The cabinet is equipped with a convenient charging station located on the countertop.

- **USB Port:** Provides 5V/2.1A output for charging various devices.
- **USB-C Port:** Provides 5V/2.1A output for charging compatible devices.
- Simply plug your cell phone, headphones, or other electronic devices into the appropriate port for charging.

1

2-in-1 Charge

Desktop with USB and TYPE-C charging port



2

Removable Shelves

Shelves can be removed for more space



Figure 5: 2-in-1 Charging Station. This image displays the integrated USB and USB-C charging ports in use, demonstrating their function for powering electronic devices.

Removable Shelves:

The shelves within the bottom cabinet are designed to be removable, offering flexible storage options.

- To remove a shelf, carefully lift it and slide it out of its supports.
- Removing shelves increases the vertical space, allowing for storage of taller items such as bottles or small appliances.



Figure 6: Removable Shelves. This image highlights the adjustable nature of the interior shelves, showing how they can be reconfigured to suit different storage needs.

MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your Gurexl storage cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals, abrasive cleaners, or polishes that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood finish.
- **Dusting:** Regularly dust the cabinet with a dry, soft cloth.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **LED Lights:** The LED lights are designed for long life and typically do not require replacement. If issues occur, refer to the troubleshooting section.

TROUBLESHOOTING

If you encounter any issues with your Gurexl storage cabinet, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Cabinet is wobbly or unstable.	Loose fasteners; uneven floor; anti-tip kit not installed.	Ensure all screws are tightened. Place shims under the base if the floor is uneven. Install the anti-tip kit securely to a wall stud.
LED light does not turn on.	Power adapter not plugged in; loose connection; faulty light strip.	Check if the power adapter is securely plugged into an outlet and the light strip. Ensure all connections are firm. If the issue persists, contact customer support.
Auto-sensing LED light not working.	Sensor obstructed; sensor malfunction.	Ensure the sensor area is clear of obstructions. Test the light by manually pressing the control button. If the manual function works but auto-sensing does not, contact customer support.
Charging ports (USB/USB-C) not working.	Power adapter not plugged in; loose connection; faulty charging module.	Verify the cabinet's power adapter is plugged in. Check the connection of the charging module. Try a different device or cable to rule out external issues. If still not working, contact customer support.
Doors do not close properly.	Misaligned hinges; cabinet not level.	Adjust the hinges as per the assembly instructions. Ensure the cabinet is level on the floor.

SPECIFICATIONS

- **Brand:** Gurexl
- **Model:** B0DJ7FH4PS
- **Product Dimensions:** 20"D x 20"W x 67"H
- **Material:** Wood
- **Color:** Oak Rustic
- **Special Feature:** Human Sensor Light, 2-in-1 USB/USB-C Charging Station
- **Mounting Type:** Free Standing (Anti-tip kit included for wall attachment)
- **Room Type:** Kitchen, Dining Room, Living Room
- **Door Style:** Acrylic Door
- **Number of Doors:** 1 (upper section has two smaller doors)
- **Number of Shelves:** 3 (removable in bottom cabinet)
- **Assembly Required:** Yes (Detailed instructions provided)

WARRANTY AND SUPPORT

Gurexl stands behind the quality of its products. For specific warranty details, please refer to the

documentation included with your purchase or visit the official Gurexl website.

If you have any questions, require assistance with assembly, or encounter any issues not covered in this manual, please contact Gurexl customer support. Have your model number (B0DJ7FH4PS) and purchase information ready when contacting support.

Gurexl Customer Support: Please refer to the contact information provided in your product packaging or on the Gurexl brand store page.