

[Manuals.plus](#) /

› [AWEI](#) /

› AWEI T39 Wireless Earbuds User Manual

AWEI T39

AWEI T39 Wireless Earbuds User Manual

Model: T39

1. INTRODUCTION

Thank you for choosing the AWEI T39 Wireless Earbuds. This manual provides essential information for setting up, operating, and maintaining your earbuds to ensure optimal performance and longevity. Please read this manual thoroughly before use.

Angelic Sounds Just like Nightingale

Inspired by Small Eggshells
More Mini & Exquisite



Image 1.1: AWEI T39 Wireless Earbuds and their charging case, showcasing their compact design.

2. PACKAGE CONTENTS

Ensure all items are present in the package:

- AWEI T39 Wireless Earbuds (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual (This document)
- Eartips (Various sizes)

3. SETUP

3.1 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB Type-C charging cable to the charging port on the case and to a power source (e.g., USB wall adapter, computer USB port).
3. The indicator lights on the case will show charging status. A full charge typically takes about 1 hour for the case.
4. Once fully charged, disconnect the charging cable.

Note: The earbuds provide approximately 7 hours of continuous use per charge. The charging case extends total playback time to about 37 hours in dual-ear mode, or up to 60 hours in single-ear mode by alternating earbuds.

Long Battery Life For Endless Entertainment

With the charging case, it provides 200 hours of standby time



...




250 mAh
Battery Capacity of
Charging Case


200 h
Standby Time


6 h
Play Time

The above data are the test values of AWEI laboratory. The actual data may vary slightly depending on the specific test environment.

Image 3.1: The AWEI T39 charging case with earbuds inserted, illustrating the charging setup.

3.2 Bluetooth Pairing

The AWEI T39 earbuds utilize Bluetooth 5.3 technology for a stable and efficient connection.

1. First-time Pairing:

- Open the charging case. The earbuds will automatically power on and enter pairing mode.
- On your device (smartphone, tablet, laptop), enable Bluetooth.
- Search for "AWEI T39" in the list of available Bluetooth devices and select it to connect.
- Once connected, you will hear a confirmation tone, and the earbuds' indicator lights will change.

2. Automatic Reconnection:

- After initial pairing, the earbuds will automatically connect to the last paired device when removed from the charging case and Bluetooth is enabled on the device.

3. Single Earbud Mode:

- You can use either the left or right earbud independently. Simply take one earbud out of the case, and it will connect. The other earbud can remain in the case or be used later.

Wider Compatibility For Different Devices



Widely applicable to cellphones, tablets, laptops, desktops, etc. of various operating systems

...



Image 3.2: AWEI T39 earbuds demonstrating compatibility with various devices like smartphones and laptops.

4. OPERATING INSTRUCTIONS

The AWEI T39 earbuds feature smart touch controls for easy operation.

4.1 Power On/Off

- **Power On:** Open the charging case, or long-press the touch area on both earbuds for 3 seconds.
- **Power Off:** Place the earbuds back into the charging case and close the lid, or long-press the touch area on both earbuds for 5 seconds.

4.2 Touch Control Functions

The touch-sensitive area is located on the outer surface of each earbud.

Action	Function
Tap either earbud once	Play/Pause music, Answer/Hang up call
Tap L/R earbud twice	Previous song (Left), Next song (Right)
Long touch L/R earbud	Volume down (Left), Volume up (Right)
Tap either earbud for 2 seconds	Reject call
Tap L earbud thrice	Activate Voice Assistant

Sensitive Touch Control Intelligent Interaction Design



Blind touching can also be easily operated

...



Play/Pause
Tap either



Answer/Hand Up
Tap either



PREV/NEXT
Tap L/R earbud twice



Reject
Touch either for 2s



VOL+/-
Long touch L/R earbud



Voice Assistant
Tap L earbud thrice

Image 4.1: Visual representation of the touch control functions on the AWEI T39 earbuds.

5. MAINTENANCE

5.1 Cleaning

- Regularly clean the earbuds and charging case with a soft, dry, lint-free cloth.
- Remove earwax or debris from the earbud mesh and eartips using a small, soft brush or cotton swab.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.

5.2 Storage

- When not in use, store the earbuds in their charging case to protect them and keep them charged.
- Store in a cool, dry place, away from extreme temperatures and direct sunlight.

5.3 Waterproofing (IPX6)

The AWEI T39 earbuds are rated IPX6 waterproof, meaning they are protected against high-pressure water jets from any direction. This makes them suitable for workouts and light rain.

- Do not submerge the earbuds in water.
- The charging case is not waterproof.
- Ensure earbuds are dry before placing them back into the charging case to prevent damage.

T39 TWS Earbuds

Ergonomics Design Skin & Eco-Friendly Materials



Tightly fitting to ear canals without fear of bumps and swings

...



Image 5.1: An AWEI T39 earbud comfortably fitted in a user's ear, highlighting its ergonomic design and suitability for active use.

6. TROUBLESHOOTING

If you encounter issues with your AWEI T39 earbuds, refer to the following common solutions:

6.1 Earbuds Not Pairing or Connecting

- Ensure both earbuds are charged.
- Make sure Bluetooth is enabled on your device.
- Place the earbuds back into the charging case, close the lid, wait a few seconds, then open it again to re-enter pairing mode.
- On your device, forget or delete "AWEI T39" from your Bluetooth device list, then attempt to pair again.
- Try pairing with a different device to rule out device-specific issues.

6.2 No Sound or Low Volume

- Check the volume level on both your device and the earbuds.
- Ensure the earbuds are properly connected to your device.
- Clean the earbud mesh to remove any obstructions.
- Try resetting the earbuds (refer to manufacturer's specific reset instructions if available, otherwise, re-pair).

6.3 Charging Issues

- Ensure the charging cable is securely connected to both the case and the power source.
- Try a different USB Type-C cable or power adapter.
- Check the charging contacts on the earbuds and inside the case for any debris or damage.

7. SPECIFICATIONS

Feature	Detail
Model Name	T39
Bluetooth Version	5.3
Connectivity Technology	Wireless
Wireless Communication Technology	Bluetooth
Water Resistance Level	IPX6 (Earbuds only)
Battery Life (Earbuds)	Up to 7 hours
Total Playtime with Charging Case	Up to 37 hours (dual-ear), 60 hours (single-ear)
Charging Time	Approx. 1 hour (case)
Control Type	Touch Control
Ear Placement	In Ear
Audio Driver Type	Dynamic Driver (13mm speaker)
Bluetooth Range	Up to 10 meters (33 feet)
Included Components	Cable, User Manual, Charging Case, Wireless Earbuds, Eartip

8. WARRANTY AND SUPPORT

AWEI products are designed and manufactured to the highest quality standards. For warranty information, technical support, or customer service inquiries, please refer to the warranty card included in your package or visit the official AWEI website. Keep your proof of purchase for warranty claims.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question