

[manuals.plus](#) /

- › [DOOGEE](#) /
- › [DOOGEE U11 Android 15 Tablet User Manual](#)

DOOGEE U11

DOOGEE U11 Android 15 Tablet User Manual

Model: U11

Brand: DOOGEE

1. INTRODUCTION

Welcome to the user manual for your new DOOGEE U11 Android 15 Tablet. This guide provides essential information on setting up, operating, maintaining, and troubleshooting your device. The DOOGEE U11 is an 11-inch tablet featuring the latest Android 15 operating system, an octa-core processor, and a high-capacity battery, designed for a smooth and efficient user experience.

2. PRODUCT OVERVIEW AND FEATURES

The DOOGEE U11 tablet combines powerful performance with a vibrant display and long-lasting battery life, making it ideal for entertainment, productivity, and communication.

2.1 Key Components




This image displays the DOOGEE U11 tablet from both the front and back, highlighting its sleek design and the rear camera module. Key specifications like Android 15, 16GB RAM, and 128GB storage are visible on the screen.

2.2 Core Features

- Operating System & Processor:** Powered by the fast, smart, and secure Android 15 OS with a built-in T606 Octa-core processor for efficient and smooth performance.

Powerful Octa-core Processor



 **Unisoc T606**

 **1.6GHz**


 **12nm**

 **Mali-G57**

The image shows the clean and intuitive interface of the Android 15 operating system on the DOOGEE U11 tablet, with various app icons and system settings visible.

The Latest Android 15 System

Smarter, Smoother & Safer



This diagram illustrates the T606 Octa-core processor, highlighting its key specifications such as Unisoc T606, 1.6GHz clock speed, 12nm process, and Mali-G57 GPU, which power the tablet's performance.

- Display:** Features an 11-inch IPS full-color 90Hz display with brilliant colors and comfortable touch, supporting Netflix 1080P (Widevine L1 certified).



This image details the 11-inch IPS display of the DOOGEE U11 tablet, showcasing its 1280*800 resolution, 83.2% screen-to-body ratio, 16.7 million screen colors, and 1000:1 contrast ratio for a clear and vibrant viewing experience.

- Battery:** Built-in 8580mAh high-capacity battery, providing extended usage times for video watching, music playback, and web browsing.

8580mAh Monster Battery



1509 Hours
Standby


9.2 Hours
Video Watching

28.3 Hours
Music Playing

6.7 Hours
Web Browsing

The image illustrates the impressive battery life of the DOOGEE U11 tablet, powered by its 8580mAh battery. It highlights usage durations such as 1509 hours standby, 9.2 hours video watching, 28.3 hours music playing, and 6.7 hours web browsing.

- Memory & Storage:** Equipped with 16GB RAM (4GB + 12GB RAM expansion) and 128GB ROM, expandable up to 2TB via MicroSD/TF card.



This image emphasizes the massive storage capabilities of the DOOGEE U11 tablet, featuring 128GB ROM expandable to 2TB, and 4GB+12GB RAM. It also shows a variety of popular applications, indicating ample space for apps and media.

- Cameras:** Features a 13MP main camera and a 5MP front camera for capturing moments and video calls.

Capture Every Detail with Clarity



The image highlights the camera capabilities of the DOOGEE U11 tablet, featuring a 13MP main camera for clear photos and a 5MP front camera suitable for video calls and selfies.

- Audio:** Stereo-enhanced dual speakers for an immersive audio experience.

Stereo-enhanced Dual Speaker



This image details the stereo-enhanced dual speakers of the DOOGEE U11 tablet, indicating specifications such as 1.0W output, 128dB volume, and 770Hz frequency response, promising a rich audio experience.

3. SETUP

3.1 Initial Charging

Before first use, fully charge your DOOGEE U11 tablet. Connect the provided USB cable to the tablet's charging port and the other end to a compatible power adapter. The charging indicator will show the charging status.

3.2 Powering On/Off

- To Power On:** Press and hold the Power button until the DOOGEE logo appears on the screen.
- To Power Off:** Press and hold the Power button until the power options menu appears. Select 'Power off' and confirm.

3.3 Initial Setup Wizard

Upon first power-on, the tablet will guide you through an initial setup wizard. Follow the on-screen prompts to:

- Select your language.
- Connect to a Wi-Fi network.
- Sign in with your Google account or create a new one.
- Set up screen lock (PIN, pattern, password, or Face ID).

3.4 Inserting a MicroSD/TF Card

The DOOGEE U11 supports MicroSD/TF cards up to 2TB for expanded storage. Locate the SIM/SD card tray on the side of the tablet. Use the provided ejector tool to open the tray. Carefully place the MicroSD/TF card into the designated slot and reinsert the tray.

4. OPERATING INSTRUCTIONS

4.1 Basic Navigation

The DOOGEE U11 uses touch gestures for navigation:

- **Tap:** To select an item or open an app.
- **Swipe:** To scroll through screens or lists.
- **Pinch-to-zoom:** To zoom in or out on images or web pages.
- **Long press:** To access contextual menus or move icons.

4.2 Wi-Fi Connection

1. Go to 'Settings' > 'Network & internet' > 'Wi-Fi'.
2. Turn on Wi-Fi.
3. Select your desired network from the list.
4. Enter the password if prompted and tap 'Connect'.

4.3 Bluetooth Pairing

1. Go to 'Settings' > 'Connected devices' > 'Bluetooth'.
2. Turn on Bluetooth.
3. Ensure the device you want to pair with is in pairing mode.
4. Select the device from the 'Available devices' list and follow any on-screen prompts.

4.4 App Management

- **Installing Apps:** Open the Google Play Store app, search for your desired app, and tap 'Install'.
- **Uninstalling Apps:** Long press on the app icon on the home screen or app drawer, then drag it to 'Uninstall' or select 'App info' and tap 'Uninstall'.

4.5 Using the Cameras

Open the 'Camera' app. You can switch between the 13MP main camera and the 5MP front camera. Tap the shutter button to take photos or switch to video mode to record videos. Adjust settings like flash, timer, and filters as

needed.

4.6 Media Playback

The DOOGEE U11 supports high-definition media playback, including Netflix 1080P thanks to Widevine L1 certification. Use pre-installed apps like YouTube or download streaming services from the Play Store for an optimal viewing experience.

4.7 Face ID Setup

To set up Face ID for unlocking your tablet:

1. Go to 'Settings' > 'Security & privacy' > 'Device unlock' > 'Face unlock'.
2. Follow the on-screen instructions to register your face. Ensure you are in a well-lit environment.

5. MAINTENANCE

5.1 Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. For stubborn smudges, slightly dampen the cloth with water or a screen cleaner. Avoid using harsh chemicals or abrasive materials.

5.2 Battery Care

- Avoid exposing the tablet to extreme temperatures.
- Do not let the battery completely drain frequently.
- Use the original charger or a certified compatible charger.

5.3 Software Updates

Regularly check for system updates to ensure your tablet has the latest features, security patches, and performance improvements. Go to 'Settings' > 'System' > 'System update'.

5.4 Storage Management

The DOOGEE U11 includes a Memory Manager feature to help optimize storage. This tool provides cleaning suggestions to free up space by identifying and allowing you to delete junk files, duplicate files, large files, and downloaded files. Access it through system settings or a dedicated app if available.

6. TROUBLESHOOTING

If you encounter issues with your DOOGEE U11 tablet, refer to the following common problems and solutions:

Problem	Possible Solution
Tablet not turning on	Ensure the battery is charged. Connect to a charger for at least 30 minutes. Press and hold the Power button for 10-15 seconds to force a restart.
Wi-Fi connection issues	Restart the tablet and your Wi-Fi router. Forget the network in Wi-Fi settings and reconnect. Ensure you are within range of the Wi-Fi signal.

Problem	Possible Solution
Apps crashing or freezing	Close and reopen the app. Clear the app's cache and data in 'Settings' > 'Apps'. Update the app to the latest version.
Slow performance	Close unused apps. Clear cache and junk files using the Memory Manager. Restart the tablet regularly. Consider uninstalling rarely used apps.
Screen unresponsive	Force restart the tablet by holding the Power button. If the issue persists, contact support.
Cannot connect to Bluetooth device	Ensure Bluetooth is enabled on both devices and they are in pairing mode. Move devices closer. Restart both devices.
Face ID not working	Ensure sufficient lighting. Clean the front camera lens. Re-register your face in settings.

If the problem persists after trying these solutions, you may need to perform a factory reset (this will erase all data on the tablet, so back up important information first) or contact customer support.

7. SPECIFICATIONS

Feature	Specification
Model Name	U11
Operating System	Android 15
Screen Size	11 Inches
Max Screen Resolution	1920x1200 Pixels
Processor	Octa-Core (T606)
RAM	16GB (4GB + 12GB expansion)
Flash Memory Size (ROM)	128 GB
Expandable Storage	Up to 2TB (MicroSD/TF)
Rear Webcam Resolution	13 MP
Front Webcam Resolution	5 MP
Battery Capacity	8580mAh
Wireless Type	802.11ax (Wi-Fi), Bluetooth 5.0
Item Weight	1.19 pounds
Product Dimensions	7.95 x 4.92 x 0.08 inches
Color	Pink

8. WARRANTY AND SUPPORT

Your DOOGEE U11 tablet comes with a standard manufacturer's warranty. For detailed warranty terms and

conditions, please refer to the warranty card included in your product packaging or visit the official DOOGEE website. For technical support, troubleshooting assistance beyond this manual, or service inquiries, please contact DOOGEE customer support through their official channels.

© 2025 DOOGEE. All rights reserved.