K&F Concept O275A5+BH-36

K&F Concept O275A5+BH-36 Camera Tripod User Manual

Model: O275A5+BH-36

1. Product Overview

The K&F Concept O275A5+BH-36 is a versatile and portable camera tripod designed for photographers and videographers. It features a robust aluminum alloy construction, a 36mm ball head, and a detachable monopod function, making it suitable for various shooting environments and devices.



Image: K&F Concept O275A5+BH-36 Camera Tripod with included accessories, showcasing its compact design and components.

2. Key Features

- **Flexible and Portable:** 5-section leg construction, adjustable height from 55 cm to 192 cm, with a folded size of 43 cm for easy transport.
- **Extensive Compatibility:** Includes 2 quick release plates, a mobile phone/tablet holder, and a Bluetooth remote for wide compatibility with mobile phones, tablets, MSLR, SLR cameras, and other devices.
- **Fliplock Quick Release:** Legs equipped with Fliplock quick release for fast and convenient locking and unlocking, saving setup time.
- **Detachable Monopod Design:** Converts into a more portable monopod with a maximum height of 203 cm for flexible and stable shooting.

- **36mm Ball Head:** Ensures stability, features a new oil-free damping design for smooth and precise camera rotation. Includes a 360-degree horizontal scale for easy panoramic shooting. Load capacity up to 8 kg, compatible with Arca standard quick release plate.

3. Package Contents

Please verify that all items listed below are included in your package:



Image: Diagram illustrating the components of the K&F Concept tripod, including the Arca-Swiss quick release plate, Bluetooth remote, and stabilization hooks.

- 1 x K&F Concept Tripod
- 1 x Mobile Phone Holder

- 1 x Tripod Bag
- 2 x Quick Release Plates (Arca-Swiss compatible)
- 1 x Bluetooth Remote Control

4. Setup and Assembly

4.1 Attaching Your Camera or Device

The tripod comes with two Arca-Swiss compatible quick release plates and a dedicated mobile phone/tablet holder.

1. Attach one of the quick release plates to the bottom of your camera or device using the 1/4-inch screw. Ensure it is securely tightened.
2. If using a smartphone or tablet, insert your device into the provided mobile phone holder. The holder can accommodate devices from 4.6 to 7.8 inches in length and 2.1 to 3.67 inches in width.
3. Slide the quick release plate (with camera) or the phone holder (with device) into the clamp on the ball head until it clicks securely into place. Tighten the locking knob on the ball head to prevent accidental release.

Applications



Image: The smartphone/tablet holder and the 1/4-inch interface, compatible with various devices.

4.2 Adjusting Tripod Height

The tripod legs feature Fliplock quick release mechanisms for rapid height adjustment.

1. To extend a leg section, flip open the corresponding Fliplock lever.
2. Pull the leg section outwards to the desired length.
3. Flip the Fliplock lever back to the closed position to secure the leg section. Ensure all levers are firmly closed before placing equipment on the tripod.
4. The center column can also be extended for additional height. Loosen the center column locking knob, extend the column, and then tighten the knob.



Image: The tripod can be adjusted to various heights, from a compact 43cm when folded to a maximum of 192cm.

5. Operating Instructions

5.1 Ball Head Operation

The 36mm ball head allows for flexible positioning of your camera.

- **Main Locking Knob:** Loosen this knob to adjust the angle of your camera (tilt and swivel). Tighten to secure the camera in position.
- **Panoramic Base Knob:** Loosen this knob to rotate the ball head horizontally 360 degrees for panoramic shots. The integrated 360-degree scale assists with precise alignment. Tighten to lock the panoramic rotation.

5.2 Monopod Conversion

The tripod can be quickly converted into a monopod for increased portability and flexibility.

1. Identify the leg with the foam grip. This is the detachable leg.
2. Unscrew the detachable leg from the tripod chassis by rotating it counter-clockwise.
3. Unscrew the ball head from the center column of the tripod.
4. Screw the ball head onto the top of the detached leg.
5. Your monopod is now ready for use. The monopod can extend up to 203 cm.




Image: Steps to convert the tripod into a monopod, showing the detachable leg and ball head reattachment.

5.3 Bluetooth Remote Control

The included Bluetooth remote control allows for remote shutter release, ideal for selfies and group photos.

1. Ensure the remote control has a working battery (1 AAA battery required, not always included).
2. Turn on the remote control (if it has a power switch).
3. Enable Bluetooth on your smartphone or tablet.
4. Search for available Bluetooth devices and select the remote control (usually named something like 'AB Shutter3' or similar).

5. Once paired, open your camera app. Press the corresponding button on the remote (iOS or Android) to trigger the shutter. The remote has an operating range of up to 10 meters.

6. Compatibility

The K&F Concept O275A5+BH-36 tripod is compatible with a wide range of devices, including:

- DSLR cameras (e.g., Canon, Sony, Nikon)
- Mirrorless cameras
- Action cameras
- Camcorders
- Smartphones (with included holder)
- Tablets (with included holder)



Image: Usage scenarios demonstrating the tripod's versatility for various photography and videography needs.

7. Specifications

Detailed specifications for the K&F Concept O275A5+BH-36 tripod:



Image: K&F Concept O275A5+BH-36 tripod with a camera, illustrating its dimensions and load capacity.

Feature	Specification
Model	O275A5+BH-36
Material	Aluminum Alloy
Max Height (Tripod)	192 cm (75.59 inches)
Max Height (Monopod)	203 cm (79.92 inches)

Feature	Specification
Min Height	55 cm (21.65 inches)
Folded Length	43 cm (16.93 inches)
Load Capacity	8 kg (17.6 lbs)
Net Weight	1.5 kg (3.3 lbs)
Leg Sections	5
Ball Head Diameter	36 mm
Compatible Devices	DSLR, Mirrorless, Action Cameras, Camcorders, Smartphones, Tablets
Bluetooth Remote Battery	1 x AAA (not included)

8. Maintenance

Proper maintenance will extend the lifespan of your tripod:

- **Cleaning:** Wipe down the tripod with a soft, dry cloth after each use. If it gets wet, dry it thoroughly to prevent corrosion. Avoid using harsh chemicals or abrasive materials.
- **Lubrication:** The ball head features an oil-free damping design and generally does not require lubrication. Do not apply oil or grease to the leg locks or other moving parts unless specifically instructed by the manufacturer.
- **Storage:** Store the tripod in its carrying bag in a cool, dry place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all screws, knobs, and leg locks to ensure they are tight and functioning correctly. Do not overtighten.

9. Troubleshooting

If you encounter issues with your tripod, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Tripod is unstable.	Leg sections not fully extended or locked; uneven surface; overloaded.	Ensure all Fliplock levers are securely closed. Adjust legs to match the terrain. Verify equipment weight does not exceed 8 kg.
Ball head movement is stiff or jerky.	Locking knob is too tight; dust/debris in the mechanism.	Loosen the main locking knob slightly. Clean the ball head area with a soft, dry cloth. Do not force movement.

Problem	Possible Cause	Solution
Bluetooth remote not connecting.	Battery low/dead; remote not paired; Bluetooth off on device.	Replace the AAA battery. Ensure Bluetooth is enabled on your phone/tablet. Re-pair the remote via your device's Bluetooth settings.
Leg sections won't extend/retract smoothly.	Dirt or sand inside leg sections; Fliplock mechanism obstructed.	Clean leg sections thoroughly. Ensure Fliplock levers are fully open before adjusting. Avoid using in sandy or dusty environments without proper protection.

10. Warranty and Support

K&F Concept products are manufactured to high-quality standards. For specific warranty information, please refer to the warranty card included with your product or visit the official K&F Concept website.

If you require technical assistance, have questions about product operation, or need to report a defect, please contact K&F Concept customer support through their official channels. Be prepared to provide your product model number (O275A5+BH-36) and proof of purchase.

For the most up-to-date support information, please visit:

K&F Concept Official Website

© 2024 K&F Concept. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question