

[Manuals.plus](#) /

› [HOSTACK](#) /

› HOSTACK King Size Upholstered Lift-Up Storage Bed Frame with Charging Station and Reading Lights Instruction Manual

HOSTACK B0DJ91JCXM

HOSTACK King Size Upholstered Lift-Up Storage Bed Frame

MODEL: B0DJ91JCXM

Instruction Manual

Introduction

Thank you for choosing the HOSTACK King Size Upholstered Lift-Up Storage Bed Frame. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Designed for comfort and functionality, this bed frame features a hydraulic lift-up storage system, an integrated charging station, adjustable reading lights, and a stylish wingback headboard.



A complete view of the HOSTACK King Size Lift-Up Storage Bed Frame, showcasing its upholstered design, integrated reading lights, and headboard charging station within a modern bedroom.

Safety Information

- Always use appropriate bedding materials for infants and young children.
- Do not exceed the weight limit of **1000 pounds**.
- Be cautious when using the lift-up storage mechanism to prevent injury. Ensure hands and fingers are clear before lowering the mattress platform.
- Keep all electrical components (charging station, reading lights) away from liquids.

Package Contents

Before beginning assembly, please verify that all components are present and undamaged. The package should contain:

- 1x Bed Frame (disassembled components)
- 1x Step-by-step Instructions Manual

- 1x Accessories Bag (containing hardware and tools)

Setup and Assembly

Assembly is required for this bed frame. Please follow the detailed step-by-step instructions provided in the included manual. It is recommended to have two people for assembly. Ensure you have adequate space and the necessary tools (a power drill may expedite the process, though basic tools are included).

1. **Unpack Components:** Carefully unpack all parts and lay them out on a clean, soft surface to prevent scratches. Verify against the parts list in your manual.
2. **Assemble Frame:** Follow the sequence of steps in the instruction manual to connect the main frame components.
3. **Install Slats:** Securely attach the wooden slats to the frame. Ensure the noise-avoiding EVA mute bar is correctly positioned.
4. **Attach Headboard:** Connect the adjustable wingback headboard to the main frame.
5. **Install Accessories:** Mount the reading lights and connect the charging station power cord as directed.



View of the bed frame's internal structure, highlighting the wooden slat support system and the metal frame components.

For a visual guide on the bed frame's features and assembly, please refer to the video below:

Your browser does not support the video tag.

An official product video demonstrating the key features of the HOSTACK Lift-Up Storage Bed Frame, including the hydraulic lifting mechanism, under-bed storage, adjustable reading lights, and integrated charging station.

Operating Instructions

1. Hydraulic Lift-Up Storage

The bed frame features a hydraulic mechanism for easy access to under-bed storage. To use:

- Grasp the lift-up handles located at the foot of the bed.
- Gently lift the mattress platform upwards. The hydraulic pistons will assist in raising and holding the platform in place.
- To lower, firmly push the platform down until it locks into its closed position. Ensure the anti-slip device is engaged to keep the mattress in place when closed.



Image demonstrating the hydraulic lifting mechanism that allows access to the spacious storage area beneath the mattress.

Eye-Protecting Reading Light



An example of the large storage capacity available under the bed frame, suitable for various items like luggage and bedding.

2. Headboard Charging Station

The headboard is equipped with two 5V/2.1A USB ports for convenient charging of your mobile devices. Simply plug your device's USB cable into the ports located on the top surface of the headboard.



Detailed view of the bed frame's headboard, showing the two integrated USB charging ports and space for devices.

3. Reading Lights

Two eye-protecting reading lights are integrated into the headboard. These lights feature:

- **360° Swivel Gooseneck:** Adjust the light direction as needed.
- **Three Color Temperatures:** Cycle through 2700K (Warm Light), 5000K (Warm-White Light), and 6000K (White Light) by pressing the power button.
- **Adjustable Brightness:** Hold the power button to dim or brighten the light.



Hydraulic Lifting Mechanism

Anti-Slip Device

Lift-up Handles

Close-up of the flexible gooseneck reading light, illustrating its 360° adjustability, three color temperature options, and brightness control.



Sleep



2700K Warm Light

Reading



5000K Warm-White Light

Daily Use



6000K White Light


A visual representation of the reading lights' ability to switch between warm, warm-white, and white light color temperatures.

4. Adjustable Wingback Headboard

The headboard is designed with an adjustable height feature to accommodate various mattress thicknesses. Adjust the headboard height during assembly or by re-positioning the attachment points as per the assembly manual.

KING SIZE

 **Mattress: 8-12in**

 **Max Capacity: 1000 lbs**




Diagram illustrating the key dimensions of the King Size bed frame, including length, width, headboard height, and under-bed clearance.

Maintenance

- **Cleaning Fabric:** For general cleaning, gently vacuum the upholstered fabric to remove dust. For spills, blot immediately with a clean, damp cloth. Avoid harsh chemicals.
- **Frame Inspection:** Periodically check all bolts and screws to ensure they are tight. Re-tighten if necessary to maintain stability and prevent squeaking.
- **Hydraulic Mechanism:** Do not apply excessive force to the hydraulic lift system. If it becomes stiff or difficult to operate, ensure no obstructions are present.

Troubleshooting

Problem	Possible Cause	Solution
Difficulty with assembly	Incorrect steps, missing parts, or damaged components.	Review the step-by-step instruction manual carefully. Ensure all parts are correctly identified and oriented. Contact customer support if parts are missing or damaged.

Problem	Possible Cause	Solution
Mattress gap between headboard and mattress	Mattress thickness is not optimal for the headboard's adjustable height.	This bed frame is designed for mattresses between 8-12 inches thick. Adjust the headboard height if possible, or consider a mattress within the recommended thickness.
Bed frame is noisy or unstable	Loose connections or uneven floor.	Check and tighten all bolts and screws. Ensure the bed frame is on a level surface. The wooden slats include an EVA mute bar to reduce noise.
Hydraulic lift mechanism is stiff	Obstruction or mechanism not fully engaged.	Ensure there are no items obstructing the mechanism. Apply even pressure when lifting or lowering. Do not force the mechanism.
Charging station or reading lights not working	Power connection issue or faulty component.	Verify the main power cord for the headboard is securely plugged into a working outlet. Check all connections for the lights and USB ports. If issues persist, contact customer support.

Specifications

Feature	Detail
Size	King
Material	Fabric, Metal, Wood
Overall Dimensions	84"L x 81.5"W x 45"H
Color	Beige
Weight Limit	1000 Pounds
Assembly Required	Yes
Special Features	Adjustable Wingback Headboard, Charging Station (2 USB Ports), Lift Up Storage, Reading Light (3 color temperatures, adjustable brightness, 360° swivel)
Recommended Mattress Thickness	8-12 inches (No box spring required)
Ground To Item Distance	12 Inches

Warranty and Support

For any questions, concerns, or assistance with your HOSTACK bed frame, please contact our customer support team. We offer 24/7 service and are always ready to help you.

How to Contact Support:

- Message us via the "Contact Seller" option on Amazon.

Please have your model number (B0DJ91JCXM) and purchase date ready when contacting support to ensure efficient service.