Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KCLASO V10

KCLASO Cordless Vacuum Cleaner User Manual

Model: V10

Introduction

The KCLASO V10 Cordless Vacuum Cleaner is designed for efficient and effortless home cleaning. Featuring a powerful 550W motor and 45KPa suction, it handles various cleaning tasks on multiple surfaces. Its intelligent touchscreen, multi-layer filtration system, and ergonomic design ensure a comfortable and thorough cleaning experience. This manual provides essential information for setup, operation, maintenance, and troubleshooting to help you get the most out of your vacuum cleaner.

Setup

Before first use, ensure all components are present and fully charge the battery. The modular design allows for easy assembly.

1. **Assemble the Main Unit:** Connect the telescopic tube to the main vacuum body.
2. **Attach the Floor Brush:** Secure the floor brush to the end of the telescopic tube.
3. **Install the Battery:** Slide the rechargeable battery pack into the designated slot on the main unit until it clicks into place.
4. **Initial Charge:** Fully charge the battery using the original adapter (identifiable by "V10 VACUUM"). The touchscreen will indicate battery percentage.



Figure 1: All components of the KCLASO V10 Cordless Vacuum Cleaner ready for assembly.



Figure 2: The complete package includes the LED roller brush, 2-in-1 dust brush, crevice nozzle, HEPA filter, extendable metal tube, wall mount, and power adapter.

Operating Instructions

The KCLASO V10 offers intuitive operation with its intelligent touchscreen and versatile attachments.

Power Modes and Suction Adjustment

- The LED touchscreen allows for quick switching between 3 suction levels with a simple tap.
- The display shows real-time remaining battery life and current suction power.
- Choose from Min, Mid, or Max modes to suit your cleaning needs.



Figure 3: The intelligent touchscreen provides real-time information and easy control over suction modes.

Versatile Cleaning with Attachments

The vacuum comes with various practical attachments for different cleaning scenarios:

- **Crevice Tool:** Ideal for hard-to-reach areas, window sills, frames, and car interiors.
- **2-in-1 Furniture Brush:** Suitable for cleaning curtains, furniture surfaces, and soft furnishings.
- The flexible swivel head rotates 0° to 180° sideways and 0° to 90° up and down, effortlessly reaching under furniture and into corners.
- Front LED lights illuminate the cleaning path, revealing hidden dust and debris.



Figure 4: The vacuum can be easily switched from a full-size stick vacuum to a handheld unit for diverse cleaning needs.



Figure 5: The flexible floor brush with LED headlights ensures thorough cleaning even in dark or hard-to-reach areas.

Official Product Video

Your browser does not support the video tag.

Video 1: A detailed review of the KCLASO Cordless Vacuum Cleaner, highlighting its lightweight design, powerful suction, and ease of use for various cleaning tasks. This video is provided by the seller, KCLASO US.

Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

Dust Cup Cleaning

- The dust cup has a one-touch dump design for easy, hygienic waste disposal.

- Press the button to release and empty the dust cup.
- Wash the dust cup and filters with cold water and dry completely before re-use.



Figure 6: The 500ML dust cup features a one-click empty design for convenient and hygienic disposal of collected debris.

Filter Cleaning

- The vacuum features a 6-layer filtration system including a HEPA filter, stainless steel filter, and sponge filters.
- For optimal performance, clean the HEPA filter every 2-3 weeks and replace it every 3 months.
- Ensure the dust cup’s exhaust port is aligned with the filter during assembly for proper installation.



Figure 7: The 6-layer filtration system effectively captures fine dust particles and prevents secondary pollution.

Roller Brush Cleaning

- The innovative V-shaped roller brush and comb design guide hair smoothly into the air duct, reducing tangling.
- If the red anti-tangle alert lights up on the touchscreen, clean the floor brush.
- Remove the brush roller and clean any debris or tangled hair.



Figure 8: The V-shaped brush design minimizes hair tangling and is easy to clean for continued efficiency.

Troubleshooting

- **Vacuum ceases functioning:** Inspect the floor brush and air intake for any obstructions.
- **Reduced suction power:** Check if the dust cup is full and needs emptying. Clean or replace the HEPA filter if it's clogged. Ensure the dust cup's exhaust port is properly aligned with the filter.
- **Short runtime:** Ensure you are using the original "V10 VACUUM" adapter for charging. Fully charge the battery before each use. Note that runtime may vary on long pile carpets (under 20 minutes in MAX mode, or less than 40 minutes in MIN mode).
- **Battery not charging:** Verify the original adapter is used and properly connected. Ensure the battery is fully inserted into the main unit or charging dock.

Specifications

Feature	Description
Brand	KCLASO
Model Name	V10
Motor Horsepower	550 Watts
Suction Power	45KPa (Max Mode)
Power Modes	3 (Min, Mid, Max)

Battery Type	Lithium-Ion (6 x 2500mAh)
Runtime	Up to 45 minutes (Min Mode)
Charging Time	5 Hours
Dust Cup Capacity	0.5 Liters (16 ounces)
Filtration System	6-Layer (HEPA, Stainless Steel, Sponge Filters)
Noise Level	<75dB
Product Dimensions	15"L x 12"W x 7"H
Item Weight	6.43 pounds
Special Features	LED Headlight, Self-Standing, Bendable Brush, Touch Screen, 6-in-1 Combinations

Warranty & Support

For warranty information, technical support, or service inquiries, please refer to the contact information provided in your product packaging or visit the official KCLASO website. KCLASO is committed to providing comprehensive after-sales support to ensure a positive customer experience.

© 2025 KCLASO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0DJBNGLM5

More documents and user manuals: **https://manuals.plus/**