

HONMEET 76ZR1551808Z32OCG

HONMEET Interlocking Sofa Connector Brackets User Manual

Model: 76ZR1551808Z32OCG

INTRODUCTION

This manual provides instructions for the installation and proper use of the HONMEET Interlocking Sofa Connector Brackets. These brackets are designed to securely connect modular furniture sections, such as sofas, beds, and chairs, preventing movement and maintaining alignment.

SAFETY INFORMATION

- Always wear appropriate safety gear, such as eye protection, when using power tools for installation.
- Ensure furniture is stable and supported during installation to prevent injury.
- Keep small parts away from children to avoid choking hazards.
- Do not overtighten screws, as this may damage the furniture or the connector.


PACKAGE CONTENTS

- 2 x HONMEET Interlocking Sofa Connector Brackets
- *(Screws for installation are typically not included and must be purchased separately, suitable for your furniture material.)*

SPECIFICATIONS

Item Weight	5.8 ounces
Product Dimensions	5.63 x 2.09 x 0.79 inches (14.3 x 5.3 x 2.0 cm)

Model Number	76ZR1551808Z32OCG
Material	Metal (typically galvanized steel)






Figure 1: Product dimensions. The bracket measures approximately 14.3 cm (5.62 inches) in length and 5.3 cm (2.08 inches) in width at the base.

SETUP AND INSTALLATION

Follow these steps to install the HONMEET Interlocking Sofa Connector Brackets:

1. **Identify Mounting Locations:** Determine the best location on the underside or side frame of your furniture sections where the connectors will be installed. Ensure the locations allow for proper alignment and secure interlocking. Typically, one bracket is installed on each section to be connected.
2. **Prepare the Surface:** Clean the mounting area on the furniture to ensure a secure attachment.
3. **Mark Pilot Holes:** Place one half of the connector bracket against the chosen mounting surface. Use a pencil or marker to mark the positions for the screw holes. Repeat this for the corresponding furniture section, ensuring the brackets will align and interlock correctly when the furniture pieces are brought together.




Figure 2: Drilling pilot holes. Use a drill to create pilot holes at the marked positions. Select a drill bit size appropriate for your screws and furniture material.

4. **Attach the Brackets:** Align the bracket with the pilot holes and secure it using appropriate screws (not included). Ensure the screws are tight but do not strip the wood or material.



Figure 3: Brackets and tools prepared for installation. Ensure all necessary tools and hardware are ready before beginning.

5. **Test Connection:** Once both brackets are securely installed on their respective furniture sections, bring the sections together. The male part of one bracket should slide into the female part of the other, creating a firm, interlocking connection.



FURNITURE ACCESSORIES

Furniture accessories, suitable for various sofas

Figure 4: Connecting furniture sections. Gently push the furniture pieces together until the brackets interlock securely.



Figure 5: Installed bracket. The bracket should be flush with the furniture frame and securely fastened.

OPERATING INSTRUCTIONS

To connect furniture sections, simply align the two pieces of furniture so that the installed interlocking brackets face each other. Push the sections firmly together until the male hook of one bracket slides into and engages with the female receiver of the other. To separate the furniture, pull the sections apart with a firm, steady motion.

MAINTENANCE

- Periodically inspect the brackets and screws for any signs of loosening or damage.
- Tighten any loose screws to ensure a secure connection.
- Clean the brackets with a dry cloth if dust or debris accumulates. Avoid using harsh chemicals that may corrode the metal.

TROUBLESHOOTING

- **Issue: Furniture sections do not interlock easily.**

Solution: Check the alignment of the brackets on both furniture pieces. Ensure they are installed at the same height and orientation. Verify that no obstructions are preventing the interlocking mechanism from engaging.

- **Issue: Furniture sections feel loose after interlocking.**

Solution: Inspect all screws to ensure they are securely tightened. If the furniture material is soft, consider using longer screws or reinforcing the mounting area if possible. Ensure the brackets themselves are not bent or damaged.

- **Issue: Brackets appear corroded or damaged.**

Solution: If corrosion or significant damage is present, the brackets may need to be replaced to ensure structural integrity and proper function.

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your HONMEET Interlocking Sofa Connector Brackets, please refer to your purchase documentation or contact the seller directly. Please have your model number (76ZR1551808Z32OCG) and purchase date available when contacting support.