

[Manuals.plus](#) /

› [Logitech G](#) /

› Logitech G PRO X TKL Rapid Tenkeyless Wired Gaming Keyboard User Manual

Logitech G PRO X TKL Rapid

Logitech G PRO X TKL Rapid Tenkeyless Wired Gaming Keyboard User Manual

[Introduction](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty &](#)

[Support](#)

1. INTRODUCTION

This manual provides comprehensive instructions for the Logitech G PRO X TKL Rapid Tenkeyless Wired Gaming Keyboard. This keyboard is designed for gaming, featuring magnetic analog switches, Rapid Trigger functionality, and customizable RGB lighting. Please read this manual thoroughly to ensure proper use and to maximize your experience with the product.



Image 1.1: Logitech G PRO X TKL Rapid Tenkeyless Wired Gaming Keyboard.

2. SETUP

2.1 Package Contents

Verify that your package contains the following items:

- PRO X TKL RAPID tenkeyless gaming keyboard
- USB A to C Charging/data cable
- User documentation

DESIGNED WITH PROS. ENGINEERED TO WIN.



Image 2.1: What's in the Box - Keyboard and USB-A to USB-C cable.

2.2 Connecting the Keyboard

1. Connect the USB-C end of the provided cable to the USB-C port on the keyboard.
2. Connect the USB-A end of the cable to an available USB port on your computer.
3. The keyboard will be recognized by your operating system and will be ready for basic use.

2.3 Software Installation (Logitech G HUB)

For full customization of actuation points, Rapid Trigger settings, KEYCONTROL, and LIGHTSYNC RGB lighting, install the Logitech G HUB software. This software is available for download from the official Logitech G website.

3. OPERATING INSTRUCTIONS

3.1 Magnetic Analog Switches and Rapid Trigger

The keyboard features magnetic analog (Hall-Effect) switches with Rapid Trigger functionality. This allows for highly responsive and precise input, particularly beneficial in fast-paced gaming scenarios.

- **Rapid Trigger:** This mode enables key reactivation without requiring a full release, allowing for quicker, repeated inputs.
- **Customizable Actuation Points:** Adjust the actuation point for each key to match your preferred sensitivity and play style. This can be configured via Logitech G HUB.



Image 3.1: Analog Switches - Responsive Magnetic Linear Experience.



Image 3.2: Rapid Trigger - Repeat Fast and Precise Actions.




Image 3.3: Customizable Actuation Points - Precise 0.1 mm Control, Adjustable Per Key.

3.2 KEYCONTROL Customization

Utilize the KEYCONTROL feature through Logitech G HUB to assign specific commands or create multi-action combos across multiple layers for every key on the keyboard.



Image 3.4: Customize with KEYCONTROL - Adjust Every Key via Logitech G HUB.

WHAT'S IN THE BOX

PRO X TKL RAPID



USB-A TO USB-C CHARGING AND DATA CABLE




Image 3.5: Key Priority Settings in Logitech G HUB.

3.3 LIGHTSYNC RGB Lighting

The keyboard features LIGHTSYNC RGB lighting, allowing for dynamic synchronization with on-screen action or music. You can personalize the color of individual keys and lighting effects using Logitech G HUB.




Image 3.6: LIGHTSYNC RGB Lighting in action.

3.4 Dedicated Media Controls and Game Mode

The keyboard includes dedicated media controls and a volume roller for convenient audio management. A Game Mode button is also present to disable certain keys (e.g., Windows key) during gameplay to prevent accidental interruptions.

LIGHT IT UP



LIGHTSYNC RGB LIGHTING

Image 3.7: Keyboard features including detachable USB-C cable, game mode, volume roller, and media controls.

4. MAINTENANCE

4.1 Cleaning

To maintain the keyboard's performance and appearance:

- Use a soft, lint-free cloth to wipe the surface of the keyboard.
- For dust and debris between keys, use compressed air.
- Avoid using harsh chemicals or abrasive materials, as these can damage the finish and keycaps.
- The PBT keycaps are designed for durability and resistance to wear.

4.2 Spill Prevention

While the keyboard is built with durable materials, liquid spills can cause damage. Exercise caution to prevent liquids from coming into contact with the keyboard's internal components.

5. TROUBLESHOOTING

If you encounter issues with your Logitech G PRO X TKL Rapid keyboard, refer to the following common solutions:

5.1 Keyboard Not Responding

- Ensure the USB-C cable is securely connected to both the keyboard and your computer.
- Try connecting the keyboard to a different USB port on your computer.
- Test the keyboard on another computer to determine if the issue is with the keyboard or the computer's setup.

5.2 Lighting Issues

- Verify that Logitech G HUB software is installed and up to date.
- Check lighting settings within G HUB to ensure desired effects are enabled.
- If lighting defaults to a basic blue, it may indicate G HUB is not running or not properly configured.

5.3 Key Input Problems (e.g., Multiple Letters, Unresponsive Keys)

- Ensure no debris is lodged under the affected keycaps. Use compressed air to clear any obstructions.
- If the issue persists, consider reinstalling the Logitech G HUB software.
- For advanced issues, consult Logitech G support.

6. SPECIFICATIONS

Feature	Detail
Brand	Logitech G
Series	PRO X TKL
Model Number	920-013132
Item Weight	5.3 ounces
Product Dimensions (LxWxH)	14.06 x 5.91 x 1.5 inches
Color	White
Power Source	Wired (USB-C)
Connectivity Technology	USB-C
Keyboard Description	Gaming
Recommended Uses	Business, Everyday Use, Gaming, Multimedia, Programming
Special Features	Backlit, Lightweight, Portable, Programmable Keys
Keyboard Backlighting	RGB (LIGHTSYNC)
Style	Rapid Trigger

7. WARRANTY & SUPPORT

7.1 Warranty Information

For detailed warranty information regarding your Logitech G PRO X TKL Rapid keyboard, please refer to the warranty card included with your product or visit the official Logitech G support website. Warranty terms and conditions may vary by region.

7.2 Customer Support

If you require further assistance, technical support, or have questions not covered in this manual, please contact Logitech G customer support. Support resources, including FAQs and contact information, are available on the official Logitech G website.

© 2025 Logitech G. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question