

[Manuals.plus](#) /

› [Sweetcrispy](#) /

› Sweetcrispy Heavy Duty Rolling Clothes Rack (Model SWBYJ-11) Instruction Manual

Sweetcrispy SWBYJ-11

Sweetcrispy Heavy Duty Rolling Clothes Rack (Model SWBYJ-11) Instruction Manual

PRODUCT OVERVIEW

The Sweetcrispy Heavy Duty Rolling Clothes Rack, Model SWBYJ-11, is designed for versatile clothing storage. It features three adjustable wire shelves, two hanging rods, and side hooks, all supported by a sturdy metal frame. Equipped with lockable 360° rotating wheels, this rack offers both mobility and stability for various environments such as bedrooms, laundry rooms, or cloakrooms.

Massive Storage

Study Wire Shelves



Extra Space on the Top



Double Side Hooks



Stable Hanging Rod





Image: The Sweetcrispy Rolling Clothes Rack showcasing its massive storage capabilities with clothes on hanging rods, items on shelves, and side hooks for accessories.

Your browser does not support the video tag.

Video: An overview of the Sweetcrispy Clothes Rack, demonstrating its features like double side hooks, double clothing hanging rods, and mobility.

SAFETY INFORMATION

- Ensure all connections are securely tightened before use.
- Do not exceed the maximum load capacity: 440 lbs when stationary, 260 lbs when moving. Each tier has a maximum load of 350 lbs.
- Distribute weight evenly across shelves and hanging rods to maintain stability.
- Engage wheel locks when the rack is in a desired position to prevent unintended movement.

COMPONENTS LIST

Before assembly, verify that all components listed below are present:

- Assembly Tools
- Clothes Rack components (poles, shelves, rods)
- Instruction Manual (this document)
- Clips
- Casters (wheels)
- Levelers
- Wrench
- Garment rods
- Hook racks
- Clothes hooks
- Washers
- Screws

ASSEMBLY INSTRUCTIONS

This clothes rack is designed for easy assembly without additional tools. Follow these steps or refer to the installation video for visual guidance.

1. **Attach Levelers or Casters:** Based on your preference for stationary or mobile use, screw the levelers (F) or casters (E) onto the threaded end of the Bottom poles (C). Tighten securely with the provided wrench (G).
2. **Install Bottom Shelf:** Place the Hook racks (I) through the corner holes of the bottom 4-cone shelf (A). Fit the shelf carefully and securely over the clips (D) on the bottom poles.
3. **Assemble Garment Rods:** Unscrew the preinstalled screws on the Garment rod (H). Install the clothes hook (J) onto the Garment rod (H), and then reinstall the screws (do not overtighten).
4. **Connect Upper Poles:** Attach the Upper poles (B) to the Bottom poles (C) using the clips (D). Ensure the flange fits into the groove and there are small gaps between the plastic clips for a secure fit.
5. **Install Middle and Top Shelves:** Repeat step 2 for the middle and top 4-cone shelves (A), adjusting their height as desired using the clips (D).
6. **Attach Garment Rods:** Secure the assembled Garment rods (H) under the shelves by tightening the screws.

Easy to Assemble



The flange needs to fit into groove.



Gaps between plastic clips



Slide down firmly to secure the clips.



Adjustable shelves can be adjusted up and down to meet your different needs.

Image: Visual guide for the assembly process, highlighting key steps like fitting flanges into grooves and securing clips.

Your browser does not support the video tag.

Video: A step-by-step installation guide for the Sweetcrispy Clothes Rack, demonstrating how to assemble each part.

OPERATING INSTRUCTIONS

Adjustable Wire Shelves

The wire shelves can be adjusted to various heights to accommodate different storage needs. To adjust a shelf, remove items, detach the clips supporting the shelf, reposition the clips to the desired height on the poles, and then reattach the shelf securely.

Adjustable Storage Shelves



Image: The clothes rack illustrating the adjustable nature of its storage shelves, allowing for customized configurations.

Lockable 360° Wheels

The rack is equipped with four rolling wheels, all of which are lockable. To move the rack, unlock all wheels. To secure the rack in place, engage the locks on all four wheels. This ensures stability and prevents unwanted movement.

Lockable Caster for Easy to Move



More quietly

Flexible 360° rotating wheels



4 of the wheels are lockable



4 adjustable leveling feet



Image: A detailed view of the lockable 360° rotating wheels, highlighting their functionality for easy movement and secure positioning.

Side Hooks

Utilize the integrated side hooks for hanging bags, hats, scarves, or other accessories, maximizing the storage potential of the rack.

MAINTENANCE

To ensure the longevity and appearance of your Sweetcrispy clothes rack, follow these maintenance guidelines:

- **Cleaning:** All metal parts are coated with powder, making them easy to clean. Wipe down the rack with a soft, damp cloth and mild detergent. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Load Management:** Always adhere to the specified weight limits to prevent bending or damage to the shelves and

rods.



Image: Demonstrating the ease of cleaning the powder-coated metal surfaces of the rack.

TROUBLESHOOTING

If you encounter any issues with your Sweetcrispy Rolling Clothes Rack, please refer to the following common solutions:

- **Rack is unstable or wobbly:**
 - Ensure all clips are correctly installed and securely fastened to the poles.
 - Verify that the shelves are properly seated over the clips.
 - If using levelers, adjust them to ensure the rack stands evenly on the floor.
 - If using casters, ensure all four wheels are locked when stationary.
- **Difficulty moving the rack:**
 - Check that all wheel locks are disengaged.
 - Ensure the rack is not overloaded beyond its moving weight capacity (260 lbs).
- **Shelf not holding weight:**
 - Confirm that the clips are correctly positioned and fully closed around the poles.
 - Ensure the weight on the shelf does not exceed the per-tier maximum load of 350 lbs.
 - Distribute items evenly to prevent concentrated stress points.

SPECIFICATIONS

Brand	Sweetcrispy
Model Number	SWBYJ-11
Color	Black
Material	Alloy Steel
Product Dimensions (Overall with wheels)	17.72"D x 47.24"W x 80.31"H

Maximum Load Capacity (Stationary)	440 lbs
Maximum Load Capacity (Moving)	260 lbs
Per-tier Maximum Load Capacity	350 lbs
Number of Shelves	3
Installation Type	Free Standing
Special Features	Lockable Wheels, Portable, Adjustable Shelves, Side Hooks



Image: The clothes rack displaying its dimensions and maximum weight capacities for both stationary and mobile use.

WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your Sweetcrispy Rolling Clothes Rack, please contact Sweetcrispy

customer service. Refer to your purchase documentation for specific warranty details and contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question